

The Available Solution



SF-320 & HF-320

General-purpose Compact Inverter
V/F CONTROL-SENSORLESS VECTOR CONTROL

SF & HF

200V class 0.2–7.5kW
400V class 0.4–7.5kW



 **Sumitomo Heavy Industries, Ltd.**
POWER TRANSMISSION & CONTROLS GROUP

Cat. No.
D1001E-1

SF-320 • HF-320

From now on

Select a model the sensible way by Load characteristics!!

Two series are available for different purposes.

General-purpose inverter, **SF-320**, and sensorless vector inverter, **HF-320**



High-function" to "High Functionality and easy operation

- Front cover protects programming keys to comply with PL Law.
- External signals permit use for various applications.
- Easily switch operation between panel and external signal.

The method of operation remains unchanged!

- The two models share external dimensions, basic functions, and basic operation so you can focus your selection based on load characteristics.
- The HF Series eliminate complicated setup for achieving starting torque.


State-of-the-art functions

1. Intelligent terminal

Program the terminals for the functions required by the application.


2. Multistep speed change (16 stages)

Fine adjustment meets the need in the age of Flexible Manufacturing System (FMS).



3. PID function

Use PID function to simplify process control.



Global applications



The overseas specification series are also available.

Standard lineup of 400 V-class series for small capacity motors

0.2 0.4 0.75 1.5 2.2 3.7 5.5 7.5 ^{kW}

Input...3-phase, 200 V / Output...3-phase, 200 V

Input...3-phase, 400 V / Output...3-phase, 400 V

Input...Single-phase, 200 V / Output...3-phase, 200 V * (W-version only)

□ F 3202 - A20 - □

Type
 None: standard specifications
 W: CE, UL, Standard specifications (Single phase series is only available for W type.)
 A: Southeast asian Specifications (Carrier Frequency Default Setting is lower.)

Series name
 S: SF-320 Series
 H: HF-320 Series

Voltage class
 2: 200V class
 4: 400V class

Applicable motor capacity
 A20: 0.2kW 2A2: 2.2kW
 A40: 0.4kW 3A7: 3.7kW
 A75: 0.75kW 5A5: 5.5kW
 1A5: 1.5kW 7A5: 7.5kW



SF-320

- Apply V/f control method in multi-motor application* and in PID function for industrial pumps and fans.

*Operation of more than one motor with one inverter

HF-320

- The sensorless vector control method provides 200% starting torque ! Furthermore, the maximum torque during operation exceeds 150%.
- The auto tuning function permits high-performance operation.
- This inverter is suitable for machines that need high torque during start-up, slow-speed operation or regular operation. It is ideal for applications such as extruders, high-viscosity pumps, cart drivers, elevators, and special agitators, as well as for applications that need regenerative braking.



List of Functions

Monitor Mode/Basic Setting Mode

| | HF | SF | Code | Function | Monitor/setting Range | Initial setting |
|-------------------|----|----|------|---|--|------------------|
| Monitor | ● | ● | d01 | Output frequency monitor | 0.0–360.0Hz | – |
| | ● | ● | d02 | Output current monitor | 0.00–999.9A | – |
| | ● | ● | d03 | Running direction monitor | F(forward run), r(reverse run), □(stop) | – |
| | ● | ● | d04 | PID feedback value monitor | 0.01–9,999 | – |
| | ● | ● | d05 | Input terminal status monitor | Display the status of terminal | – |
| | ● | ● | d06 | Output terminal status monitor | Display the status of terminal | – |
| | ● | ● | d07 | Operating frequency converted value monitor | (output frequency (Hz))×(frequency converted value: b86) | – |
| | ● | ● | d08 | Trip monitor | Details of the latest error are displayed | – |
| | ● | ● | d09 | Trip history monitor | The causes of past two errors, excluding the latest one, are displayed | – |
| Setting | ● | ● | F01 | Output frequency setting | 0.5–360Hz | Volume set value |
| | ● | ● | F02 | Acceleration time 1 setting | 0.1–3000s | 10.0s |
| | ● | ● | F03 | Deceleration time 1 setting | 0.1–3000s | 10.0s |
| | ● | ● | F04 | Running direction setting | Forward/Reverse | Forward |
| Expanded Function | ● | ● | A-- | (Extended function of A group setting) | | |
| | ● | ● | B-- | (Extended function of B group setting) | | |
| | ● | ● | C-- | (Extended function of C group setting) | | |
| | ● | ● | H-- | (Extended function of H group setting) | | |

Expanded Function A (Frequently Used Functions)

| | HF | SF | Code | Function | Monitor/setting Range | Initial setting |
|-------------------------|----|-----|-----------------------------|--|--|---|
| Basic setting | ● | ● | A01 | Frequency Command | 00: Potentiometer(Front case) 01: Control terminal 02: Panel or Digital operator | 00 |
| | ● | ● | A02 | Run command | 01: Control terminal 02: Panel or Digital operator | 02 |
| | ● | ● | A03 | Base frequency setting | 50–360Hz | 60Hz |
| | ● | ● | A04 | Maximum frequency setting | 50–360Hz | 60Hz |
| Analog input setting | ● | ● | A11 | External frequency setting start | 0.03–60Hz | 0.0Hz |
| | ● | ● | A12 | External frequency setting end | 0.0–360Hz | 0.0Hz |
| | ● | ● | A13 | External frequency setting start rate | 0–100% | 0% |
| | ● | ● | A14 | External frequency setting end rate | 0–100% | 100% |
| Multispeed freq setting | ● | ● | A15 | External frequency start pattern setting | 00: Set frequency of (A11) 01: 0Hz | 01 |
| | ● | ● | A16 | External frequency sampling count setting | 1–8 times | 8 |
| | ● | ● | A20 A35 | Multispeed frequency setting (speed 0–speed 15) | Setting range: 0.0–360Hz Arbitrary setting is possible | 0: 0Hz 1: 5Hz 2: 10Hz 3: 15Hz 4: 20Hz 5: 30Hz 6: 40Hz 7: 50Hz 8: 60Hz Other: 0Hz |
| | ● | ● | A38 | Jogging frequency setting | 0.00–9.99Hz | 1.0Hz |
| V/F characteristics | ● | ● | A39 | Jogging stop operation selection | 00: Free run stop 01: Decelerate stop 02: DC braking | 00 |
| | ● | ● | A41 | Torque boost mode selection | 00: Manual 01: Auto | 00 |
| | ● | ● | A42 | Manual torque boost setting | 0–99 | 30 |
| | ● | ● | A43 | Boost frequency setting | 0.0–50.0% | 1.5% |
| | ● | ● | A44 | V/F characteristics setting | 00: Constant torque 01: Reduced torque 02: Sensorless vector (HF only) | 00 |
| ● | ● | A45 | Output voltage gain setting | 50–100% | 100% | |

| | HF | SF | Code | Function | Monitor/setting Range | Initial setting |
|--|----|----|------|---|--|-----------------|
| DC Braking | ● | ● | A51 | DC braking function selection | 00: Invalid 01: Valid | 00 |
| | ● | ● | A52 | DC braking frequency setting | 0.00–10.0Hz | 0.5 |
| | ● | ● | A53 | DC braking output delay time setting | 0.00–5s | 0.0 |
| | ● | ● | A54 | DC braking power setting | 0–100% | 0 |
| | ● | ● | A55 | DC braking time setting | 0.0–60s | 0.0 |
| Upper/Lower limiter, jump frequency | ● | ● | A61 | Frequency upper limit setting | 0.0–360Hz | 0.0Hz |
| | ● | ● | A62 | Frequency lower limit setting | 0.0–360Hz | 0.0Hz |
| | ● | ● | A63 | Jump frequency setting 1 | 0.0–360Hz | 0.0Hz |
| | ● | ● | A64 | Jump frequency width setting 1 | 0.0–10Hz | 0.5Hz |
| | ● | ● | A65 | Jump frequency setting 2 | 0.0–360Hz | 0.0Hz |
| | ● | ● | A66 | Jump frequency width setting 2 | 0.0–10Hz | 0.5Hz |
| | ● | ● | A67 | Jump frequency setting 3 | 0.0–360Hz | 0.0Hz |
| | ● | ● | A68 | Jump frequency width setting 3 | 0.0–10Hz | 0.5Hz |
| PID Control | ● | ● | A71 | Selection of PID function | 00: Without PID control 01: With PID control | 00 |
| | ● | ● | A72 | P gain setting | 0.2–5 times | 1.0 |
| | ● | ● | A73 | I gain setting | 0.0–150s | 1.0 |
| | ● | ● | A74 | D gain setting | 0.0–100s | 0.0 |
| | ● | ● | A75 | PID scale rate setting | 0.01–99.9 | 1.0 |
| | ● | ● | A76 | Feedback input method setting | 00: IRF terminal (Current input) 01: VRF terminal (Voltage input) | 00 |
| AVR | ● | ● | A81 | AVR function selection | 00: ON 01: OFF 02: OFF at deceleration | 02 |
| | ● | ● | A82 | Motor input voltage setting | 200/220/230/240 200V class 380/400/415/440/460 400V class | 200/400 |
| Acceleration/Deceleration function | ● | ● | A92 | Second acceleration time setting | 0.1–3,000S | 15.0S |
| | ● | ● | A93 | Second deceleration time setting | 0.1–3,000S | 15.0S |
| | ● | ● | A94 | Second acceleration/deceleration switching method | 00: External contact signal (2 nd acceleration/deceleration terminal) 01: Preset frequency | 00 |
| | ● | ● | A95 | Acceleration switching frequency | 0–360Hz | 0Hz |
| | ● | ● | A96 | Deceleration switching frequency | 0–360Hz | 0Hz |
| | ● | ● | A97 | Acceleration pattern selection | 00: Linear 01: S-curve | 00 |
| | ● | ● | A98 | Deceleration pattern selection | 00: Linear 01: S-curve | 00 |

■ Expanded Function H (HF–320 Sensorless Vector Control Tuning function)(Note 1)

| | Code | Function | Setting Range | Initial setting |
|-------------------------------|------|---|---|-----------------|
| Sensorless Vector Control | H01 | Auto tuning mode selection | 0: Without auto tuning 1: With auto tuning 2: Measurement of resistance and inductance | 0 |
| | H02 | Motor data selection | 0: Standard motor 1: AF motor (Inverter motor) 2: Auto tuning data (H30–H34 selection) | 0 |
| | H03 | Motor capacity | 0.1/0.2/0.4/0.75/1.5/2.2/3.7/5.5/7.5 (kW) | (Note 2) |
| | H04 | Motor poles | 2/4/6/8 | 4 |
| | H05 | Speed control response constant setting | 0–99 Equivalent to 10 mec per set value of 1 | 20 |
| | H06 | Motor stabilization constant setting | 0–255% | 100 |
| Motor Constant | H20 | Motor constant R1 setting | 0–0.999,1.00–9.99,10.0–65.5 Unit: Ω | (Note 3) |
| | H21 | Motor constant R2 setting | 0–0.999,1.00–9.99,10.0–65.5 Unit: Ω | (Note 3) |
| | H22 | Motor constant L setting | 0–0.999,1.00–9.99,10.0–65.5 Unit: mH | (Note 3) |
| | H23 | Motor constant I _o setting | 0–0.999,1.00–9.99,10.0–65.5 Unit: A | (Note 3) |
| | H24 | Inertia setting | Ratio to the single inertia of a motor with the same kW as the inverter 0–0.999,1000 Unit: % | 2.0 |
| Auto Tuning Motor Constant | H30 | Motor constant R1 setting | 0.–0.999,1.00–9.99,10.0–65.5 Unit: Ω | (Note 3) |
| | H31 | Motor constant R2 setting | 0.–0.999,1.00–9.99,10.0–65.5 Unit: Ω | (Note 3) |
| | H32 | Motor constant L setting | 0.–0.999,1.00–9.99,10.0–65.5 Unit: Ω | (Note 3) |
| | H33 | Motor constant I _o setting | 0.–0.999,1.00–9.99,10.0–65.5 Unit: mH | (Note 3) |
| | H24 | Inertia setting | Ratio to the single inertia of a motor with the same kW as the inverter 0–0.999,1000 Unit: % | 2.0 |

(Note 1) SF-320 Series have no H parameter.

(Note 2) The same capacity as the inverter


(Note 3) Data on SUMITOMO standard motors with the same capacity as the inverter

Operation

Operation


Explanation of operation panel

Easily operate the SF-320 and HF-320 series with the standard equipped digital operator panel.




Method of operation


1. Setting (Setting the maximum frequency)



2. Running the motor (Using the potentiometer)



3. Monitoring (Monitoring the output current value)



Explanation of Functions

Monitor


- d01** Output frequency monitor
- d02** Output current monitor
- d03** Operation direction monitor
- d04** PID feedback value monitor
- d05** Input terminal status monitor
- d06** Output terminal status monitor
- d07** Output frequency equivalent monitor
- d08** Trip monitor
- d09** Trip history monitor

• The output frequency and current value can also be monitored.

d05 Input terminal status monitor

The status of all multifunctional input terminals is displayed together.

• Example of display



d06 Output terminal status monitor

• The status of the error output terminal and multifunctional output terminal is displayed together.

• Example of display



The status of error output terminal ON means the case where an error has occurred or power is turned off (b-contact point) or an error has occurred (a-contact point).

d07 Output frequency equivalent monitor

• The output frequency multiplied by the conversion factor set by **b66** is displayed.

Use this to display line speed. (Refer to p.10.)

d08 Trip monitor

d09 Trip history monitor

- **d08** displays the contents of the latest error. In addition to the error code, the output frequency, output current, and DC voltage between P and N at time of trip can be viewed.
- **d09** shows the error codes of the last two trips prior to the latest one. (Refer to p.13)

Setting the output frequency

F01 Output frequency setting


- When setting the frequency command destination of **A01** to 02: Panel or Digital operator, set the output frequency by **F01**. Also use **F01** to set one of the multispeed frequency.

Setting the acceleration/deceleration time

F02 Acceleration time 1 setting

F03 Deceleration time 1 setting

- **F02** is the acceleration time from 0Hz to **A04** (maximum frequency). **F03** is the deceleration time from **A04** (maximum frequency) to 0Hz.



Setting the direction of operation

F04 Operation direction setting

- The direction of motor operation (rotation) is set.

Setting the frequency command destination and operation command destination

A01 Frequency command

A02 Operation command

- The frequency command destination and operation/stop command destination are set by the following codes.

Even if the operation command destination is set to the control terminal, the **STOP** key on the panel and operator is valid. It can be made invalid as well. (Function code **b87**)

A01 Code of frequency command destination

A02 Code of operation command destination

| Command destination | Code |
|--|------|
| Main unit volume | 00 |
| Control terminal (VRF and IRF terminals) | 01 |
| Digital panel | 02 |


| Command destination | Code |
|--|------|
| Control terminal (VRF and IRF terminals) | 01 |
| Digital panel | 02 |

Setting the base frequency and maximum frequency

A03 Base frequency setting

A04 Maximum frequency setting

- The base frequency and maximum frequency can be set within the 50-360 Hz range (1 Hz).




Explanation of Functions

Explanation of Functions


Analog input setting

- A11** External frequency setting start
- A12** External frequency setting end
- A13** External frequency setting start rate
- A14** External frequency setting end rate
- A15** External frequency start pattern setting
- A16** External frequency sampling count setting

• The frequency scaling for the analog input signal (4-20mA or 0-10V) is adjusted as follows.



- A11** : The scaling start frequency is set.
- A12** : The scaling end frequency is set.
- A13** : The analog input level for the scaling start frequency is set.
- A14** : The analog input level for the scaling end frequency is set.
- **A15** sets the frequency output start method.



When **A15** : 00 Starting at the start frequency (set by **A11**).

When **A15** : 01 Starting at 0 Hz.

• **A16** sets the number of sampling times (1-8 times) of the analog input filter. The average value sampled is used to determine the command frequency. Reduce the sample number to increase response time. Increase the sample number to filter out noisy signals.


| | |
|---------------------------|---------------|
| Set value | 1 ↔ 8 |
| Response | Quick ↔ Slow |
| Stability (Filter effect) | Small ↔ Large |

Multispeed frequency setting

A20 - **A35** Multispeed frequency setting

• A maximum of 16 multispeed operation is possible when multispeed frequencies are set in **A20** - **A35** . (Input terminals are set with C01-C06.)

| | Multispeed frequency setting code | Multifunctional input terminal | | | |
|----------|-----------------------------------|--------------------------------|-----|-----|-----|
| | | SW4 | SW3 | SW2 | SW1 |
| 0 speed | A20 | OFF | OFF | OFF | OFF |
| 1 speed | A21 | OFF | OFF | OFF | ON |
| 2 speed | A22 | OFF | OFF | ON | OFF |
| 3 speed | A23 | OFF | OFF | ON | ON |
| 4 speed | A24 | OFF | ON | OFF | OFF |
| 5 speed | A25 | OFF | ON | OFF | ON |
| 6 speed | A26 | OFF | ON | ON | OFF |
| 7 speed | A27 | OFF | ON | ON | ON |
| 8 speed | A28 | ON | OFF | OFF | OFF |
| 9 speed | A29 | ON | OFF | OFF | ON |
| 10 speed | A30 | ON | OFF | ON | OFF |
| 11 speed | A31 | ON | OFF | ON | ON |
| 12 speed | A32 | ON | ON | OFF | OFF |
| 13 speed | A33 | ON | ON | OFF | ON |
| 14 speed | A34 | ON | ON | ON | OFF |
| 15 speed | A35 | ON | ON | ON | ON |



* Multispeed 1 through 15 can always be activated. However, Multispeed 0 can only be activated when A01 is programmed to 02.

* Additionally, A20 through A35 can be programmed using F01 when each corresponding speed is activated.



* Setting during operation is possible.

Jogging operation setting

- A38** Jogging frequency setting
- A39** Jogging stop mode selection

• Use motor jogging operation for simple positioning. Assign jogging to any of the input terminals FR through RST.

• The operation after jogging can be selected from among "Free-run stop," "Deceleration stop," and "DC braking stop."




Torque boost setting

- A41** Torque boost mode selection
- A42** Manual torque boost setting
- A43** Manual torque boost frequency adjustment

• The output voltage is raised in the low-frequency band to adjust the motor torque. **A41** permits selection of Manual/Auto for torque boost.

• When the torque boost is set to Manual, the torque boost level and the boost frequency can be set.




Explanation of Functions

V/F characteristic setting

A44 V/F characteristics setting

A45 Output voltage gain setting

- **A44** permits selection of constant torque or reduced torque of the V/F characteristic by means of a load. HF-320 permits selection of sensorless control as well.
- The output voltage at the base frequency can be set within 50-100% of the range by **A45**. Use this to operate a motor with rated voltage lower than the inverter supply voltage under optimum condition.



DC braking

A51 DC braking function selection

A52 DC braking frequency setting

A53 DC braking output wait time setting


A54 DC braking force setting

A55 DC braking time setting

- Use DC braking during deceleration and stopping for position and to adjust stopping accuracy.
- When the DC braking output wait time is set, the operation during that time will be in the free-run state.

(Note 1) Disable DC braking for applications with frequent starts and stops.

(Note 2) Excessively strong braking force may cause tripping.




Upper/lower limiter

A61 Frequency upper limiter setting

A62 Frequency lower limiter setting

- The upper and lower limits of the output frequency can be controlled.




Jump frequency setting

A63, **A65**, **A67** Jump frequency setting

A64, **A66**, **A68** Jump frequency width setting

* Used to avoid resonance frequencies on the applied machinery.

A maximum of three jump frequencies can be set.



PID function

A71 PID control selection

A72 P gain setting

A73 I gain setting

A74 D gain setting

A75 PID scale setting

A76 Feedback input method setting

Use PID operation to control processes with a feedback signal. PID control the motor speed to drive the error between the target value and feedback value to zero.

It is effective for controlling processes such as temperature, pressure, flow rate, and air capacity.

<P: Proportional control>

In this control, the operation quantity is proportional to the deviation of the target value and feedback value.

A72 P gain setting K_P

- The response of the operation quantity with respect to deviation is adjusted.

| | | | |
|-----------|----------|---|--------|
| K_P | Large | ↔ | Small |
| Response | Quick | ↔ | Slow |
| Stability | Unstable | ↔ | Stable |

<I: Integral control>

Under the proportional control alone, the operation quantity is small when the deviation is small; therefore correction may not be sufficient, and will not coincide with the target value.

I: Integral control is the function to correct the above. Deviation is accumulated with the passage of time to correct the operation quantity.

A73 I gain setting K_I

- Integral time is set. When the integral time is short ($1/K_I$), the response is quick.

| | | | |
|-----------|----------|---|--------|
| K_I | Small | ↔ | Large |
| Response | Quick | ↔ | Slow |
| Stability | Unstable | ↔ | Stable |

<D: Differential operation>

Differential operation uses the rate of change of the deviation to adjust the operation quantity. It is used for correction of P (proportional) and I (integral) control.

A74 D gain setting K_D

| | | | |
|-----------|----------|---|--------|
| K_D | Large | ↔ | Small |
| Response | Quick | ↔ | Slow |
| Stability | Unstable | ↔ | Stable |

A75 PID scale setting

- This function converts the target value so that it will match the feedback value.

d04 permits monitoring of the value obtained by multiplying the feedback value by the factor of **A75**.

Indication by flow rate and air capacity is also possible.

Explanation of Functions

Explanation of Functions

A76 Feedback input method setting

- The feedback input destination is set.
- Code [00] ... IRF terminal (4–20mA)
 [01] ... VRF terminal (0–10VDC)

AVR function

A81 AVR function selection

A82 AVR motor voltage selection

- Irrespective of the input power, the output voltage is corrected and maintained at a constant value according to the motor voltage. (However, output voltage exceeding the input voltage of the inverter is not possible.)
- The AVR function can be turned OFF during deceleration.

2nd deceleration function

A92 2nd Acceleration time setting

A93 2nd Deceleration time setting


A94 2nd accel/decel change method

A95 Acceleration time crossover frequency


A96 Deceleration time crossover frequency

- The acceleration and deceleration time can be changed during operation. Use the 2nd acceleration and 2nd deceleration times when load inertia changes during operation.
- Change the acceleration and deceleration time with input terminals or with the crossover frequency setting.

<Change by terminal>



<Change by crossover frequency>




Acceleration/deceleration pattern

A97 Acceleration pattern selection

A98 Deceleration pattern selection

- The characteristics of acceleration and deceleration can be selected from among "linear" and "S-curve."
- The S-curve permits softer starts and stops than linear acceleration/deceleration. It is effective in preventing cargo from tipping.



Setting the restart (mode)

b01 Restart mode


b02 Allowable undervoltage time setting

b03 Retry waiting time setting

- Retry or restart is possible after undervoltage, overcurrent, and overvoltage protection functions. (If the fault conditions still persists after the decided retrials, the drive will stop.)

<Set value of b01>

| Set value | Function |
|-----------|--|
| 00 | Alarm output after tripped |
| 01 | 0 Hz restart |
| 02 | Frequency matching restart |
| 03 | Deceleration stop after frequency matching restart |




Electronic thermal

b12 Electronic thermal level setting (Note 1)

b13 Electronic thermal characteristics selection

- Level and characteristic setting are available for the built-in electronic thermal relay to protect motor from overheating.

Explanation of Functions



(Note) Contact the technical staff at our factory when the electronic thermal level is to be set below 50%.

Overload restriction

- b21** Overload restriction peration mode selection
- b22** Overload restriction level setting
- b23** Overload restriction deceleration rate

- The level at which the overload restriction function is activated, details of operation, and deceleration rate for overload restriction can be set.
- * When this function is used for a load with a large moment of inertia, the overload restriction level will extend the deceleration time.

Software lock (data change prevention)

b31 Lock selection

- When set data should not be changed, use this software lock function.
- The software lock function is enabled by code setting or by a control terminal.

| Set value | Function |
|-----------|--|
| 00* | [When software lock terminal is ON] Change of any function other than software lock is impossible. |
| 01* | [When software lock terminal is ON] Change of any function other than software lock and frequency setting is impossible. |
| 02 | [Whether software lock terminal is ON or OFF] Change of any function other than software lock is impossible. |
| 03 | [Whether software lock terminal is ON or OFF] Change of any function other than software lock and frequency setting is impossible. |

* When the control terminal is used

No-load reactive current setting

b32 Reactive current setting

- The no-load (reactive) current of the motor is set.

Note: **b32** is only for SF-320.

Analog meter adjustment


b81 Analog meter adjustment

- The scale of an analog frequency counter and ammeter connected to the inverter can be adjusted.

Starting frequency adjustment

b82 Starting frequency adjustment

- The starting frequency output from the inverter can be adjusted. Increase the starting frequency to increase the starting torque. (Higher values will reduce the soft start and increase the inrush current.)



Carrier frequency setting

b83 Carrier frequency setting

- The carrier frequency can be changed. When the carrier frequency is lowered, the motor noise increases, but generated high-frequency noise and leakage current can be reduced.

(The carrier frequency is held at 1 kHz automatically when DC braking is working.)

| | |
|-------------------|-----------------------------------|
| Carrier frequency | Low \longleftrightarrow High |
| Motor noise | Large \longleftrightarrow Small |
| Leak current | Small \longleftrightarrow Large |

(Note) The table is not quantitative.

Data/trip history initialization

b84 Initialization mode selection

b85 Initialization data selection

- Data on all the functions can be returned to the initial set values. In addition, the trip history can be cleared.

Setting the frequency conversion scale display function

b86 Frequency conversion value setting

- The **d07** monitor permits monitoring of the frequency after scale conversion. The line speed and speed of rotation can be displayed.

Displayed value = Output frequency \times **b86**

(Example) When the line speed is 6 m/min at 60 Hz
0.1 is set to **b86**.

(Display)

At 20 Hz: **20** (2 m/min)

At 40 Hz: **40** (4 m/min)

Explanation of Functions

Explanation of Functions

STOP key-meaning selection


[b87] STOP key meaning selection

- Even when operation command is set to external signal (control terminal), [STOP] the key on the operator is valid. It can be made invalid with this function.

Operation restart mode after free-run

[b88] Free-run operation mode setting

- The inverter operation after canceling the free-run command can be selected.



(Note) In "Frequency matching start," operation starts at motor coasting speed to reduce the chance of tripping. However, response is slower than "Restart from 0 Hz."

Setting the multifunctional input terminal

[c01] - [c06] Multifunctional input terminal function setting

- Functions are selected and assigned freely to input terminals, FR through RST. [c11] - [c16] permits selection of input signal polarity A-contact (NO) or B-contact (NC) for each terminal.
 - [c06] and [c16] are only for HF-320.
- <Selection function>


| Code | Function | Code | Function |
|------|-----------------------------|------|---|
| 00 | Forward command | 09 | No.2 acceleration/ deceleration command |
| 01 | Reverse command | 11 | Free-run command |
| 02 | Multi-stage speed 1 command | 12 | External trip |
| 03 | Multi-stage speed 2 command | 13 | USP function |
| 04 | Multi-stage speed 3 command | 15 | Software lock |
| 05 | Multi-stage speed 4 command | 16 | Analog current input selection |
| 06 | Jog operation command | 18 | Reset |
| 08* | B-mode selection | 27* | Frequency Up |
| | | 28* | Frequency Down |

*HF-320 only.

- Forward/reverse operation command

Use this when operating the inverter with an external contact signal. (control terminal)

It is valid when the operation command destination is "Terminal block."




- Multi-stage speed command (Refer to p.7.)
- Inching operation command (Refer to p.7.)
- No.2 acceleration/deceleration command

The No.2 acceleration/deceleration change method must be set to "terminal" by [a94]. (Refer to p.9.)


- Free-run stop command

The inverter output can be cut off during operation for free-run stop of the motor. It can be used on a motor with brake.



- External trip input

Use this to shut off inverter output with external contact signal to provide safety interlock with operating equipment.



(Note) External trip input is assigned to the inputs (FR through RST). When this function is activated, the inverter outputs a fault signal and cuts off output.

- USP (Unattended Start Prevention) function

The function can prevent resumption of operation when the power returns with operation command engaged. When this function is enabled and power is applied with run (operation) command issued to the control terminal, the drive trips and displays the trip code for "USP error."

- Software lock (Refer to p.10.)

- Analog current input selection

Analog input for frequency command can be switched between voltage (0-10VDC) and current (4-20mA) inputs. When using analog current input or analog voltage input, set the frequency command destination to "Terminal."

Explanation of Functions

| Input method | Terminal assignment | Terminal ON/OFF |
|-------------------|---------------------|-----------------|
| Current (4-20 mA) | Assigned | ON |
| Voltage (0-10 V) | | OFF |
| Current + Voltage | Not assigned | — |

(Note) When no terminal is assigned, the frequency equivalent to the current command value plus voltage command value is output.

- Reset
This digital input removes the trip condition from the drive and cancels the fault signal.
(Note) When this function is on during operation, the output is cut off.


Multifunctional input terminal contact setting

[C11] - [C16] Multifunctional input terminal contact setting

- The contact condition of each multifunctional input terminal can be independently set to A-contact (NO-normally open) or B-contact (NC-normally closed).
- [C16] is only for HF-320.

| Multifunctional input terminal | | Setting code |
|--------------------------------|--------|--------------|
| SF-320 | HF-320 | |
| FR | FR | [C11] |
| RR | RR | [C12] |
| 2DF | DFL | [C13] |
| 3DF | DFM | [C14] |
| RST | DFH | [C15] |
| | RST | [C16] |

A-contact (NO): ON (operation) when short-circuited
B-contact (NC): ON (operation) when opened



Setting the multifunctional output terminal

[C21], [C22] Multifunctional output terminal contact setting

[C41] Overload signal level setting

[C42] Frequency detect setting during acceleration


[C43] Frequency detect setting during deceleration

[C44] PID deviation level setting


- The functions of output terminals UPF and DRV are assigned freely by [C21] and [C22]. The output is an open collector type.

| Code | Function | Code | Function |
|------|-------------------------|------|----------------------|
| 00 | Run signal | 03 | Overload signal |
| 01 | Frequency match signal | 04 | PID deviation signal |
| 02 | Frequency detect signal | 05 | Alarm signal |

- [C31] and [C32] sets the output condition to either A-contact (NO-normally open) or B-contact (NC-normally closed).
- Run signal
Output when the inverter is operating.



- Frequency match signal and frequency detect signal
These functions for the multifunction output terminals enable output signals either when output frequency matches command frequency or when output frequency exceeds detect frequencies. The detect frequencies are assigned with [C42] and [C43] separately for acceleration and deceleration.



- Overload signal
When the output current exceeds the level set by [C41] the signal is output.
- PID deviation signal
A signal is output when the deviation of the target value and feedback value exceeds the value set by [C44] during PID control.
- Alarm signal
When a trip occurs, the multifunctional output terminal (open collector output) outputs a fault signal.

Selection of the monitor signal

[C23] Monitor signal selection

| Set value | Contents of monitor |
|-----------|--------------------------------------|
| 00 | Analog output and frequency monitor |
| 01 | Analog output and current monitor |
| 02 | Digital output and frequency monitor |

- The output monitor from the FRQ terminal is selected. In the case of a digital output frequency monitor, the scale is changed by the coefficient set by [B86]. (Refer to [B81] and [B86].)

Multifunctional output terminal and alarm terminal contact setting

[C31], [C32] Multifunctional output terminal contact setting

[C33] Alarm terminal contact setting

- The operation specification of the multifunctional output terminals UPF and DRV and alarm terminals AL0-AL2 can be selected from among A-contact and B-contact.

| Terminal | A-contact specification | B-contact specification |
|--------------------------------|--|---|
| Output (Transistor output) | (Initial setting) L level when ON H level when OFF | H level when ON L level when OFF |
| Alarm (Relay output) | (Initial setting) AL0-AL1 open when normal or power is cut off AL0-AL1 closed when alarm | AL0-AL1 closed when normal AL0-AL2 closed when alarm or power is cut off |


◆ Protective Functions

| Name | Description | Digital panel/ Digital operator | Remote operator ERR1**** | |
|------------------------------|--|------------------------------------|-----------------------------|----------|
| Overcurrent protection | When output of an inverter is short circuited, the motor is locked or drive sees sudden heavy load, the inverter output current exceeds a certain level, and the inverter output is cut off. | Constant speed | E01 | OC.Drive |
| | | Deceleration | E02 | OC.Decel |
| | | Acceleration | E03 | OC.Accel |
| | | Others | E04 | Over.c |
| Overload protection (Note 1) | When a motor overload is detected by the electronic thermal function, the output of the inverter is cut off. | E05 | Over.L | |
| Overvoltage protection | When the inverter DC bus voltage exceeds a certain level due to regenerative energy from the motor, this protection engages and the output of the inverter is cut off. | E07 | Over.V | |
| EEPROM error (Note 2) | When the built-in memory has problems due to noise or excessive temperature rise, this protection engages and the output of the inverter is cut off. | E08 | EEPROM | |
| Undervoltage protection | Output is cut off when the DC bus voltage goes down below a certain level. Low DC bus voltage of an inverter causes improper function of the control circuit, generates the motor heat and causes low torque. Trip level is approximately 150-160V for 200V Class and 300-320V for 400V Class. | E09 | Under.V | |
| CPU error | Malfunction or error of the built-in CPU causes this fault and shuts the inverter output off. | E11 E22 | CPU1 CPU2 | |
| External trip | A fault indication from external equipment signals an intelligent input terminal programmed for External Trip to cut off the output of the inverter. | E12 | EXTERNAL | |
| USP error | With USP function enabled through the intelligent terminal, a run command when power comes on causes this fault. | E13 | USP | |
| Ground fault protection | At power up, the inverter looks for ground fault at the motor output terminals. This protection is provided for the inverter and not for operator safety. | E14 | GND.Fit | |
| Input overvoltage protection | When the input voltage is higher than the specified value, inverter responds to this 100 seconds after power up by faulting and by cutting off the output. The detection level is approximately 258V for 200V Class and 516V for 400V Class. | E15 | OV.SRC | |
| Thermal protection | When thermal sensor in the inverter detects high temperature in the power module, the inverter trips and shuts output off. | E21 | OH.FIN | |
| Undervoltage wait condition | The drive shuts output and waits when input voltage drops below a specific value. | --U | UV.WAIT | |


(Note 1) Press the reset key 10 seconds after the alarm has occurred.

(Note 2) If an EEPROM error **E08** occurs, be sure to confirm the setting value again.

■ Trip Monitoring Method



■ Trip History Monitoring Method



(Note 3) Details of the latest error are displayed
 (Note 4) **--** is displayed when there is no error.

| Model | | 200 V class | | | | | | | 400 V class | | | | | | | |
|--------------------------------|--|---|--|------------|------------|------------|------------|------------|--|------------|------------|------------|------------|------------|------------|------------|
| | | SF3202-A20 | SF3202-A40 | SF3202-A75 | SF3202-1A5 | SF3202-2A2 | SF3202-3A7 | SF3202-5A5 | SF3202-7A5 | SF3204-A40 | SF3204-A75 | SF3204-1A5 | SF3204-2A2 | SF3204-3A7 | SF3204-5A5 | SF3204-7A5 |
| Applicable motor (kW) (Note 1) | | 0.2 | 0.4 | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 0.4 | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 |
| Output | Rated capacity (kVA) | 0.6 | 1.0 | 1.5 | 2.7 | 3.8 | 6.1 | 9.1 | 12.2 | 1.1 | 1.9 | 2.9 | 4.2 | 6.6 | 9.9 | 12.2 |
| | Rated output current | 1.6 | 2.6 | 4.0 | 7.1 | 10 | 15.9 | 24.0 | 32.0 | 1.5 | 2.5 | 3.8 | 5.5 | 8.6 | 13.0 | 16.0 |
| | Rated output voltage (Note 2) | 3-phase 200–230 V (corresponding to input voltage) | | | | | | | 3-phase 380–460 V (corresponding to input voltage) | | | | | | | |
| | Overload current rating | 150%, 60 seconds | | | | | | | | | | | | | | |
| Power | Rated input voltage | 3-phase: 200–230V±10% | | | | | | | 3-phase: 380–460V±10% | | | | | | | |
| | Frequency | 50/60Hz±5% | | | | | | | 50/60Hz±5% | | | | | | | |
| Control | Control method | Sinusoidal pulse width modulation (PWM) control | | | | | | | | | | | | | | |
| | Output frequency range (Note 3) | 0.5–360Hz | | | | | | | | | | | | | | |
| | Frequency accuracy | Digital command: ±0.01% of the Max. frequency, Analog command: ±0.1% (25°C±10°C) of the Max. frequency | | | | | | | | | | | | | | |
| | Frequency setting resolution | Digital: 0.01Hz, Analog: Max. frequency/1000 | | | | | | | | | | | | | | |
| | Carrier frequency | 0.5–16 kHz variable | | | | | | | | | | | | | | |
| | Volt./Freq. characteristic | V/f characteristic (Setting available for constant torque, reduced torque.) • V/f characteristics variable arbitrarily | | | | | | | | | | | | | | |
| | Acceleration/Deceleration time | 0.1–3000sec. linear acceleration/deceleration, second acceleration/deceleration setting available | | | | | | | | | | | | | | |
| | Dynamic braking (short time) (Note 4) | 40% | | | 30% | | 20% | | 40% | | | 30% | | 20% | | |
| | DC braking | Operating frequency, time, and braking force variable | | | | | | | | | | | | | | |
| Input signal | Frequency setting signal | Digital | Operation by operator key | | | | | | | | | | | | | |
| | | Analog | Operation by built-in potentiometer (Analog setting) | | | | | | | | | | | | | |
| | | External setting | DC0–10V • DC4–20mA (Note 5) | | | | | | | | | | | | | |
| | Operation signal | Operator panel | Run/Stop (Forward/Reverse change by function) | | | | | | | | | | | | | |
| External setting | | Forward run (A-contact), Reverse run available with terminal assignments (A- or B-contact selectable) | | | | | | | | | | | | | | |
| Intelligent input terminal | Forward run command, reverse run command, multi-stage speed setting, jogging command 2-stage acceleration/deceleration command, free run stop command, external trip, USP function, software lock, analog current input select signal, Reset | | | | | | | | | | | | | | | |
| Output signal | Intelligent output terminal | Run, frequency match/detect, overload, PID deviation, alarm | | | | | | | | | | | | | | |
| | Frequency monitor | Analog output frequency monitor, analog output current monitor or digital output frequency monitor. | | | | | | | | | | | | | | |
| | Alarm output contact | ON for the inverter alarm (IC contact output) (Possible to change to OFF for the alarm) | | | | | | | | | | | | | | |
| Other functions | | AVR function, upper/lower limiter, PID control, carrier frequency, jump frequency, electronic thermal level, gain/bias adjustment, retry function, automatic torque boost, trip monitoring etc. | | | | | | | | | | | | | | |
| Protective function | | Overcurrent, overvoltage, undervoltage, overload, high temperature, CPU error, EEPROM error, ground fault detection at startup, internal communication error etc. | | | | | | | | | | | | | | |
| Operating environment | Location | Indoor (Corrosion, toxicity, inflammable gas, dust, or oil mist not allowed.) | | | | | | | | | | | | | | |
| | Ambient temperature | -10–50°C (Note 6) | | | | | | | | | | | | | | |
| | Storage temperature | -10–60°C (Temperature in a short period of time during transportation) | | | | | | | | | | | | | | |
| | Ambient humidity | 90% RH or less | | | | | | | | | | | | | | |
| | Altitude | Altitude 1,000m or less | | | | | | | | | | | | | | |
| | Vibration | 0.6 G or less | | | | | | | | | | | | | | |
| Protective structure | | IP20 | | | | | | | | | | | | | | |
| Weight (kg) | | 0.8 | 0.85 | 0.9 | 1.7 | 1.8 | 2.8 | 5.5 | 5.7 | 1.3 | 1.7 | 1.7 | 1.7 | 2.8 | 5.5 | 5.7 |

(Note 1) The applicable motor refers to Sumitomo 3-phase standard motor and AF motor (4-pole).
To use other motors, care must be taken to prevent the rated motor current (50Hz) from exceeding the output current of the inverter.

(Note 2) The output voltage decreases as the main power supply voltage decreases. (Except when AVR function is active)

(Note 3) To operate the motor beyond 60Hz, consult the motor manufacturer about the maximum allowable rotation speed.

(Note 4) The value is the average deceleration torque based on energy absorption capacity for short deceleration cycle (stoppage from 60Hz). This does apply to continuous regenerative load.


(Note 5) The frequency command is the maximum frequency at 9.8V for input voltage 0–10 VDC, or at 19.6mA for input current 4–20mA.
If this characteristic is not convenient, contact your Sumitomo sales representative.

(Note 6) To use the inverter at 40°C or higher, it is necessary to reduce the output current rating and carrier frequency values.

Terminal Functions

Terminal Functions

[Main circuit terminals]



Main circuit terminals Front case (right open)

[Control circuit terminals]




Terminal section cover (left open) Control circuit terminals

| | Terminal screw diameter | Terminal width |
|---------------------------|-------------------------|----------------|
| Main circuit terminals | M4(M3.5) | 9(7.1) |
| Control circuit terminals | M2 (press-tight type) | — |
| Alarm terminal | M3 (press-tight type) | — |
| Ground | M4 | — |

() : SF3202-A20-A75

Main Circuit Terminals

| Symbol | Terminal name | Explanation |
|--------|-----------------------------------|---|
| R,S,T | Main power supply input terminals | Connect the input power supply |
| U,V,W | Inverter output terminals | Connect the motor |
| P,P1 | DC reactor connection terminals | Connect the DC reactor for harmonic suppression. Power factor improve (Remove the shorting bar when connecting a DC reactor.) |
| ⊕ | Ground connection terminal | Ground to prevent electric shock and reduce noise. |



Control Circuit Terminal


| Symbol | Terminal Name | Remarks |
|--------|--|--|
| FRQ | Monitor terminal (frequency, current, etc.) | PWM output |
| COM | Common terminal for monitor and frequency command | — |
| PCS | External DC power supply | DC24V, Max.30mA |
| RST | Intelligent input terminals: | Contact input |
| 3DF | Select from forward run command, reverse run command, multispeed commands, 2-stage acceleration / deceleration command, free run stop, external trip, jogging, analog input selection, software lock, reset. | |
| 2DF | | |
| RR | | |
| FR | | |
| FR | | |
| +V | Power supply for frequency command | DC10V |
| VRF | Frequency command input (voltage command) | DC0-10V (Variable by parameter) Input impedance 10kΩ |
| IRF | Frequency command input (current command) | DC4-20mA (Variable by parameter) Input impedance 250Ω |
| COM | Common terminal for frequency command | — |
| DRV | Intelligent output terminals: | Open collector output |
| UPF | Select from match run, overload, alarm, frequency match, and frequency detect. | L level at operation (ON) DC27V, Max.50mA |
| OM | | |
| AL2 | | |
| AL1 | Alarm output terminals (IC contact (relay) output) | Contact rating |
| AL0 | <p>(Initial setting) When normal, power OFF: AL0-AL2 Close When alarm: AL0-AL2 Open (Switchable to AL0-AL1 Close when normal.)</p> | AC250V 2.5A (resistive load) 0.2A (cos φ=0.4) DC30V 3.0A (resistive load) 0.7A (cos φ=0.4) (Min.) AC100V 10mA DC 5V 100mA |

(Note 1) The maximum frequency command is 9.8 V when the voltage input is 0-10 VDC, and 19.6 mA when the current input is 4-20 mA.

(Note 2) The reset terminal cannot be changed to [Operation with (SW) Open].

Basic Connection Diagram

<Basic connection diagram>



(Note 1) Do not start and stop the motor with only the MC switch.

⚠ (Note 2) Be sure to ground the inverter chassis and motor.
 (Note 3) The common of each terminals differ.

| Terminal | FR, RR, 2DF, 3DF, RST, FRQ | +V, VRF, IRF | UPF, DRV |
|----------|----------------------------|--------------|----------|
| Common | COM | COM | OM |


(Note 4) Refer to the figure at right for the power ON and Run command ON timing. Even if the main circuit power and operation command are turned ON simultaneously, the control power will not be turned ON for 2.0 seconds and not permit operation.

(Note 5) When the contactor is to be opened and closed for each operation, be sure to insert an ACL on the primary side of the contactor to reduce the inrush current.

(Note 6) When a DC reactor is used, remove the shorting bar between terminals P and P1.

(Note 7) Provide external thermal overload protection for each when operating frequency is below 30 Hz or when multiple motors are used.

[Turn on the main power at the timing shown below.]




Applied Connection Diagram

*Refer to p.24 for circuits using PID.

Applied Connection Diagram


Operation by current signal (4-20 mADC)

When terminal 2DF is used as a current/voltage signal (speed setting unit) changeover signal input



- (Note 1) Set parameter A02 to "01: Input to control circuit."
- (Note 2) Set parameter A01 to "01: Input to control circuit."
- (Note 3) Set parameter C03 to "16: Current input selection."
- (Note 4) Install a step-down transformer when the power is 400 V-class.
- (Note 5) Set parameters C33 to "00".

Multispeed operation (16-step speed)



Frequency setting by external signal

| Frequency setting | Multi-stage speed 1 | Multi-stage speed 2 | Multi-stage speed 3 | Multi-stage speed 4 |
|-------------------|---------------------|---------------------|---------------------|---------------------|
| A 20 | × | × | × | × |
| A 21 | ○ | × | × | × |
| A 22 | × | ○ | × | × |
| A 23 | ○ | ○ | × | × |
| A 24 | × | × | ○ | × |
| A 25 | ○ | × | ○ | × |
| A 26 | × | ○ | ○ | × |
| A 27 | ○ | ○ | ○ | × |
| A 28 | × | × | × | ○ |
| A 29 | ○ | × | × | ○ |
| A 30 | × | ○ | × | ○ |
| A 31 | ○ | ○ | × | ○ |
| A 32 | × | × | ○ | ○ |
| A 33 | ○ | × | ○ | ○ |
| A 34 | × | ○ | ○ | ○ |
| A 35 | ○ | ○ | ○ | ○ |

(×... Open, ○... Closed)

(Note) Install it when the operation frequency is less than 30 Hz.

| Model | | 200 V class | | | | | | | | 400 V class | | | | | | | | | |
|--------------------------------|--|--|--|------------|------------|------------|------------|------------|------------|--|------------|------------|------------|------------|------------|------------|-----|--|--|
| | | HF3202-A20 | HF3202-A40 | HF3202-A75 | HF3202-1A5 | HF3202-2A2 | HF3202-3A7 | HF3202-5A5 | HF3202-7A5 | HF3204-A40 | HF3204-A75 | HF3204-1A5 | HF3204-2A2 | HF3204-3A7 | HF3204-5A5 | HF3204-7A5 | | | |
| Applicable motor (kW) (Note 1) | | 0.2 | 0.4 | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 0.4 | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | | | |
| Output | Rated capacity (kVA) | 0.6 | 1.0 | 1.5 | 3.0 | 4.2 | 6.7 | 9.1 | 12.2 | 1.1 | 1.9 | 2.9 | 4.2 | 6.6 | 9.9 | 12.2 | | | |
| | Rated output current | 1.6 | 3.0 | 5.0 | 8.0 | 11 | 17.5 | 24.0 | 32.0 | 1.5 | 2.5 | 3.8 | 5.5 | 8.6 | 13.0 | 16.0 | | | |
| | Rated output voltage (Note 2) | 3-phase 200–230 V (corresponding to input voltage) | | | | | | | | 3-phase 380–460 V (corresponding to input voltage) | | | | | | | | | |
| | Overload current rating | 150%, 60 seconds | | | | | | | | | | | | | | | | | |
| Power | Rated input voltage | 3-phase: 200–230V±10% | | | | | | | | 3-phase: 380–460V±10% | | | | | | | | | |
| | Frequency | 50/60Hz±5% | | | | | | | | | | | | | | | | | |
| Control | Control method | Sensorless vector (V/F control) sinusoidal pulse width modulation PWM control | | | | | | | | | | | | | | | | | |
| | Output frequency range (Note 3) | 0.5–360Hz | | | | | | | | | | | | | | | | | |
| | Frequency accuracy | Digital command: ±0.01% of the Max. frequency, Analog command: ±0.1% (25°C±10°C) of the Max. frequency | | | | | | | | | | | | | | | | | |
| | Frequency setting resolution | Digital: 0.01Hz, Analog: Max. frequency/1000 | | | | | | | | | | | | | | | | | |
| | Carrier frequency | 0.5–16 kHz variable | | | | | | | | | | | | | | | | | |
| | Volt./Freq. characteristic | V/f characteristic (Setting available for constant torque, reduced torque.) • V/f characteristics variable arbitrarily | | | | | | | | | | | | | | | | | |
| | Acceleration/Deceleration time | 0.1–3000sec. linear acceleration/deceleration, second acceleration/deceleration setting available | | | | | | | | | | | | | | | | | |
| | Dynamic braking (short time) (Note 4) | 40% | | | 30% | | | 20% | | | 40% | | | 30% | | | 20% | | |
| | Dynamic control (succession) | Use an optional dynamic braking resistor. (Refer to pp.23 and 27.) | | | | | | | | | | | | | | | | | |
| | DC braking | Operating frequency, time, and braking force variable | | | | | | | | | | | | | | | | | |
| Input signal | Frequency setting signal | Digital | Operation by operator key | | | | | | | | | | | | | | | | |
| | | Analog | Operation by built-in potentiometer (Analog setting) | | | | | | | | | | | | | | | | |
| | | External setting | DC0–10V • DC4–20mA (Note 5) | | | | | | | | | | | | | | | | |
| | Operation signal | Operator panel | Run/Stop (Forward/Reverse change by function) | | | | | | | | | | | | | | | | |
| External setting | | Forward run (A-contact), Reverse run available with terminal assignments (A- or B-contact selectable) | | | | | | | | | | | | | | | | | |
| Intelligent input terminal | Forward run command, reverse run command, multi-stage speed setting, jogging command 2-stage acceleration/deceleration command, free run stop command, external trip, USP function, software lock, analog current input select signal, Reset | | | | | | | | | | | | | | | | | | |
| Output signal | Intelligent output terminal | Run, frequency match/detect, overload, PID deviation, alarm | | | | | | | | | | | | | | | | | |
| | Frequency monitor | Analog output frequency monitor, analog output current monitor or digital output frequency monitor. | | | | | | | | | | | | | | | | | |
| | Alarm output contact | ON for the inverter alarm (IC contact output) (Possible to change to OFF for the alarm) | | | | | | | | | | | | | | | | | |
| Other functions | | AVR function, S-curve acceleration/deceleration, upper and lower limiters, 16-stage speed, fine adjustment of start frequency, carrier frequency, jump frequency, gain and bias setting, jogging run, electronic thermal level adjustment, retry function, trip history monitor, 2nd setting selection, auto tuning. | | | | | | | | | | | | | | | | | |
| Protective function | | Overcurrent, overvoltage, undervoltage, overload, high temperature, CPU error, EEPROM error, ground fault detection at startup, internal communication error etc. | | | | | | | | | | | | | | | | | |
| Operating environment | Location | Indoor (Corrosion, toxicity, inflammable gas, dust, or oil mist not allowed.) | | | | | | | | | | | | | | | | | |
| | Ambient temperature | -10–50°C (Note 6) | | | | | | | | | | | | | | | | | |
| | Storage temperature | -10–60°C (Temperature in a short period of time during transportation) | | | | | | | | | | | | | | | | | |
| | Ambient humidity | 90% RH or less | | | | | | | | | | | | | | | | | |
| | Altitude | Altitude 1,000m or less | | | | | | | | | | | | | | | | | |
| | Vibration | 0.6 G or less | | | | | | | | | | | | | | | | | |
| Protective structure | | IP20 | | | | | | | | | | | | | | | | | |
| Weight (kg) | | 0.8 | 0.85 | 0.9 | 1.7 | 1.8 | 2.8 | 5.5 | 5.7 | 1.3 | 1.7 | 1.7 | 1.7 | 2.8 | 5.5 | 5.7 | | | |

(Note 1) The applicable motor refers to Sumitomo 3-phase standard motor and AF motor (4-pole).

To use other motors, care must be taken to prevent the rated motor current (50Hz) from exceeding the output current of the inverter.

(Note 2) The output voltage decreases as the main power supply voltage decreases. (Except when AVR function is active)

(Note 3) To operate the motor beyond 60Hz, consult the motor manufacturer about the maximum allowable rotation speed.

(Note 4) The value is the average deceleration torque based on energy absorption capacity for short deceleration cycle (stoppage from 60Hz). This does apply to continuous regenerative load.

(Note 5) The frequency command is the maximum frequency at 9.8V for input voltage 0–10 VDC, or at 19.6mA for input current 4–20mA.

If this characteristic is not convenient, your Sumitomo sales representative.

(Note 6) To use the inverter at 40°C or higher, it is necessary to reduce the output current rating and carrier frequency values.

Explosion-proof motor series with protection type "frameproof (d2G4)".

200V•400V class

NEW



Features

1. Control range: 1:20 wide-range control

2. Starting torque: 200% or more

3. Speed fluctuation: ±1% accuracy (Sensorless vector control operation)

Specifications

| kWXP | Motor frame No. | Specifications | | | | | | Scope of manufacture | |
|--------|-----------------|----------------|--|-----------------------|------------------------------|---------------|-----------------|----------------------|---|
| | | Insulation | Characteristics | Output base frequency | Protection type | | Starting torque | | Constant power range |
| | | | | | Indoor JP44 | Outdoor JPW44 | | | |
| 0.2X4 | T-71S | Class B | 1:20 Constant torque Continuous rating | Dedicated to 60 Hz | Totally-enclosed self-cooled | | 200% or more | -120Hz | 1. Available <ul style="list-style-type: none"> • Direct coupling with CYCLO • Outdoor • JEM flange • Foot mounted 2. Unavailable <ul style="list-style-type: none"> • With PG • With brake |
| 0.4X4 | T-80M | | | | Totally-enclosed fan-cooled | | | | |
| 0.75X4 | T-90L | | | | | | | | |
| 1.5X4 | T-100L | | | | | | | | |
| 2.2X4 | T-112M | | | | | | | | |
| 3.7X4 | T-132MS | | | | | | | | |
| | | | | | | -100Hz | | | |

200 V class 0.2 kW model alone is available.

⚠ The output base frequency is 60 Hz only. Any other base frequency setting may cause fire. Be sure to set the base frequency at 60 Hz.

⚠ The explosion-proof (d2G4) motor is used only with HF-320 Series, and it cannot be used with SF-320 Series. Set the inverter to "Sensorless vector control."

Option

Operator station specifications for Exd2

| Model No. | EGFCT3203 | | | |
|-------------------|--|-------------------------------------|--------------------------------|--------------------------|
| Ordering type | OS1-Exd2-□-□ | OS2-Exd2-□-□ | OS3-Exd2-□-□ | OS4-Exd2-□-□ |
| Frequency counter | Scale: 0-100% (Special scale is also available.) | | | |
| Volume | RA30YN-2W 1kΩ | | | |
| Pilot lamp | — | Power indication | Power indication | Power indication |
| Operation switch | ON-OFF selector switch | Reverse-Stop-Normal selector switch | Normal-Reverse selector switch | ON-OFF pushbutton switch |

(Products are made according to customer's specifications.)

Ordering type OS1-Exd2- 2 -□

- 1. Pilot lamp power: 24 VDC
- 2. Pilot lamp power: 100 VAC
- 3. Pilot lamp power: 200 VAC


Meter input specifications: 0-10 V.F.S.

Contact us when the wiring distance exceeds 30 m.

Terminal Functions

[Main circuit terminals]

[Control circuit terminals]



Main circuit terminals Front case (right open)




Terminal section cover (left open) Control circuit terminals

| | Terminal screw diameter | Terminal width |
|---------------------------|-------------------------|----------------|
| Main circuit terminals | M4(M3.5) | 9(7.1) |
| Control circuit terminals | M2 (press-tight type) | — |
| Alarm terminal | M3 (press-tight type) | — |
| Ground | M4 | — |

() : HF3202-A20-A75

Main Circuit Terminals

| Symbol | Terminal name | Explanation |
|---------------|--|--|
| R,S,T | Main power supply input terminals | Connect the input power supply |
| U,V,W | Inverter output terminals | Connect the motor |
| PR,P, P1,N | P-PR: Regenerative braking resistor (Note 1) P-P1: Short bar or DCL | Regenerative braking resistor terminals Connect the DC reactor for harmonic suppression. Power factor improvement |
| ⊕ | Ground | Ground to prevent electric shock and reduce noise. |



(Note 1) Contact our company when continuous regenerative operation is desired.

Control Circuit Terminal


| Symbol | Terminal Name | Remarks |
|----------|---|--|
| FRQ | Monitor terminal (frequency, current, etc.) | PWM output DC 10V 1mA |
| COM | Common terminal for monitor and frequency command | — |
| PCS | External DC power supply | DC24V, Max.30mA |
| RST | Intelligent input terminals: | Contact input Operation by SW Close. (Changeable to operation by SW Open.) (Note 2) Minimum ON time: 12 ms or more |
| DFM, DFH | Select from forward run command, reverse run command, | |
| DFL | multispeed commands, 2-stage acceleration/deceleration command, | |
| RR | free run stop, external trip, jogging, analog input selection, software | |
| FR | lock, reset, and initial setting. Un attended start prevention. | |
| +V | Power supply for frequency command | |
| VRF | Frequency command input (voltage command) | DC10V |
| IRF | Frequency command input (current command) | DC0-10V (Variable by parameter) Input impedance 10kΩ |
| COM | Common terminal for frequency command | DC4-20mA (Variable by parameter) Input impedance 250Ω |
| DRV | Intelligent output terminals: | Open collector output L level at operation (ON) DC27V, Max.50mA |
| UPF | Select from run, overload, alarm, frequency match, and set frequency | |
| OM | defect. | |
| AL2 | Alarm output terminals (IC contact (relay) output) | Contact rating AC250V 2.5A (resistive load) 0.2A (cos φ=0.4) DC30V 3.0A (resistive load) 0.7A (cos φ=0.4) (Min.) AC100V 10mA DC 5V 100mA |
| AL1 | (Initial setting) | |
| AL0 | When normal, power OFF: AL0-AL2 Close When alarm: AL0-AL2 Open (Switchable to AL0-AL1 Close when normal.) | |
| AL0 | | |

(Note 1) The maximum frequency command is 9.8 V when the voltage input is 0-10 VDC, and 19.6 mA when the current input is 4-20 mA.

(Note 2) The reset terminal cannot be changed to [Operation with (SW) Open].

Connection Diagram

Connection Diagram



(Note 1) Do not start and stop the motor with only the MC switch.
Refer to p.23 for the reference circuit for MC.

⚠ (Note 2) Be sure to ground the inverter chassis and motor.
(Note 3) The common of each terminals differ.


| Terminal | FR, RR, DFH, DFM, DFL, RST, FRQ | +V, VRF, IRF | UPF, DRV |
|----------|---------------------------------|--------------|----------|
| Common | COM | COM | OM |

(Note 4) Refer to the figure at right for the power ON and Run command ON timing. Even if the main circuit power and operation command are turned ON simultaneously, the control power will not be turned ON for 2.0 seconds and not permit operation.

(Note 5) When the contactor is to be opened and closed for each operation, be sure to insert an ACL on the primary side of the contactor to reduce the inrush current.

(Note 6) When a DC reactor is used, remove the shorting bar between terminals P and P1.


[Turn on the main power at the timing shown below.]



Applied Connection Diagram


Operation by current signal (4-20 mADC)

When terminal DFL is used as a current/voltage signal (speed setting unit) changeover signal input



- (Note 1) Set parameter A02 to "01: Input to control circuit."
- (Note 2) Set parameter A01 to "01: Input to control circuit."
- (Note 3) Set parameter C03 to "16: Current input selection."
- (Note 4) Install a step-down transformer when the power is 400 V-class.
- (Note 5) Set parameter C33 to "00".

Multispeed operation (16-step speed)





Frequency setting by external signal

| Frequency setting | Multi-stage speed 1 | Multi-stage speed 2 | Multi-stage speed 3 | Multi-stage speed 4 |
|-------------------|---------------------|---------------------|---------------------|---------------------|
| A 20 | × | × | × | × |
| A 21 | ○ | × | × | × |
| A 22 | × | ○ | × | × |
| A 23 | ○ | ○ | × | × |
| A 24 | × | × | ○ | × |
| A 25 | ○ | × | ○ | × |
| A 26 | × | ○ | ○ | × |
| A 27 | ○ | ○ | ○ | × |
| A 28 | × | × | × | ○ |
| A 29 | ○ | × | × | ○ |
| A 30 | × | ○ | × | ○ |
| A 31 | ○ | ○ | × | ○ |
| A 32 | × | × | ○ | ○ |
| A 33 | ○ | × | ○ | ○ |
| A 34 | × | ○ | ○ | ○ |
| A 35 | ○ | ○ | ○ | ○ |



(×... Open, ○... Closed)

Operation of motor with brake



- (Note 1) When using a DC reactor, remove the shorting bar between P and P1 and connect them.
- (Note 2) When the power supply is a 400 V class, install a step-down transformer.
- (Note 3) Set parameter C03 to 11.
- (Note 4) Set parameter C33 to 00.


Up-down operation for positioning



- (Note 1) Use inflammable cable for braking resistor wiring.
- (Note 2) Parameter A21 is for slow-speed frequency setting and A20 is for high-speed setting.
- (Note 3) When the power supply is a 400 V class, install a step-down transformer.
- (Note 4) Set parameter C21 to 02 and adjust the braking timing by C42 and C43. Parameters C42 and C43 should be set at approx. 2 Hz usually.
- (Note 5) Set parameter C03 to 11.
- (Note 6) Set parameter C33 to 00.

Reference Circuit

PID circuit



(Note 1) Command source parameters

| Purpose | Parameter No. | Set value |
|--|---------------|--------------------|
| Inputting target signal to VRF terminal. | A01 | 01 |
| Using FR terminal for normal rotation command. | A02 | 01 |
| PID control is set. | A71 | 01 |
| Feedback input destination: IRF terminal | A76 | 00 (Initial value) |

(Note 2) PID adjusting parameters

| Details of adjustment | Parameter No. |
|---|---------------|
| P (proportional) gain | A72 |
| I (integral) gain | A73 |
| D (differential) gain | A74 |
| Level matching of target value and feedback value | A75 |


(Note 3) Parameters setting for PID deviation signal

| Purpose | Parameter No. | Set value |
|--|---------------|-----------|
| DRV terminal function setting | C22 | 04 |
| PID deviation signal detection level setting | C44 | 0-100% |


Dimensional Drawings

Dimensional Drawings


SF3202-A20, A40, A75
HF3202-A20, A40, A75




SF3204-A40
HF3204-A40




SF3202-1A5, 2A2, SF3204-A75, 1A5, 2A2
HF3202-1A5, 2A2, HF3204-A75, 1A5, 2A2



SF3202-3A7, SF3204-3A7
HF3202-3A7, HF3204-3A7




SF3202-5A5, 7A5, SF3204-5A5, 7A5
HF3202-5A5, HF3204-5A5, 7A5



(Note) Overseas specification models have different dimensions. Contact our company for details.

Applicable Wiring for Accessories and Options



| Standard Accessories | | | | | |
|----------------------|----------------|---------------|---|---|-----------------------------------|
| Rated input voltage | Inverter model | | Circuit breaker (made by Mitsubishi Electric) | Electromagnetic contactor (made by Fuji Electric) | Cable size 20m (mm ²) |
| | SF-320 series | HF-320 series | | | |
| 200V | SF3202-A20 | HF3202-A20 | NF-30 5A | SC - 03 | 2 |
| | SF3202-A40 | HF3202-A40 | | | |
| | SF3202-A75 | HF3202-A75 | NF-30 10A | | |
| | SF3202-1A5 | HF3202-1A5 | NF-30 20A | SC - 1N | |
| | SF3202-2A2 | HF3202-2A2 | | | |
| | SF3202-3A7 | HF3202-3A7 | NF-30 30A | | |
| 400V | SF3202-5A5 | HF3202-5A5 | NF-50 50A | SC-2N (2SN) | 3.5 |
| | SF3202-7A5 | HF3202-7A5 | NF-100 60A | | 5.5 |
| | SF3204-A40 | HF3204-A40 | NF-30 5A | SC - 03 | 2 |
| | SF3204-A75 | HF3204-A75 | | | |
| | SF3204-1A5 | HF3204-1A5 | NF-30 10A | | |
| | SF3204-2A2 | HF3204-2A2 | NF-30 20A | SC - 1N | 3.5 |
| SF3204-3A7 | HF3204-3A7 | | | | |
| SF3204-5A5 | HF3204-5A5 | NF-30 30A | | | |
| SF3204-7A5 | HF3204-7A5 | | | | |

Notes: 1. The shown accessories are for use with SUMITOMO 3-phase, 4-pole motors.
 2. Select the circuit breaker based on required capacity.
 3. Use thicker cables when wiring distance exceeds 20 m.
 *The alarm output point should be 0.75 mm².

When using an earth leakage breaker (ELB), select the breaker's trip current from the table below based on the total wire distance (ℓ) by summing the distance from the breaker to the inverter and the inverter to the motor.

| ℓ | Trip current (mA) |
|--------------|-------------------|
| 100m or less | 30 |
| 300m or less | 100 |
| 600m or less | 200 |

Notes: 1. When CV wiring is used in metal conduit, the leakage current is approximately 30mA/km.
 2. Leakage current will increase eightfold with IV type cable due to higher dielectric constant. In this case, use ELB with the next higher trip rating.

| Name | Function |
|---|---|
| Input AC reactor for harmonic suppression/power smoothing/powerfactor improvement | This is useful in suppressing harmonics induced on the power supply lines, or when the main power voltage imbalance exceeds 3%, (and power source capacity is more than 500kVA), or to smooth out line fluctuations. It also improves the power factor. |
| Radio noise filter Zero-phase reactor | Electrical noise interference may occur on nearby equipment such as a radio receiver. This magnetic choke filter helps reduce radiated noise. |
| Input noise filter for inverter LC filter | This filter reduces the conducted noise in the power supply wiring between the inverter and the power distribution system. Connect it to the inverter primary (input side). |
| Input radio noise filter (XY filter) | This capacitive filter reduces radiated noise from the main power wires in the inverter input side. |
| DC reactor | The inductor or choke filter suppresses harmonics generated by the inverter. |
| Regenerative braking resistor HF-320 only | The regenerative braking resistor is useful for increasing the inverter's control torque for high duty-cycle (on-off) applications, and improving the decelerating capacity. |
| Output noise filter LC filter | This filter reduces radiated noise emitted on the inverter output cable that may interfere with radio or television reception and test equipment and sensor operation. |
| Radio noise filter Zero-phase reactor | Electrical noise interference may occur on nearby equipment such as a radio receiver. This magnetic choke filter helps reduce radiated noise. |
| Output AC reactor | Install it on the output side to reduce leakage current contributed by higher harmonics. Contact our company for details. |

(Note 1) SF-320 Series are not equipped with a PR terminal. Use HF-320 when regenerative braking is required.


Operation

Operation

Options for braking resistor HF-320

| Rated power (W) | Dimensions | | | | | | | | Weight (g) |
|-----------------|------------|----|----|----|----|-----|-----|---|------------|
| | F | G | H | J | K | L | M | N | |
| 200 | 28 | 26 | 22 | 6 | 53 | 287 | 306 | 4 | 340 |
| 300 | 44 | 40 | 40 | 10 | 78 | 309 | 335 | 5 | 840 |
| 400 | 44 | 40 | 40 | 10 | 78 | 385 | 411 | 5 | 1000 |
| 750 | 57 | 40 | 40 | 10 | 84 | 355 | 381 | 5 | 1360 |

100% braking torque: 10 sec 10% ED




| Voltage (V) | Capacity (kW) | Braking resistor | | | | Thermal relay set value (A) |
|-------------|---------------|------------------|-------------|-------------|-------------|-----------------------------|
| | | Part No. | Rated power | Resistance | Qty | |
| 200V | 0.2 | Y135AA201 | 200W | 400Ω | 1 | 0.83 |
| | 0.4 | Y135AA200 | 200W | 200Ω | 1 | 0.83 |
| | 0.75 | Y135AA205 | 300W | 200Ω | 1 | 1.25 |
| | 1.5 | Y135AA204 | 300W | 80Ω | 1 | 1.25 |
| | 2.2 | Y135AA208 | 400W | 70Ω | 1 | 1.7 |
| | 3.7 | Y135AA203 | 300W | 20Ω | 2-pc series | 2.1 |
| | 5.5 | X435AC069 | 750W | 10Ω | 2-pc series | 5.3 |
| 400V | 7.5 | X435AC069 | 750W | 10Ω | 2-pc series | 5.3 |
| | 0.4 | Y135AA202 | 200W | 750Ω | 1 | 0.42 |
| | 0.75 | Y135AA207 | 300W | 750Ω | 1 | 0.63 |
| | 1.5 | Y135AA206 | 300W | 400Ω | 1 | 0.63 |
| | 2.2 | Y135AA209 | 400W | 250Ω | 1 | 0.83 |
| | 3.7 | Y135AA204 | 300W | 80Ω | 2-pc series | 1.1 |
| | 5.5 | Y135AA209 | 400W | 250Ω | 3-pc series | 2.0 |
| 7.5 | Y135AA209 | 400W | 250Ω | 3-pc series | 2.0 | |

Type of thermal relay: TR-ONH

DC reactor for power factor improvement and higher harmonics control

A DC reactor is available for improvement of the power factor of the inverter, ensuring power line impedance, and control of higher harmonics.




(Note) Models below 200 V class 3.7 kW of SF-320 and HF-320 are subject to the "Guideline for the Suppression of Harmonics in Household and General-Use Equipment" issued by the Ministry of International Trade and Industry in September 1994. Therefore, it is necessary to install a reactor for inverters to be installed from January 1, 1997 onward to conform to the standards described in these guidelines.

| | Applicable capacity (kW) | Specification | | Part No. Y220DA | W | W1 | D | D1 | D2 | D3 | H | H1 | H2 | G | Connection terminal | Weight (kg) | Insulation |
|-------------|--------------------------|---------------|-------|-----------------|-----|----|----|----|----|-----|-----|-----|-------|-------|---------------------|-------------|------------|
| | | Current(A) | L(mH) | | | | | | | | | | | | | | |
| 200V Series | 0.2 | 1.0 | 29.7 | 032 | 52 | 35 | 40 | 32 | 20 | 22 | 65 | - | 300 | dia.4 | M4 | 0.3 | B |
| | 0.4 | 2.0 | 14.8 | 033 | 52 | 35 | 40 | 32 | 20 | 22 | 75 | - | 300 | dia.4 | M4 | 0.4 | B |
| | 0.75 | 3.75 | 9.72 | 034 | 52 | 35 | 50 | 42 | 25 | 27 | 85 | - | 300 | dia.4 | M4 | 0.6 | B |
| | 1.5 | 7.5 | 4.83 | 035 | 74 | 50 | 45 | 37 | - | - | 120 | 145 | - | dia.5 | M5 | 1.0 | B |
| | 2.2 | 11.0 | 3.41 | 036 | 74 | 50 | 45 | 37 | - | - | 120 | 145 | - | dia.5 | M5 | 1.1 | B |
| | 3.7 | 18.5 | 2.13 | 037 | 90 | 60 | 62 | 52 | - | - | 140 | 170 | - | dia.5 | M8 | 2.0 | B |
| | 5.5 | 28.0 | 1.47 | 038 | 90 | 60 | 62 | 52 | - | - | 140 | 170 | - | dia.5 | M5 | 2.4 | B |
| 400V Series | 7.5 | 38.0 | 1.11 | 039 | 100 | 80 | 95 | 80 | - | - | 140 | 170 | - | 5.5X7 | M5 | 3.5 | B |
| | 0.4 | 1.0 | 59.3 | 003 | 52 | 35 | 40 | 32 | 20 | 22 | 75 | - | 300 | dia.4 | M4 | 0.4 | B |
| | 0.75 | 1.88 | 38.9 | 004 | 52 | 35 | 50 | 42 | 25 | 27 | 85 | - | 300 | dia.4 | M4 | 0.6 | B |
| | 1.5 | 3.75 | 19.3 | 005 | 59 | 40 | 60 | 47 | 30 | 35 | 100 | - | 300 | dia.4 | M4 | 0.9 | B |
| | 2.2 | 5.5 | 13.7 | 006 | 74 | 50 | 45 | 37 | - | - | 120 | 140 | - | dia.5 | M5 | 1.1 | B |
| | 3.7 | 9.25 | 8.52 | 007 | 74 | 50 | 70 | 62 | - | - | 120 | 145 | - | dia.5 | M5 | 1.8 | B |
| | 5.5 | 14.0 | 5.87 | 008 | 90 | 60 | 62 | 52 | - | - | 140 | 165 | - | dia.5 | M5 | 1.5 | B |
| 7.5 | 19.0 | 4.46 | 009 | 100 | 80 | 95 | 80 | - | - | 140 | 165 | - | 5.5X7 | M5 | 3.5 | B | |

AC reactor for power factor improvement and higher harmonics control

An AC reactor is available for improvement of the power factor of the inverter, ensuring proper power line impedance, and control of higher harmonics.

* The AC reactor is for 3-phase input.



(Note) Models below 200 V class 3.7 kW of SF-320 and HF-320 are subject to the "Guideline for the Suppression of Harmonics in Household and General-Use Equipment" issued by the Ministry of International Trade and Industry in September 1994. Therefore, it is necessary to install a reactor for inverters to be installed from January 1, 1997 onward to conform to the standards described in these guidelines.

| | Applicable capacity (kW) | Specification | | Part No. Y220CA | W | D1 | D2 | H1 | H2 | A | B | G | L | T | Weight (kg) | Insulation |
|-------------|--------------------------|---------------|-------|-----------------|-----|----|----|-----|-----|----|----|---|-----|----|-------------|------------|
| | | Current(A) | L(mH) | | | | | | | | | | | | | |
| 200V Series | -0.4 | 2.1 | 5.8 | 053 | 90 | 35 | 30 | 100 | - | 50 | 38 | 4 | 300 | M4 | 1.0 | B |
| | 0.75 | 4.0 | 3.1 | 054 | 90 | 35 | 30 | 100 | - | 50 | 38 | 4 | 300 | M4 | 1.1 | B |
| | 1.5 | 8.0 | 1.6 | 055 | 90 | 40 | 35 | 100 | 120 | 55 | 48 | 4 | - | M4 | 1.6 | B |
| | 2.2 | 11 | 1.2 | 056 | 115 | 42 | 37 | 120 | 145 | 55 | 43 | 4 | - | M4 | 2.1 | B |
| | 3.7 | 17 | 0.7 | 057 | 115 | 42 | 37 | 120 | 145 | 55 | 43 | 4 | - | M5 | 2.4 | B |
| | 5.5 | 24 | 0.5 | 058 | 155 | 45 | 40 | 150 | 180 | 80 | 50 | 5 | - | M5 | 3.9 | F |
| | 7.5 | 33 | 0.4 | 059 | 155 | 45 | 40 | 150 | 185 | 80 | 50 | 5 | - | M6 | 4.4 | F |
| 400V Series | 0.4 | 1.2 | 22 | 080 | 90 | 35 | 30 | 100 | - | 50 | 38 | 4 | 300 | M4 | 1.0 | B |
| | 0.75 | 2.1 | 12 | 081 | 90 | 35 | 30 | 100 | - | 50 | 38 | 4 | 300 | M4 | 1.1 | B |
| | 1.5 | 4.0 | 6.5 | 082 | 90 | 40 | 35 | 100 | - | 55 | 48 | 4 | 300 | M4 | 1.7 | B |
| | 2.2 | 5.5 | 4.6 | 083 | 115 | 42 | 37 | 120 | - | 55 | 43 | 4 | 300 | M4 | 2.5 | B |
| | 3.7 | 9.0 | 2.9 | 084 | 115 | 42 | 37 | 120 | 145 | 55 | 43 | 4 | - | M4 | 2.8 | B |
| | 5.5 | 13 | 2.0 | 085 | 155 | 45 | 40 | 150 | 175 | 80 | 50 | 5 | - | M4 | 4.2 | B |
| | 7.5 | 17 | 1.5 | 086 | 155 | 45 | 40 | 150 | 175 | 80 | 50 | 5 | - | M5 | 4.4 | B |

Noise filter



1. Zero-phase reactor (inductive filter)

Common to 200 V and 400 V classes, as well as input and output sides

- 3.7 kW or less • 5.5 kW or more
- Part No. X480AC188 Part No. X480AC192
- Type RC5078 Type RC9129

Method of connection

- (1) It can be used on both input (power supply) side and output (motor) side of the inverter.
- (2) Wind the cables of the three phases respectively on the input or output side more than three times (4 turns) in the same direction. If cables are too thick to wind more than three times (4 turns), arrange two or more zero-phase reactors to reduce the number of winding turns.
- (3) Make the gap between the cable and the inside of the core as small as possible.



| | |
|---------------|------------------------|
| Winding turns | More than 3 times (4T) |
| Qty used | 1 pc |
| Winding | |




2. Capacitive filter

Common to all capacities
Common to 200 V and 400 V classes


- Part No. X480AC185
- Type 3XYHB-105104

Method of connection

- (1) Connect directly to the input (power) terminal of the inverter. Make the connection cable as short as possible.
- (2) Correctly ground the equipment. (Grounding resistance: 100Ω or less)
- (3) It cannot be used for the output (motor) side of the inverter.



Leakage current
200V: 3.9mA
400V: 7.8mA



Noise filter

Noise filter

3. LC filter



200V class

| Power supply | Applicable motor (kW) | Input side | | Output side | |
|--------------------|-----------------------|------------|-----------|-------------|-----------|
| | | Type | Part No. | Type | Part No. |
| 3-phase 200V class | 0.2-0.4 | NF3010A-VZ | X480AC289 | CC3005C-P | X480AC163 |
| | 0.75-1.5 | NF3020A-VZ | X480AC290 | CC3010C-P | X480AC164 |
| | 2.2 | | | CC3015C-P | X480AC165 |
| | 3.7 | | | CC3020C-P | X480AC166 |
| | 5.5 | NF3030A-VZ | X480AC291 | CC3030C-P | X480AC167 |
| 7.5 | NF3040A-VZ | X480AC292 | CC3045C-P | X480AC168 | |

400V class


| Power supply | Applicable motor (kW) | Input side | | Output side | |
|--------------------|-----------------------|------------|-----------|-------------|-----------|
| | | Type | Part No. | Type | Part No. |
| 3-phase 400V class | 0.4-1.5 | NF3010C-VZ | X480AC296 | CC3005C-P | X480AC163 |
| | 2.2-3.7 | NF3020C-VZ | X480AC297 | CC3010C-P | X480AC164 |
| | 5.5 | | | CC3015C-P | X480AC165 |
| | 7.5 | | | CC3020C-P | X480AC166 |

- Connect the input-side filter between the power supply and inverter input terminal, and the output-side filter between the inverter output terminal and motor. Make the connection cable as short as possible.
- Use grounding cable as thick as possible. Correctly ground the equipment.
- The input and output cables of the filter should be sufficiently separated.
- Do not connect the input-side filter to the inverter output (motor) side.



Input-side LC filter

| Model | Type | A | B | C | D | E | F | G | H | J | K | L |
|-----------|------------|-----|-----|-----|----|----|----|-----|-------|---------|----|---|
| X480AC289 | NF3010A-VZ | 128 | 118 | 108 | 63 | 43 | | | 4.5X6 | dia.4.5 | M4 | |
| X480AC290 | NF3020A-VZ | | | | | | 42 | 1.0 | | | | |
| X480AC291 | NF3030A-VZ | 145 | 135 | 125 | 70 | 50 | | | | | | |
| X480AC292 | NF3040A-VZ | 179 | 167 | 155 | 90 | 70 | 54 | 1.6 | | | M5 | |
| X480AC296 | NF3010C-VZ | 128 | 118 | 108 | 63 | 43 | 42 | 1.0 | | | M4 | |
| X480AC297 | NF3020C-VZ | | | | | | | | | | M4 | |



Output-side LC filter


| Output side | | Dimensions | | | | | | | | | | (Unit: mm) | |
|-------------|-----------|------------|-----|-----|-----|-----|-----|----|----|----|---------|------------|----------------|
| Type | Part No. | A | B | C | D | E | F | G | H | J | K | L | M |
| CC3005C-P | X480AC163 | 147 | 140 | 125 | 110 | 95 | 70 | 50 | 50 | 25 | dia.4.5 | M4 | R2.25 length 6 |
| CC3010C-P | X480AC164 | | | | | | | | | | | | |
| CC3015C-P | X480AC165 | | | | | | | | | | | | |
| CC3020C-P | X480AC166 | 167 | 160 | 145 | 130 | 110 | 80 | 60 | 70 | 35 | dia.5.5 | M5 | R2.75 length 7 |
| CC3030C-P | X480AC167 | 215 | 200 | 185 | 170 | 120 | 90 | 70 | 70 | 35 | dia.5.5 | M5 | R2.75 length 7 |
| CC3045C-P | X480AC168 | 255 | 230 | 215 | 200 | 140 | 110 | 80 | 80 | 40 | dia.6.5 | M6 | R3.25 length 8 |

Example of noise filter use

when AM radio picks up noise

1. When noise level is high

Take possible measures among the following in the order of ①-⑦. Each measure will improve noise reduction.




Corrective measures

- ① Lower the carrier frequency as much as possible. Up to approx. 10 kHz when low-noise operation is necessary.
- ② Install a zero-phase reactor on the output side of the inverter. (Type: RC9129)
- ③ Install an LC filter on the input side of the inverter. (□□□□-FS)
- ④ Connect the inverter and motor with a metal conduit or shielded cable.
- ⑤ Use 4-wire cable as a motor power line, and ground one of the wires.
- ⑥ Connect the inverter and power with a metal conduit or shielded cable.
- ⑦ Install a drive isolation or noise reduction transformer for the power supply.

□□□□ differs according to the inverter capacity and voltage.


Connection of ② zero-phase reactor and ③ LC filter



Note: Turn wires the same number of times for all phases of the zero-phase reactor. 3 times (4 T) or more. Increase the number of zero-phase reactor when the cable is too thick to wind correctly.

2. When noise level is low


Take possible measures among the following in the order of ①-⑥. Each measure will improve noise reduction.



Corrective measures

- ① Lower the carrier frequency as much as possible. Up to approx. 10 kHz when low-noise operation is necessary.
- ② Install a zero-phase reactor on the output side of the inverter. (Type: RC5078, RC9129)
- ③ Install a zero-phase reactor on the input side of the inverter. (Type: RC5078, RC9129)
- ④ Install a capacitive filter on the input side of the inverter. (Type: 3XYHB-105104)
- ⑤ Connect the inverter and motor with a metal conduit or shielded cable.
- ⑥ Use 4-wire cable as a motor power line, and ground one of the wires.


Connection of ②③ zero-phase reactor and ④ capacitive filter



Note: Turn wires the same number of times for all phases of the zero-phase reactor. 3 times (4 T) or more. Increase the number of zero-phase reactor when the cable is too thick to wind correctly.

Measures to take when proximity switch/photoelectric switch, etc. malfunction

Take possible measures among the following in the order of ①-⑫. Each measure will improve noise reduction.




Corrective measures

- ① Use twisted pair/shielded wire as a sensor signal line, and connect the shielded wire to common.
- ② Separate the inverter and power line from the sensor circuit as much as possible. (More than 10 cm desirable)
- ③ Remove the grounding wire when the power supply for the sensor is grounded.
- ④ Lower the carrier frequency as much as possible. Up to approx. 10 kHz when low-noise operation is necessary.
- ⑤ Install a zero-phase reactor on the output side of the inverter. (Type: RC5078, RC9129)
- ⑥ Install an LC filter on the input side of the inverter. (Type: □□□□-FS)
- ⑦ Install a capacitive filter on the input side of the inverter. (Type: 3XYHB-105104)
- ⑧ Use a metal conduit or shielded cable for power supply wiring.
- ⑨ Use 4-wire cable as a motor power line, and ground one of the wires.
- ⑩ Install a drive isolation or noise reduction transformer for the inverter power supply.

when low-noise operation is necessary.

- ① Ground the power supply for the sensor via a 0.01-0.1 →(630V 0.1μF)
- ⑫ Separate the inverter power supply from the sensor power supply system.

Connection of ⑤⑥ reactors and ⑦ capacitive filter




Note: Turn wires the same number of times for all phases of the zero-phase reactor. 3 times (4 T) or more. Increase the number of zero-phase reactors when the cable is too thick to wind correctly.

Peripheral equipment

Peripheral equipment


Frequency setting unit: VR-07 1k Ω , 2W

Unit VR07



% speed meter: DCF-12N[10V F.S.]

0-100%; 50divisions (X525AA048)



AC ammeter: ACF-12N

The CT directly detects the current of the secondary side of the inverter.




Table of combination of AC ammeter (ACF-12N) and current transformer

| Motor capacity (kW) | 200V class | | | | | 400V class | | | | |
|---------------------|------------|-------------------|----------------|------------------|---------------------------------|------------|-------------------|----------------|---------------|---------------------------------|
| | Part No. | Meter | | CT Type | Number of primary through holes | Part No. | Meter | | CT Type | Number of primary through holes |
| | | Rated current [A] | Max. scale [A] | | | | Rated current [A] | Max. scale [A] | | |
| 0.2 | X525AA078 | 3 | 3 | COMA-15 5/5A | - | - | - | - | - | - |
| 0.4 | X525AA079 | 5 | 5 | COMA-15 5/5A | - | X525AA078 | 3 | 3 | COMA-15 5/5A | - |
| 0.75 | X525AA080 | 5 | 10 | COMA-15 10/5A | - | X525AA079 | 5 | 5 | COMA-15 5/5A | - |
| 1.5 | X525AA081 | 5 | 15 | COMA-15 15/5A | - | X525AA080 | 5 | 10 | COMA-15 10/5A | - |
| 2.2 | X525AA082 | 5 | 20 | COMA-15 20/5A | - | X525AA080 | 5 | 10 | COMA-15 10/5A | - |
| 3.7 | X525AA083 | 5 | 30 | COMA-15 30/5A | - | X525AA081 | 5 | 15 | COMA-15 15/5A | - |
| 5.5 | X525AA042 | 5 | 50 | COMA-15-26 50/5A | 3 | X525AA082 | 5 | 20 | COMA-15 20/5A | - |
| 7.5 | X525AA042 | 5 | 50 | COMA-15-26 50/5A | 3 | X525AA083 | 5 | 30 | COMA-15 30/5A | - |

Construction of current transformer (CT) COMA-15 type: Totally molded current transformer with primary winding

COM-15-26 type: Totally molded current transformer, throughhole type



COM-15-30 type: Totally molded current transformer, throughhole type

Install the current transformer (CT) on the output side of the inverter.

■ Remote operator

SF-320•HF-320 common option

Example connection




Caution in selecting peripheral equipment


| | | |
|-----------------------------------|---------------------------|--|
| Wiring and connection | | <p>(1) Be sure to connect the power supply to RST (input terminals) and the motor to U, V, W (output terminals).</p> <p>(2) Be sure to connect the grounding terminal. (⊖ mark) Inverters generate high frequency, increasing leakage current. Be sure to ground the inverter and motor.</p> |
| Wiring between inverter and motor | Electromagnetic contactor | When using an electromagnetic contactor between the inverter and motor, do not turn the contactor ON or OFF during inverter operation. |
| | Thermal relay | <p>Install a thermal relay that matches the motor in the following cases:</p> <ul style="list-style-type: none"> * Install a thermal relay for each motor when operating more than one motor with one inverter. * Set the current of the thermal relay at the rated motor current x 1.1. When the wiring length is long (more than 10 m), the thermal relay may be activated too quickly. Install an AC reactor or current sensor on the output side. * When motors are to be operated with the rated current exceeding the adjustable level of the built-in electronic thermal relay. <p>〈SF-320〉</p> <ul style="list-style-type: none"> * When operation continues at frequencies beyond the 30-60 Hz range. |
| Earth leakage breaker | | Install an earth leakage breaker on the input side for protection of the inverter wiring and operators. Conventional earth leakage breakers may malfunction because of high harmonics from the inverter; therefore use an earth leakage breaker that is applicable to the inverter. The leakage current differs according to the cable length. Refer to p.26. |
| Wiring distance | | <p>The wiring distance between the inverter and operation panel should be less than 20 m. If it exceeds 20 m, use a current/voltage converter, etc. Use shielded cable for wiring.</p> <p>When the wiring distance between the motor and inverter is long, the leakage current from high harmonics may cause the protective function of the inverter and peripheral equipment to be activated. The situation will be improved by an AC reactor installed on the output side of the inverter.</p> <p>Select appropriate cable to prevent voltage drop. (Large voltage drop lowers the torque.)</p> |
| Phase-advanced capacitor | | <p>Do not use a phase-advanced capacitor.</p> <p>When a power factor improving capacitor is connected between the inverter and motor, the capacitor may be heated or broken by the higher harmonics in the inverter output.</p> |

◆ Notes to inverter users

Continuous operation torque characteristics



HF-320 Output torque characteristics when general-purpose motors are operated under sensorless vector control



- Combination ... The output torque is 100% when the motor rating is 60 Hz.
Use an AF motor when constant torque is necessary for motors 5.5 kW or more.

Motor temperature rise

When a general-purpose motor is used in variable-speed operation with an inverter, the temperature rise of the motor will be slightly greater than in cases where commercial power is used. The causes are shown below:

Influence of output waveform Unlike commercial power, the output waveform of an inverter is not a perfect sine wave, and contains higher harmonics. Therefore, the motor loss increases and the temperature is slightly higher.

Reduction in the motor cooling effect during slow-speed operation ... Motors are cooled by the fan on the motor itself. When the motor speed is reduced by an inverter, the cooling effect will decrease.

Therefore, lower the load torque or use an inverter motor to control temperature rise when the frequency is below the frequency of commercial power.

Life of major parts

The electrolytic capacitor, cooling fan, and other parts used for inverters are consumables. Their life substantially depends on the operating condition of inverters. When replacement is necessary, contact our dealer or service center.

◆ Warranty

1. Warranty policy on inverter

| | |
|--------------------|--|
| Warranty period | The warranty shall be 18 months from date of shipment or 12 months after initial operation, whichever is shorter. |
| Warranty condition | <p>In the event that any problem or damage to the Product arises during the "Warranty Period" from defects in the Product whenever the Product is properly installed and combined with the Buyer's equipment or machines maintained as specified in the maintenance manual, and properly operated under the conditions described in the catalog or as otherwise agreed upon in writing between the Seller and the Buyer or its customers; the Seller will provide, at its sole discretion, appropriate repair or replacement of the Product without charge at a designated facility, except as stipulated in the "Warranty Exclusions" as described below.</p> <p>However, if the Product is installed or integrated into the Buyer's equipment or machines, the Seller shall not reimburse the cost of: removal or re-installation of the Product or other incidental costs related thereto, any lost opportunity, any profit loss or other incidental or consequential losses or damages incurred by the Buyer or its customers.</p> |
| Warranty exclusion | <p>Notwithstanding the above warranty, the warranty as set forth herein shall not apply to any problem or damage to the Product that is caused by:</p> <ol style="list-style-type: none"> 1. Installation, connection, combination or integration of the Product in or to the other equipment or machine that rendered by any person or entity other than the Seller; 2. Insufficient maintenance or improper operation by the Buyer or its customers such that the Product is not maintained in accordance with the maintenance manual provided or designated by the Seller; 3. Improper use or operation of the Product by the Buyer or its customers that is not informed to the Seller, including, without limitation, the Buyer's or its customers' operation of the Product not in conformity with the specifications; 4. Any problem or damage on any equipment or machine to which the Product is installed, connected or combined or any specifications particular to the Buyer or its customers; 5. Any changes, modifications, improvements or alterations to the Product or those functions that are rendered on the Product by any person or entity other than the Seller; 6. Any parts in the Product that are supplied or designated by the Buyer or its customers; 7. Earthquake, fire, flood, salt air, gas, lightning, acts of God or any other reasons beyond the control of the Seller; 8. Normal wear and tear, or deterioration of the Product's parts, such as the cooling fan bearings; 9. Any other troubles, problems or damage to the Product that are not attributable to the Seller. |
| Others | The Seller will not be responsibility for the installation and removal of the inverter. Any inverter transportation cost shall be born by both Seller and Buyer. |

2. Warranty policy on repaired and returned products

| | |
|--------------------|--|
| Warranty period | The warranty shall be 6 months from date of repair and shipment. |
| Warranty condition | Warranty on repaired Product will apply only on the replacement parts used in the repair done or authorized by the Seller. All other aspects conform to the Warranty Conditions described in item 1. |
| Warranty exclusion | Please refer to Warranty Exclusions described in item 1. |
| Others | Please refer to Others described in item 1. |

SAFETY PRECAUTIONS

- Before use, be sure to read the Instruction Manual thoroughly to insure proper use of the inverter.
- Note that the inverter requires electrical wiring; a specialist should carry out the wiring.
- The inverter in this catalog is designed for general industrial applications. For special applications in fields such as aircraft, aerospace, nuclear power, electrical power, transportation, medical equipment, and submarine relay equipment, please consult with us in advance.
- For application in a facility where human safety is involved or serious losses may occur, make sure to provide adequate safety devices to avoid a serious accident.
- The inverter is intended for use with a three-phase AC motor. For use with a load other than this, please consult with us.

Worldwide Sumitomo Network

U.S.A

Sumitomo Machinery Corporation of America
4200 Holland Blvd.,
Chesapeake, VA 23323
Tel : (1)757-485-3355
Fax: (1)757-487-3193

Canada

SM-Cyclo of Canada, Ltd.
870A Equestrian Court Oakville,
Ontario, Canada L6L 6L7
Tel : (1)905-469-1050
Fax: (1)905-469-1055

Mexico

SM-Cyclo De Mexico, S.A. de C.V.
Calle "C" No. 506A Parque Industrial
Almacentro Apodaca, N. L., Mexico 66600
Tel : (52)8-369-3697
Fax: (52)8-369-3699

Brazil

SM-Cyclo Redutores Do Brasil Ltda.
Av. Dr. Ulysses Guimarães,
3533, 09990-080 Diadema, São Paulo, Brazil
Tel : (55)11-4071-4388
Fax: (55)11-4071-2922

Chile

SM-Cyclo De Chile, Ltda.
Avenida Zanartu #1231, Comuna Nunoa,
Casilla No.22 Santiago 60, Chile
Tel : (56)2-237-2407
Fax: (56)2-237-0225

Argentina

SM-Cyclo De Argentina S.A.
Montes de Oca #6719, (B1606BMG)
Munro, Buenos Aires, Argentina
Tel : (54)11-4765-5332
Fax: (54)11-4765-5517

United Kingdom

Sumitomo (SHI) Cyclo Drive Europe, Ltd.
Marfleet Kingston Upon Hull HU9 5RA,
United Kingdom
Tel : (44)1482-788022
Fax: (44)1482-713205

SM-Cyclo U.K. Ltd.
Marfleet Kingston Upon Hull HU9 5RA,
United Kingdom
Tel : (44)1482-790340
Fax: (44)1482-790321

France

SM-Cyclo France E.U.R.L.
65/75 Avenue Jean Mermoz
F-93120 La Courneuve France
Tel : (33)149-929494
Fax: (33)149-929490

Italy

SM-Cyclo Italy S.r.l.
Via dell' Artigianato 23 20010
Cornaredo (Mi)
Tel : (39)02-9356-2121
Fax: (39)02-9356-9893

Netherlands

SM-Cyclo Benelux BV
Den Engelsman 16D NL-6026 RB
Maarheeze The Netherlands
Tel : (31)495599777
Fax: (31)495593177

Sweden

SM-Cyclo Scandinavia AB
Företagsvägen 30A S-232 37
Arlöv Sweden
Tel : (46)40430220
Fax: (46)40431001

Spain

SM-Cyclo Iberia, S.L.
Pol.Ind.C/En Proyecto no.29, Parc.66,
Nave B 46470 Catarroja (Valencia) Spain
Tel : (34)9-6-1264461
Fax: (34)9-6-1265602

Switzerland

SM-Cyclo Switzerland AG
Lerzenstrasse 27 CH8953 Dietikon
Tel : (41)56-6-33 0441
Fax: (41)56-6-33 0442

Belgium

SMBE Branch Belgium Office
Gentsesteenweg 1387
B-1082 Brüssel
Tel : (32)2-469-0517
Fax: (32)2-469-0207

South Africa

SM-Cyclo of South Africa Proprietary Ltd.
P. O. Box 2808, Edenvale 1610
78 Watt Street, Meadowdale
Germiston 1401
Tel : (27)11-974-3145
Fax: (27)11-974-2530

Germany

Sumitomo (SHI) Cyclo Drive Germany, GmbH
Cyclostraße 92
D-85229 Markt Indersdorf
Tel : (49)8136-66-0
Fax: (49)8136-5771

SCG Branch Hannover Office
Auf dem Kessel Lande 4 30900 Wedemark
Tel : (49)5130-7922-71
Fax: (49)5130-7922-79

Austria

SCG Branch Austria Office
Weinheberstraße 9 A-4020 Linz
Tel & Fax: (43)732-330766

China

Sumitomo (SHI) Cyclo Drive China, Ltd.
No. 7 Sanjijing Road Dongli Economic
Development Zone, Tianjin
Tel : (86)22-2499-3501
Fax: (86)22-2499-3133

Hong Kong

SM-Cyclo of Hong Kong Co., Ltd.
Rm 708, Kowloon Plaza, 485
Castle Peak Road, Kowloon, Hong Kong
Tel: (852)2460-1881
Fax: (852)2460-1882

Singapore

Sumitomo (SHI) Cyclo Drive
Asia Pacific Pte., Ltd.
No.36 Tuas South Street 3,
Singapore 638031
Tel : (65)863-2238
Fax: (65)863-4238

Malaysia

SM-Cyclo of Malaysia Sdn. Bhd.
No.2, Jalan TP 7/5,
Sime-up Industrial Park, 40400 Shah Alam,
Selangor Malaysia
Tel : (60)3-5128909
Fax: (60)3-5128809

Thailand

SM-Cyclo of Thailand Co., Ltd.
195, Empire Tower
Unit 1504, 15th Floor
South Sathorn Road, Yannawa Sathorn
Bangkok 10120, Thailand
Tel : (66)2-670-0998
Fax: (66)2-670-0999

Australia

SM-Cyclo of Australia Pty., Ltd.
13 Centre Place, Wetherill Park,
NSW 2164
Tel : (61)2-9756-2455
Fax: (61)2-9756-2002

Philippine

SCA Branch Philippines Office
Unit 504, Amberland Plaza
Condominium, Julia Vargas Ave.,
Ortigas Center Metro Manila
Tel: (63)2-637-2106
Fax: (63)2-632-7372

Taiwan

Tatung SM-Cyclo Co., Ltd.
22 Chungshan N. Road.,
3rd Sec. Taipei,
Taiwan, 104 R.O.C.
Tel : (886)2-2595-7275
Fax: (886)2-2595-5594

Korea

SM-Cyclo of Korea Co., Ltd.
Royal Bldg. 9F. Rm. 913
5 Danju-dong Chongro-ku Seoul 110
Tel : (82)2-730-0151
Fax: (82)2-730-0156

POWER TRANSMISSION & CONTROLS GROUP

 **Sumitomo Heavy Industries, Ltd.**

5-9-11, KITA-SHINAGAWA SHINAGAWA-KU, TOKYO 141-8686, JAPAN
PHONE: (03)5488-8363 FAX: (03)5488-8355
TELEX: J24580 SUMIJUKA

Specifications, dimensions and other items in the catalog are subject to change without notice.

D1001E-1.0 2002.6 Printed in Japan

Distributed By: