

---

# XTRAVERT

## XTRAVERT SERIES TECHNICAL MANUAL

**PDL ELECTRONICS LTD**  
*Leaders in AC Motor Control*



## DEDICATION TO QUALITY

AC Motor Control Products can dramatically improve your process control, productivity and energy efficiency, but only if they are working correctly.

Which is why we at PDL Electronics go to great lengths in our design and manufacturing, to ensure that our products operate correctly first time, every time.

An extensive research and development investment ensures that this product is one of the most technically advanced in the world, with built-in strength and robustness to suit your application and environment.

Our NZS(ISO) 9001 certification gives you the confidence of our international, independently certified Quality Assurance program. All staff are actively involved in continuous improvement programs with a customer focus.

The components that go into our products are selected from the best in the world - and must pass our rigorous and demanding test program.

Finally, every new drive design is run through a rigorous test program, including full load operation at above rated temperature, under the most demanding load conditions.

Our dedication to quality makes the PDL Electronics product, regardless of price, less expensive than other controllers in the long run. *Extract from 4700-001*

## COMPREHENSIVE SUPPORT PROGRAM

The PDL Electronics customer support program demonstrates our confidence in our Quality Assurance system. We have total faith in our products and their reliability, and so provide a comprehensive warranty.

Fully trained engineers and technicians, with a wealth of experience and easy access to information, can assist in solving any of your drive application projects.

Our service staff are available for commissioning, after sales service, and repairs, 24 hours a day, seven days a week.

We select capable and highly qualified representatives to act as our distributors and service agents. Only after passing PDL Electronics' intensive training program are they accredited for repair or on-selling of our products.

To further support our products and customers, we run a series of comprehensive training programs focusing on self maintenance and application advice. These are available on-site and at our Head Office.

## REVISION HISTORY

DATE:	REVISION:	DESCRIPTION:
28/07/97	D	Update specifications
25/098/97	E	Add P Screens & Update Screens A4,N5,Z2, X8 for revision 2.0 software

---

## Contents

<b>XTRAVERT SPECIFICATIONS</b>	<b>4</b>
<b>THE XTRAVERT</b>	<b>7</b>
<b>SECTION 1: INSTALLING THE XTRAVERT</b>	<b>9</b>
1.1 APPLICATION RECOMMENDATIONS	9
1.2 INSTALLATION	10
1.2.1 Environmental Considerations	10
1.2.2 Mounting the Xtravert	11
1.2.3 Connecting the Xtravert	12
1.3 CONTROL INPUT/OUTPUT FUNCTIONAL DESCRIPTION AND SPECIFICATION	13
1.4 THE DISPLAY UNIT	16
1.4.1 The LED Indicators	16
1.4.2 Use of the Display Unit	17
1.5 COMMISSIONING THE XTRAVERT	17
1.6 SERVICE	19
1.7 ELECTROMAGNETIC COMPATIBILITY (EMC) AND SAFETY	19
1.7.1 Control Cables	19
1.7.2 Power Cables	19
<b>SECTION 2: CONFIGURING THE XTRAVERT</b>	<b>21</b>
2.1 INTRODUCTION TO THE FULL FEATURES OF THE XTRAVERT	21
The Status Line	23
Screen Group A Auxiliary Screens	25
Screen Group C Comparator Screens	26
Screen Group F Fault Screens	27
Screen Group H Host Communication Screens	30
Screen Group I Input Screens	31
Screen Group L Limit Screens	38
Screen Group M Multi-reference Screens	41
Screen Group N Motor Nameplate Screens	42
Screen Group O Output Screens	43
Screen Group P Process Control Screens	47
Screen Group R Rate Screens	49
Screen Group S Start/Stop Screens	52
Screen Group X Xtravert Tuning Screens	56
Screen Group Y Menu Option Screens	60
Screen Group Z Commissioning Screens	61
<b>SECTION 3: COMMISSIONING CONFIGURATION RECORD</b>	<b>63</b>
<b>SECTION 4: USING THE XTRAVERT FOR PROCESS CONTROL</b>	<b>66</b>
<b>SECTION 5: APPLICATION EXAMPLE – SIMPLE FAN SPEED CONTROL</b>	<b>70</b>
<b>INDEX</b>	<b>73</b>

Xtravert is a registered trademark of PDL Electronics Ltd.

## XTRAVERT SPECIFICATIONS

MODEL	INPUT VOLTS (V)	INPUT CURRENT (A)	RECOMMENDED INPUT FUSE (A)	OUTPUT CURRENT @ 50°C (A)	OVERLOAD CURRENT (A)	NOMINAL MOTOR SIZE	
						(kW)	(hp)
X302	230 1~	8	15	2.5	3.75	230V	230V
X304	230 1~	12	20	4	6	0.37	¾
X307	230 1~	20	35	7	10.5	0.75	1
X309	230 1~	22	35	9	13.5	1.5	2
						2.2	3
						230V	230V
X502	230 3~	4	10	2.5	3.75	0.37	¾
X504	230 3~	7	15	4	6	0.75	1½
X507	230 3~	12	20	7	10.5	1.5	2
X509	230 3~	9	15	9	13.5	2.2	3
X512	230 3~	12	20	12	18	3	3
X516	230 3~	16	30	16	24	4	5
						400V	460V
X702	400 3~	4	10	2.5	3.75	0.75	1½
X704	400 3~	7	15	4	6	1.5	2
X707	400 3~	12	20	7	10.5	3	5
X709	400 3~	9	15	9	13.5	4	5
X712	400 3~	12	20	12	18	5.5	7½
X716	400 3~	16	30	16	24	7.5	10

Note 1: Nominal motor size applies to 4-pole motors only. Check your motor specification before selecting.

4202-186 Rev E

### INPUT

Input supply range	Nominal	Actual
	230V 1~	200V to 250V ±0%
	230V 3~	200V to 250V ±0%
	400V 3~	200V to 480V ±0%
Configuration	Earthed neutral supply	
Input frequency range	48–62 Hz	
Input displacement factor	0.99	
Power loss ride through	> 1 second at nominal voltage	

### OUTPUT

Current overload capability	150% for 30 seconds
Efficiency (full load, 50Hz)	>97%
Power on delay	<1 sec
Suit motor rated voltages	10-500Vac
Suit motor rated frequencies	10–175 Hz
Output voltage	<V <sub>in</sub>
Voltage regulation	<±3%
Frequency range	0 to ±120Hz
Frequency resolution	0.01Hz
Control method	Dynamic Flux Control
Carrier frequency	8kHz (5kHz selectable)

### ENVIRONMENTAL

Protection standard	IP20; Pollution degree 2
---------------------	--------------------------

---

Operating temperature	0–50°C
Storage temperature	-40°C to +80°C
Relative humidity	<90%, noncondensing
Altitude	1000m
Altitude derating (>1000m)	-1% per 100m; 3000m max

### **XTRAVERT PROTECTION**

Supply loss	Input phase loss
Output current limit	Short circuited load
Ground fault detection	Regeneration limit
Low DC bus voltage	Motor overtemperature
Excessive DC bus voltage	Control PCB failure
Xtravert thermal model	

### **MOTOR PROTECTION**

Stall avoidance	Stall protection
Shear pin mode	Combined overload alarm
Thermal model overtemperature trip	Motor overtemperature

### **LOCAL CONTROL OPTIONS**

Selection:

Start and Stop-Reset buttons	Stop-Reset button
Reset button	None (remote)

### **FREQUENCY CONTROL SOURCES**

Local Keyboard	Inch 1, Inch 2
Analogue Input 1; Configurable as 0-10Vdc or $\pm 10$ Vdc	
Analogue Input 2; 4-20mA	
Maximum of Analogue Input 1 or Analogue Input 2	
Sum of Analogue Input 1 and Analogue Input 2	
Switch Control (7 preset)	Switch Control (3 preset)
Motorised Potentiometer	PID Process Control output
RS232/RS485 (Options)	

### **SWITCH CONTROLS**

1 x Dedicated external trip input, 4 x Multifunction inputs configurable as:	
Stop	Start
Start-Reset	Stop-Reset
Inch	Alternative Stop-Reset
Direction Invert	Feedback Enable
Alternative Accel/Decel	

### **CONFIGURABLE RELAY OUTPUTS**

2 relays; 230Vac/30Vdc/2A (non-inductive)  
1 x changeover; 1x normally open

#### **Output selection:**

Failsafe fault	Xtravert started
Xtravert running	Xtravert started or running

Xtravert overloaded	Motor overloaded
Frequency sense point	Current sense point
Direction	At set frequency
Combined overload alarm	Feedback sense
Power flow direction	
RS232/RS485 controlled (Options)	

### **ANALOGUE OUTPUT CONFIGURABLE AS 0-10VDC, $\pm$ 10VDC, OR 4-20mA**

#### **Output selection:**

$\pm 50/\pm 60/\pm 100/\pm 120$ Hz Output frequency	0–150% Output current
$\pm 50/\pm 60/\pm 100/\pm 120$ Hz Reference frequency	$\pm 10$ V RS232/RS485 (Options)
0–500Vac Output voltage	0–150% Motor power
0–150% Torque component of current	

### **CONTROL PANEL**

32 Character alphanumeric LCD (may be mounted up to 3m away) with IP54 protection.  
 Xtravert status, current, frequency permanently displayed  
 Estimated motor temperature, reference frequency, DC bus voltage, output voltage optionally displayed  
 Multi-language capability  
 Direct status/level display of input and output control terminals  
 3 key input system with separate Start and Stop-Reset buttons.  
 Local/Remote control possible  
 LED status indication for Power On, Run and Fault

### **CONTROL FEATURES**

Wide speed range up to 120Hz	7 switch selectable speed presets
Switch controlled speed inputs	Two skip frequencies
Programmable to suit almost any motor	Programmable thermal model of motor
Dynaflux optimising system	Anti-condensation motor heater
Spinning start mode	Spinning stop mode
DC injection braking	PID process controller
Configurable switch controls	Programmable reaction to mains loss
Automatic restart	Smooth current limit
Shearpin mode	Showering arc noise immunity tested
Serial communication options	Reverse lock out
Very low motor noise – WhisperWave or Fixed frequency (normal) modulation	
Programmable offset, gain and inversion of analogue reference signals	
Two sets of acceleration and deceleration rates plus alternative stop rate	
Wide acceleration and deceleration range – 0.02Hz/s to 500Hz/s	
Programmable S-curve acceleration/deceleration	

---

## THE XTRAVERT

The Xtravert is a fourth generation AC Motor Speed Controller developed by PDL Electronics Ltd. The 16 models in the range are designed to operate smaller three-phase induction motors, rated up to 7.5kW at 400Vac.

- ◆ Models are available for single-phase 230Vac, three-phase 230Vac, or three-phase 400Vac supplies. A wide tolerance in supply voltage and frequency is allowed for.
- ◆ A compact bookshelf style enclosure has been designed for this range, with IP20 ingress protection rating. This offers the advantage of reduced installation space, allowing for easy installation either in a switchboard or stand-alone.
- ◆ The Xtravert is fully compliant with appropriate European Safety and EMC directives and as such carries the CE Mark.
- ◆ Optimal thermal design and management enable construction of a compact enclosure, and allow the full output rating to be achieved in ambient temperatures up to 50°C.
- ◆ Surface mount technology on the circuit boards allows for sophisticated yet compact circuit design.
- ◆ The power electronics design uses the latest generation IGBT switching devices. These permit a high overload capacity (150% for 30 seconds minimum), and protection against output short circuits. Their high switching speed enables modulation up to 8kHz for low output harmonic currents and near silent motor operation.
- ◆ The Control PC Board uses an extremely powerful 16-bit microcontroller and waveform enhancement ASIC to generate the output waveform using space vector modulation techniques. The microcontroller also allows PDL Electronics to include many programmable features into the Xtravert yet retain simplicity of control.
- ◆ WhisperWave Modulation is incorporated in the waveform generation. This is a technique developed by PDL Electronics to remove the annoying motor tone usually associated with motors operating from AC Motor Speed Controllers, allowing the little remaining motor noise to be easily masked. This feature is especially valuable in applications requiring low noise – particularly for heating and ventilation applications.
- ◆ The output waveform may be controlled by the PDL Dynaflux Optimising System. Dynaflux is a form of automatic voltage regulation that optimises the flux within the motor according to load conditions. This leads to increased motor efficiency, particularly under reduced load conditions.
- ◆ Digital control means absolute precision and repeatability in settings with complete keyboard control. There are no internal adjustments or trim pots in the Xtravert. All information, including input terminal status and levels, is available on the Xtravert display.
- ◆ The Display Unit is normally mounted on the front of the Xtravert. However it can be removed, re-orientated, or mounted remotely up to three metres away. It can be fitted to an industry standard 56-series box to achieve an IP54 ingress protection rating.
- ◆ The Display Unit includes three status LEDs, a 32-character alphanumeric LCD, three screen control keys and START, STOP-RESET push-buttons. The functions of the push-buttons may be disabled by the user.

- ◆ Plug-in control terminals allow for speedy change-over of drives in the event of a need for service or relocation of the Xtravert.
- ◆ Digital (switch) inputs include four programmable inputs and one dedicated TRIP input. The functions of the programmable inputs can be selected from a list of fourteen different options, including stop, start, reset, direction invert, alternative reference selection, alternative ramp rate selection, inch, and multi-speed selection.
- ◆ Two analogue inputs are provided. One is configurable as 0 to 10Vdc, or -10V to +10Vdc. The other is designed for 4 to 20mA control signal. Either input can be configured as a reference source or a process controller feedback source.
- ◆ Two relay outputs are provided, each rated at 230Vac/30Vdc/2A. One relay has change-over contacts, the other is normally open. Each may be configured to perform one of seventeen different functions, including indication of start, run, overload and direction status, frequency and current sensing.
- ◆ One analogue output is provided, which may have its format configured to 0 to 10V, -10V to +10V, or 4 to 20mA. The function of the analogue output can be selected from a list of fifteen, including output current, voltage, frequency.
- ◆ An internal PID Process Controller is provided, to enable applications such as level control, constant pressure pumping etc., to be set up without the need for an external controller.
- ◆ A Serial Communications Card may be fitted in place of the display unit, to enable extensive control and monitoring of the Xtravert from a host controller, e.g., computer, PLC, DCS, etc. Message format is industry standard MODBUS. Signal format can be either RS485 or RS232, or Serial Bus Interface format to communicate with industry standard PLCs.
- ◆ A stand alone dynamic brake unit is available to dissipate regenerative energy from motors that are required to decelerate quickly.

The Xtravert with its long list of desirable features and flexibility is an outstanding choice for the broad industrial market.

---

## SECTION 1: INSTALLING THE XTRAVERT

### 1.1 APPLICATION RECOMMENDATIONS

The Xtravert is suitable for controlling the speed of all standard three phase induction motors. Choose an Xtravert which is capable of supplying the full load current and voltage of the motor to be driven and is suitable for the mains supply voltage.

When the Xtravert is correctly adjusted, full torque can be obtained from the motor at up to rated speed. A standard motor may be operated above rated speed by using higher than rated frequency, but the torque that is able to be generated declines ( $1/f$ ) as there is insufficient voltage to provide correct stator flux.

Operation below rated speed must take account of the reduced cooling efficiency of the motor. Because of thermal limitations, the continuous capability of the motor reduces from rated torque at rated speed, to the value defined by the “zero speed cooling value” at zero speed. The Xtravert thermal model (overload) takes these factors into account and provides safe protection from inadvertent overloads of this type.

The quality of the Xtravert current waveform is such that no derating of the motor torque due to harmonic heating is necessary.

In a safety situation motors may be switched on and off the Xtravert while it is running but this is not good control practice – it stresses the Xtravert and may lead to occasional tripping due to arcing of the isolating device's contact terminals. A more elegant control solution is to use the Xtravert control terminals.

Generally it is better practice to leave electronic equipment (including the Xtravert) permanently connected to the mains supply. Switching the mains on and off to control the Xtravert is bad practice and should be avoided (use the control terminals). If mains switching is insisted upon (!), it must not occur more often than once every 5 minutes or the Xtravert charging circuits may be damaged.

Several motors may be operated at once on the Xtravert, but individual thermal protection must be supplied. Be sure to choose an Xtravert which is capable of supplying the total current requirements of all of the motors. If you plan to start motors independently “direct-on-Xtravert” then you must also include the DOL starting current of the motors (this generally leads to gross oversizing of the Xtravert – a much better solution is to stop the Xtravert, connect the extra motors, and restart the Xtravert).

An advantage of the Xtravert is that non-standard motors (frequency, voltage) can be driven from standard mains. The Xtravert may be set to drive any motor with a rated voltage between 10 and 500Vac with a rated frequency between 10 and 175Hz.

When selecting the gearing of your system, be sure to operate the motor as near to rated speed as possible. Centring your speed range around rated speed (so that maximum speed actually overspeeds your motor) gives better motor cooling and utilisation.

#### OTHER USEFUL TECHNIQUES INCLUDE:

- The use of a six pole motor in a four pole application (Xtravert operates around 75Hz instead of 50Hz) – this gives better motor cooling (hence a wider useful speed range) and 50% better starting torque at very little extra motor cost.

- Small motors may often be connected in 230V (delta) connection. Using this connection with a 400V Xtravert (motor voltage set to 230V) on a 400V supply allows the motor to be operated with full flux up to 87Hz, thus providing a very wide constant torque speed range. Note that the motor in fact produces 1.7 times its rated power when operated at 87Hz. The penalty is that the motor draws 1.7 times more current (because of the delta connection), so a larger Xtravert may be required.

Other recommendations:

- Regardless of how good a thermal overload or model is, a PTC thermistor in the motor windings with the appropriate control relay provides the ultimate thermal protection and is recommended.
- Always specify motors with high temperature insulation – at least class F or better.

## 1.2 INSTALLATION

### 1.2.1 ENVIRONMENTAL CONSIDERATIONS

The Xtravert must be sited in a suitable environment. As with all equipment, the cleaner, cooler and more vibration free the environment, the longer and more trouble free will be the life of the Xtravert.

The ambient temperature must not be below 0°C, and must not exceed the Xtravert specification of 50°C; relative humidity should be less than 90% and there must be no condensation. Avoid mounting the Xtravert in direct sunlight.

The Xtravert has a protection rating of IP20 and must have a clean environment (Pollution degree 2), free of electrically conductive (wet or dry) dust (e.g., carbon fibre, salt, etc.), and free of spraying water.

In some applications it may be desirable to improve the conditions in which the Xtravert is to be fitted. The first choice in this case is to fit the Xtravert remotely in a clean location.

If mounting the Xtravert in a switchboard or protective box be sure to allow for sufficient cooling. The enclosure interior air temperature must not exceed the Xtravert specification of 50°C. Calculate the correct airflow by using the formula below.

Estimate the average load power of the Xtravert :

$P_{av}(kW)$  = estimated average motor load

Knowing this power figure choose :

EITHER- a fully enclosed metal cabinet with an exposed surface area and given inside/outside temperature.

$$\text{Exposed surface area (sq. m.)} = \frac{7.5 \times P_{av}(kW)}{(\text{inside temp.} - \text{outside temp.})}$$

OR - if the cabinet is too large, air flow cooling will be required. Calculate the appropriate flow of air.

$$\text{Airflow (cu.m / sec)} = \frac{P_{av} (kW)}{50 \times (\text{outlet air temp.} - \text{inlet air temp})}$$

A suitable convection or forced air system must be provided to ensure the inside air temperature does not exceed 50°C.

Note: The Xtravert display unit has a protection rating of IP54 (front and sides only) when mounted correctly against a hard flat surface. This allows the display unit to be fitted on the front of a protective cabinet or switchboard. When remotely mounting the display unit, the protective screw caps must be fitted to maintain the IP54 rating.

### 1.2.2 MOUNTING THE XTRAVERT

The Xtravert must be mounted vertically to ensure proper cooling. Do not mount Xtraverts closer than 150mm centre to centre spacing or the localised maximum ambient air temperature may exceed specifications of 50°C. Avoid mounting Xtraverts immediately above other units.




Figure 1.1: Xtravert Dimensions




Figure 1.2: Remote Dimensions & Cutout Pattern

### 1.2.3 CONNECTING THE XTRAVERT




Figure 1.3: Xtravert Power Connections

1. Wiring Details: Refer to specifications for fuse ratings.
2. Power factor capacitors are not required on the Xtravert input (Xtravert displacement factor = 0.99), and must not be connected to the Xtravert output.
3. A motor isolator or contactor may be used on the Xtravert output, but its use should be restricted to emergencies.
4. To reduce radio frequency interference (RFI), screened cable (e.g., neutral screen, steel conduit) must be used on the Xtravert output. Bond the screen solidly to the Xtravert and motor chassis. The output cables should be run separate from the input cables (especially if not screened).
5. The Xtravert protects the motor with an electronic overload, so an external overload relay is unnecessary. Where multiple motors are attached, separate overload protection should be applied to each motor. The Xtravert or the motor must be isolated before operating on the motor terminals.

6. The Xtravert output switching voltage waveform can give rise to high (capacitive) earth leakage currents. Permanent earth connection of both the motor and the Xtravert is essential before connection to the supply.
7. The control input circuit is configurable from the keyboard. Be sure that you are using the correct configuration and circuit before wiring up. Good control circuit wiring practice should be observed. Control wiring must be screened and run physically separate from power wiring (at least 300mm distance and crossing only at right angles).
8. The control terminal strip is constructed of cage clamp terminals.  
Recommendations for control terminal wiring connections:  
Recommended tightening torque: 0.5Nm  
Maximum tightening torque: 1.0Nm  
Maximum cable size: 1.5mm<sup>2</sup> appliance wire  
Maximum number of cables/terminal: 2

### 1.3 CONTROL INPUT/OUTPUT FUNCTIONAL DESCRIPTION AND SPECIFICATION

Fig. 1.4 provides the complete electrical specification of all Xtravert control inputs and outputs and includes diagrammatic descriptions. Each input is individually described below.

#### TERMINALS D1–D3 — DISPLAY UNIT

The display unit may be mounted remotely (maximum distance 3m) by an extension lead of 3 core plus shield cable. Connect the shield (and drain wire) to 0V (Terminal D3).

#### TERMINALS T1–T5 — CONFIGURABLE RELAY OUTPUTS

Two voltage free 250Vac (30Vdc) 2A (non-inductive) rated relay outputs are provided for process interfacing. Each relay may be programmed (Screens O3 and O4) to switch according to one of several possible output controls.

One changeover contact pair and one normally open contact are provided.

#### TERMINALS T6–T9 — CONFIGURABLE (MULTI-FUNCTION) DIGITAL INPUTS

The switch (digital) input control lines of the Xtravert may be configured to provide many alternative functions. Refer to the detailed description of Screen I9 for a full description of the inputs and their alternative configurations. The level status of each of these inputs may be directly examined by viewing Screen Z6 at any time. Supply for control of active high inputs may be sourced from Terminal T11 or alternatively an external 24Vdc supply. Do not exceed 24Vdc on these terminals.

#### TERMINAL T10 — EXTERNAL TRIP INPUT (XTRIP)

If an external trip feature is not required, this input must be closed (linked to +24V). Provides a dedicated input to trip the Xtravert and immediately disables the output. Do not exceed 24Vdc on this input.

#### TERMINAL T11 — +24V SUPPLY

Supply that may used for the Multi-function digital inputs (Terminals T6–T9) and the External Trip input (Terminal T10).

**TERMINALS T12, T15, T17 — 0V CONNECTIONS**

For safety reasons the Xtravert control PCB should be linked to earth at some point in a control system. When supplied the control PCB common point (0V) is connected to earth via a link from Terminal T12. Where control wiring is run to external control equipment (or other Xtraverts) there should be only one earth connection for the complete control system (to prevent earth loops). If necessary, remove this earth link.

**TERMINAL T13 — +10V SUPPLY**

Voltage reference signal for (1 kOhm) potentiometer control.

**TERMINAL T14 — ANALOGUE INPUT 1 (AIN1)**

Voltage control input for reference frequency adjustment or as a feedback source. It may be used for voltage control or as potentiometer input source. The input signal level may be observed on Screen Z3.

**TERMINAL T16 — ANALOGUE INPUT 2 (AIN2)**

Current loop control input for reference frequency adjustment or as a feedback source. Note that the current return (-connection) is common with the control PCB circuit 0V connection. The input signal level may be observed on Screen Z4.

**TERMINAL T18 — CONFIGURABLE ANALOGUE OUTPUT**

An analogue output which may be configured (Screen O1) to represent several different internal signals. Suitable for driving industrial voltmeters or further process controls. The format is selectable from 0-10V,  $\pm 10V$  or 4-20mA via Screen O2. The output signal level may be observed on Screen Z5.




Figure 1.4: The Xtravert Control Inputs and Outputs

## 1.4 THE DISPLAY UNIT




Figure 1.5: The Display Unit

### 1.4.1 THE LED INDICATORS

The LED indicators are a useful service tool once their exact function is understood.

#### LED

Functional Indication

Actual indication

Implication

#### LED

Functional Indication

Actual indication

Implication

#### LED

Functional Indication

Actual indication

Implication

#### LED

Functional Indication

Actual indication

Implication

#### ON

Mains power is supplied or stored charge is present.

Display Unit is functioning.

Control PCB receives power from supply.

#### RUN

Xtravert is running.

Output devices enabled.

Xtravert is functional.

#### OK

Xtravert is operating normally.

Drive ready to operate.

No fault is present.

#### OK (Flashing)

Fault trip.

Output disable.

A fault (Screen F) has tripped the Xtravert.

---

## 1.4.2 USE OF THE DISPLAY UNIT

### THE LCD DISPLAY

The Xtravert has a 16 character by two line LCD display. The lines each have different functions:

- The STATUS LINE is always present and shows the Xtravert status, the output current and the output frequency.
- The CONTROL LINE display is used to view and/or adjust the many parameters of the Xtravert.

### USE OF THE CONTROL KEYS

The control keys are used to view and/or adjust the parameters of the Xtravert.

### SCREEN SELECTION

- Use “+” and “-” to examine the displays.

Note: Only the bottom line changes.

### CHANGING A VALUE

- Use “+” and “-” to locate the desired screen.
- Press and hold “\*” to allow adjustment to the value.
- Now use “+” and “-” to adjust the value.
- Release “\*” to enter new value.

Hint: For reasons of security the Xtravert must be in commission mode (Screen Z) before some adjustments can be made.

## 1.5 COMMISSIONING THE XTRAVERT

Before attempting commissioning, be sure you understand the operation of the Xtravert and have read this manual. Plan and define your wiring, controls and adjustments beforehand.

### CHECK INSTALLATION:

Check that the Xtravert will not be subject to an unacceptable environment. Check that adequate airflow is available. For reliable operation, the operating ambient temperature must not exceed 50°C.

### CHECK WIRING:

Check all wiring thoroughly according to the circuits (refer fig. 1.3 and 1.4). Check that all supply and motor cabling is correctly dimensioned for the application, the Xtravert is bonded to earth and electrical connections are secure. The cable connecting the Xtravert to the motor should be of screened construction with the screen (forming an earth connection) solidly bonded to the motor and the Xtravert chassis. Local regulations may require a separate protective earth between the Xtravert and the motor. Be particularly careful that power and motor wiring is not transposed or otherwise incorrect (else irreversible damage will occur). Control wiring must be screened and run separately from power cables.

Note that the Xtravert does not have internal power fuses. Check that the correct fuses (refer Specifications) are fitted at the supply.

Ensure that power and control cabling are securely fastened by the cable clamp on the Xtravert. Extra holes are provided on the Xtravert cable clamp for using cable ties.

Note that the External Trip input (Terminal T10) must be closed before the Xtravert will start. Check control wiring conforms to the configuration selected.

#### **TEST WITHOUT MOTOR:**

Before proceeding, ISOLATE THE MOTOR. Switch the mains supply on to the Xtravert.

#### **CHECK XTRAVERT OPERATION:**

Check that the Xtravert operates normally and displays the status and control lines. Familiarise yourself with the keyboard displays.

If any faults are indicated at any time, refer to Screen F — Fault Messages.

#### **SELECT SCREEN Z6:**

Check the status and operation of all inputs.

**WARNING: – THE XTRAVERT WILL STILL RESPOND TO THE INPUTS WHILE DISPLAYING SCREEN Z6.**

#### **SET THE ADJUSTMENTS:**

Referring to Screen Groups A to Z, set all relevant Xtravert and motor parameters.

#### **TEST RUN WITH MOTOR:**

Stop the Xtravert if it is running.

#### **WARNING:**

**CHECK THAT ALL PERSONNEL ARE CLEAR  
OF THE MOTOR AND ATTACHED MACHINERY  
AND THAT IT IS SAFE TO OPERATE THE MACHINE.**

#### **REMOVE THE MOTOR ISOLATION:**

Set a low reference speed and start the Xtravert. Check immediately for correct direction of rotation (if incorrect, stop the Xtravert, isolate it and allow to discharge before reversing two motor phase wires). Use the Xtravert adjustments to achieve the desired operation of the Xtravert.

#### **START AND RUN THE XTRAVERT:**

Check that the Xtravert correctly responds to all control inputs without the motor drawing excessive current. Remember to measure motor current (Xtravert display), not the mains current.

#### **TEST RUN:**

Operate the Xtravert and drive system, making control adjustments as necessary.

For maximum reliability of operation, try to ensure your setting up does not cause the Xtravert to rely on its protective override features (ILT - current limit; VLT - voltage limit). These should be regarded as back-up features, not to be used to overcome inadequate set up. If ILT is displayed, your acceleration rate is probably too high or your boost setting is too low or too high. If VLT is displayed, your deceleration rate is probably too fast. Reduce the deceleration rate or fit a dynamic brake unit.

Once satisfactorily commissioned, be sure to record all settings on the Commissioning Configuration Record provided for this purpose in Section 3. This makes life a lot easier if unauthorised adjustment occurs or if Xtravert replacement is necessary.

---

## 1.6 SERVICE

Faults in the Xtravert will fall into one of three major categories:

- Incorrect settings, set-up or adjustment resulting in unsatisfactory performance.
- Protective fault operation with resulting display message.
- Electrical failure within the Xtravert.

If the Xtravert powered up and running, but has performance problems; try re-tuning the Xtravert from scratch (refer Screen Y2). If this fails to give satisfactory results, finer tuning may be required using Screen Group X.

In the event of a protective fault trip occurring (refer Screen F), attempt to remove the cause of the trip and then reset the Xtravert.

In the event of electrical failure within the Xtravert, do not attempt to repair the unit. Seek service from a qualified service agent or replace the unit. For processes critical to the operation of a plant; retain a spare unit. If the Xtravert will not power up; check supply fuses or circuit breakers (load side) for the appropriate voltage. If the motor does not appear to be running; check for a motor side isolator or contactor.

## 1.7 ELECTROMAGNETIC COMPATIBILITY (EMC) AND SAFETY

### 1.7.1 CONTROL CABLES

Screened control cables must be used for the Xtravert to comply with EMC regulations. The screen should be connected to 0V on the control board (irrespective of whether the control board is earthed or floating) as an RF return. Avoid using long twisted leads (pigtailed) for the screen connection as this twisting increases the RF impedance (reducing the effectiveness of the screen). Control wiring screens should only be connected at one point in the control circuit to avoid earth loops.

For safety reasons, the control wiring 0V should be connected to earth at one point in the system. The Xtravert is supplied with an earth link from Terminal T12 (0V) to earth. This may be removed if required (e.g., control wiring is earthed by other control circuitry) allowing the control board 0V to float up to 50Vdc (clamped) from earth. This prevents earth loops in the control wiring. An example of where this is useful is where multiple drives are controlled using the same 4-20mA current source connected in series. Remove the earth link to prevent shorting out analogue input 2 (AIN2).

Avoid running control cables in parallel with power cables with a spacing less than 300mm. For longer runs (greater than 10m), increase this spacing in proportion to the length of the run. Cross control cables at right angles to power cables to avoid magnetically induced interference.

### 1.7.2 POWER CABLES

Screened output power cables must be used for the Xtravert to comply with EMC regulations. Connect the screen at both the drive and motor ends to provide an RF return path. This prevents the motor frame becoming an RF source, coupling into the local metalwork and the earthing system. Connect all earths (input, output and cabinet) together at one star point.

Local regulations may require that a separate earth be run to the motor for safety requirements. It is recommended that four core cable plus screen be used in these applications.

The Xtravert has been designed with input and output power filters to minimise radio frequency interference. The input common mode filter prevents conducted RF emission to the mains supply. The output filters on each phase reduce conducted RF emission to the motor by reducing  $dv/dt$  on the motor cables. Screened motor cables prevent any remaining noise from being radiated to the environment. Generally, it is better to keep motor cables as short as possible to reduce capacitive charging currents due to cable capacitance and limit the peak voltage at the motor terminals.

Due to the use of an input common mode filter and RFI capacitors to earth, earth leakage current will be present.

If unscreened motor cables are used, EMC regulations may not be complied with.

# EC Declaration of Conformity

Manufacturer: PDL Electronics Ltd.  
81 Austin Street, Napier, New Zealand

Authorised Representative: PDL Elektronik Vertrieb Deutschland GmbH  
Industriestraße 13A, D-90592, Schwarzenbruck, Deutschland

Details of Equipment: Xtravert

Model Number(s): X302, X304, X307, X309  
X502, X504, X507, X509, X512, X516  
X702, X704, X707, X709, X712, X716

Description: AC motor controller

Directives this equipment complies with: LVD 73/23/EEC, EMC 89/336/EEC

Standards applied in order to verify compliance with directives:

**BS EN61010-1:1993.**

*Safety requirements for electrical equipment for measurement, control, and laboratory use, part 1: General requirements.*

*Sicherheitsbestimmungen für elektrische Meß-, Steuer-, Regel- und Laborgeräte - Allgemeine Anforderungen.*

**BS EN61800-3:1996.**

*Adjustable speed electrical power drive systems, part 3: EMC product standard including specific test methods. Drehzahlveränderbare elektrische Antriebe - EMV - Produktnorm einschließlich spezieller Prüfverfahren.*

**BS EN55011:1991.**

*Limits and methods of measurement of radio disturbance characteristics of industrial, scientific and medical (ISM) radio-frequency equipment. Grenzwerte und Meßverfahren für Funkstörungen von industriellen, wissenschaftlichen und medizinischen Hochfrequenzgeräten (ISM - Geräten).*

**BS EN61000-4-2:1995.**

*Electrostatic discharge immunity. Prüfung der Störfestigkeit gegen die Entladung statischer Elektrizität.*

**BS EN61000-4-3:1995.**


*Radiated, radio-frequency, electromagnetic field immunity. Prüfung der Störfestigkeit gegen hochfrequente elektromagnetische Felder.*

**BS EN61000-4-4:1995.**

*Electrical fast transient/burst immunity. Prüfung und Störfestigkeit gegen schnelle transiente elektrische Störgrößen/Burst.*

Year of affixing CE mark: 1997

Authorised Signatory: Manufacturer



Name: Ian Hickey

Title: Research & Development

Manager

Date of Issue: 2<sup>nd</sup> December 1997

Place of Issue: Napier, New Zealand

EU Authorised Representative



Günter Gassner

Market Development

Manager

0460-902 Rev C

---

## SECTION 2: CONFIGURING THE XTRAVERT

### 2.1 INTRODUCTION TO THE FULL FEATURES OF THE XTRAVERT

When shipped from the factory the Xtravert is configured for local control.

Local control is just one selection setting of a large variety available in the Xtravert.

The process flexibility of the Xtravert only becomes evident when its programmable features are employed. This particularly refers to the ability to configure the Xtravert's operation in five specific areas (fig. 2.1):

- input frequency control source and format.
- analogue output source and format.
- process control, feedback
- relay outputs
- digital (switch) inputs

This configurability means that the Xtravert can often be employed as a complete stand-alone process control system.

To set up the Xtravert screens, the following procedure is typically used:

1. Set up the motor information of Screen Group N.
2. Set the limits of operation using Screen Group L. Set the minimum and maximum frequencies (Screens L1 and L2). The current limit on Screen L3 is typically set to 120% of the motor rated current (Screen N1). Use Screen L4 for current limit time-out (typically not required). Set Screen L5 to inhibit reverse direction being selected (typical for pumps).
3. Set up the control sources via Screen Group I. If local control is not required then disable the Display Unit's Start and Stop-Reset buttons via Screen I1. Select the speed reference source via Screen I2. If analogue input 1 (AIN1) is to be used then select the format (0-10V or  $\pm 10V$ ) for Terminal T14. Set the span of the analogue inputs using Screens I5 to I8. Before setting the desired input mode at Screen I9, make certain that Terminal T8 is open to prevent inadvertent starting.
4. External monitoring of the Xtravert is achieved using analogue output 1 (AO1) at Terminal T18 and the two relays (RLY1 and RLY2) at Terminals T1 to T5. These are set up using Screen Group O. Start by setting analogue output 1 (AO1) to the required source using Screen O1. Set the analogue output format (0-10V,  $\pm 10V$ , 4-20mA) at Terminal T18 using Screen O2. Set the relay output selections using Screens O3 and O4. If using comparators as a relay source then set up using Screen Group C.
5. The ramp rates for accelerating and decelerating are then set using Screen Group R and the Start/Stop modes are set via Screen Group S.
6. Performance enhancements can now be set by applying voltage boost (Screen S3) if the motor has trouble starting the load. DC Stopping can be set up using Screens S4 and S5 to hold the motor near zero speed. For motors having problems with condensation, DC Heat (Screen S6) can be used to provide a small DC current to keep the motor warm.

More complex control schemes (e.g., pressure control using the internal PID process controller) will require the installer to fully read the manual to understand the wide range of features and flexibility within the Xtravert.

The following section provides full descriptions of the function and setting up of all Xtravert screen controls.




Figure 2.1: Structure of the Xtravert Control System

---

## THE STATUS LINE

<b>Screen</b>	<b>STP 0.0A +0.0Hz</b>
Description	STATUS
Notes	ALWAYS DISPLAYED
Function	This is the top line of the display and is permanently displayed. The status line shows Xtravert status, motor current and output frequency according to the following:

### STATUS MESSAGES:

<b>Indication</b>	<b>STP</b>
Message	STOPPED
Notes	Xtravert stopped.
<b>Indication</b>	<b>SPG</b>
Message	STOPPING
Notes	Xtravert is stopping.
<b>Indication</b>	<b>RDY</b>
Message	READY
Notes	Xtravert is ready to run. A start command has been received but the speed demand does not exceed the minimum frequency.
<b>Indication</b>	<b>RUN</b>
Message	RUN
Notes	Xtravert is running.
<b>Indication</b>	<b>INC</b>
Message	INCHING
Notes	Xtravert is responding to an inch command.
<b>Indication</b>	<b>ACC</b>
Message	ACCELERATING
Notes	Xtravert is accelerating from a lower frequency to a higher one.
<b>Indication</b>	<b>DEC</b>
Message	DECELERATING
Notes	Xtravert is decelerating from a higher frequency to a lower one.
<b>Indication</b>	<b>ILT</b>
Message	CURRENT LIMITING
Notes	Xtravert has reduced the output frequency to maintain the motor current at or below the current limit setting.
<b>Indication</b>	<b>VLT</b>
Message	VOLTAGE LIMITING
Notes	Xtravert is limiting the deceleration rate to avoid excessive regeneration
<b>Indication</b>	<b>HST</b>
Message	HOST STOP (Serial Communications Option)
Notes	Xtravert has stopped under a command via local control or host computer.
<b>Indication</b>	<b>FLT</b>
Message	FAULT TRIP

---

Notes Xtravert has tripped on a fault (refer to Screen F for detail).

### DISPLAY STATUS, OVERLOADS:

The overload status is indicated by a flashing lower case letter while the overload is present.

**Indication** i

**Message** Current exceeds Xtravert rating.

**WARNING:** The Xtravert will eventually shut down to protect itself if this overload condition persists.

**Indication** m

**Message** Current exceeds motor capability.

**WARNING:** The thermal model of the motor indicates the motor will become too hot if this condition persists. The Xtravert will eventually stop to protect the motor if this condition persists.

### OUTPUT CURRENT & FREQUENCY

**Indication** 0.0A

**Message** Output current.

**Notes** The output current level supplied to the load.

**Indication** +0.0Hz

**Message** Output frequency.

**Notes** The frequency of the output voltage. The sign represents phase sequence; + is forward (U, V, W) phase sequence.

### MOTOR ROTATION DIRECTION

According to IEC34–7, the motor rotates clockwise when:

- viewed from the drive (shaft) end,
- motor terminals U1, V1 and W1 (or U2, V2 and W2) are connected to Xtravert phases U, V, and W respectively,
- and the Xtravert is operating with “+” forward speed.

---

**SCREEN GROUP A      AUXILIARY SCREENS**
**A1****A1                      SET LOCAL SPEED SETPOINT****A2**

**Screen**                    **A1 LOCAL S= +50.0Hz**  
**Description**            LOCAL SPEED SETPOINT  
**Min/Max**                -120/+120  
**Units**                    HERTZ

**A3**

**FUNCTION**            Local control of the set frequency.  
**SETTING UP**        Must be selected as the reference speed source (Screen I2) before it will take effect. Although this screen can be adjusted to  $\pm 120$ Hz, the Xtravert output frequency is constrained to Min Fr and Max Fr settings (Screens L1, L2).

**A4****A2, A3, A4            EXTENDED STATUS SCREENS**

**Screen**                    **A2 T=100% R= +50.0Hz**  
**Description**            MOTOR TEMPERATURE;  
                                  REFERENCE SPEED  
**Units**                    %, HERTZ  
**FUNCTION**            Shows estimated motor temperature and the input reference speed.

**Screen**                    **A3 MOTOR RPM = 460**  
**Description**            MOTOR RPM  
**Units**                    RPM (Revolutions per minute)  
**FUNCTION**            Shows motor reference speed in RPM. Screen N5 must be set appropriately for this value to be correct.

**Screen**                    **A4 Vdc=565V Vo=400V**  
**Description**            DC BUS VOLTAGE; OUTPUT VOLTAGE  
**Units**                    V(DC);V(AC)  
**FUNCTION**            Shows the internal DC bus voltage of the Xtravert, and the AC voltage applied to the motor.

---

**SCREEN GROUP C      COMPARATOR SCREENS**

C1

**C1, C2      SPEED SENSE RELAY SETPOINTS**

**Screen**            **C1 FR ON =12.0Hz**  
**Description**    FREQUENCY RELAY UPPER SET POINT  
**Min/Max**        RELAY OFF/120  
**Units**            HERTZ

C2

**Screen**            **C2 FR OFF=10.0Hz**  
**Description**    FREQUENCY RELAY LOWER SET POINT  
**Min/Max**        0.0/RELAY ON  
**Units**            HERTZ

C3

**FUNCTION**      To set the operating points of the frequency sensing relay controls.

**SETTING UP**    Adjust the setpoints to the levels required by your process.  
 Configure the relay outputs using Screens O3, O4.

**C3      CURRENT SENSE RELAY SETPOINT**

**Screen**            **C3 I SENSE=16.0A\***  
**Description**    CURRENT RELAY SET POINT (5% HYST.)  
**Min/Max**        0.00/1.50xI(Inv.)  
**Units**            AMPS

**Notes**            \* This value is dependent on Xtravert current rating.

**FUNCTION**      To set the operating points of the current sensing relay control.

**SETTING UP**    Adjust the set point to the level required by your process.  
 Configure the relay outputs using Screens O3, O4.

---

## SCREEN GROUP F      FAULT SCREENS

Fault messages are automatically displayed on Screen F. To reset fault indications, first determine and remove the cause of the fault, then operate the stop/reset control (open a reset input control circuit or local keyboard control - Screen I1).

At the time of a fault occurring, the Status Line (displaying output current and output frequency), Screen A3 (displaying the motor speed in RPM) and Screen A4 (displaying DC bus volts and output volts) have their values frozen. This provides additional diagnostic information.

Fault conditions, their interpretation, and suggested remedies are listed below:

<b>Screen</b>	<b>NO FAULT</b>
Description	FAULT DISPLAY
FUNCTION	Automatic display of fault information from the following list.
<b>Fault</b>	<b>01 LOW VDC</b>
Detail	Low DC Bus Volts; Mains voltage has dropped too low ( = HV LOW TRIP - Screen S7).
Sense level	170Vac (240Vdc on DC bus)
Possible cause	Mains interruption, dip.
Action	Check supply conditions. Disable HV low trip (refer Screen S7).
<b>Fault</b>	<b>03 HIGH VDC</b>
Detail	High DC Bus Volts; DC bus voltage has risen to a dangerous level
Sense level	Internally Set.
Possible cause	Very high mains surge. Excessive regeneration from regenerative load or excessive deceleration rate (refer detailed description of Screen R2). Earth fault on motor.
Action	Reduce deceleration rate. Check motor circuit for earth fault. Apply S-curve (Screen R7).
<b>Fault</b>	<b>04 SUPPLY FLT</b>
Detail	Supply Fault; Input supply phase voltage imbalance.
Sense level	40Vac ripple voltage in Xtravert DC bus. Ripple is load dependent so phase imbalance will be most sensitive under heavy load conditions.
Possible cause	Loss of phase, fuse, motor phase loss, motor winding fault.
Action	Check supply conditions, check wiring to motor, check motor.
<b>Fault</b>	<b>05 S/W DL FLT</b>
Detail	Software Download Fault; Incorrect EPROM fitted.
Action	Seek service or replace Xtravert.
<b>Fault</b>	<b>06 EEPROM FLT</b>
Detail	EEPROM fault; Non-volatile memory (EEPROM) is faulty.
Possible cause	IC failure.
Action	Replace Xtravert.
<b>Fault</b>	<b>07 I TRIP FLT</b>
Detail	Current Trip Fault; Output current has reached a dangerous level.
Sense level	180% of Xtravert rated current.
Possible cause	Short circuit; wiring fault; circuit fault; motor fault.
Action	Check entire output circuit and motor for wiring or winding faults. Check output circuit contactors for correct operation.

---

<b>Fault</b>	<b>15 XV O/L</b>
Detail	Xtravert Overload; The temperature calculated by the Xtravert inverter thermal model has reached a dangerous level.
Sense level	150% of Xtravert rated current for 30 seconds. Maximum continuous operation possible without trip is 105% of Xtravert rating.
Possible cause	Continuous overload of Xtravert.
Action	Check load requirements.
<b>Fault</b>	<b>16 MOTOR O/L</b>
Detail	Motor Overload; The temperature calculated by the thermal model of the motor has reached a dangerous level.
Sense level	110%.
Possible cause	Excessive load on motor (current draw too high); motor load exceeds cooling capacity at the operating speed; motor phase loss; motor winding fault; motor thermal model parameters incorrectly set.
Action	Check load and thermal model settings (Screens N1–N6).
<b>Fault</b>	<b>18 DATA FLT</b>
Detail	Data Fault; Non-volatile memory (EEPROM) reading error. The Xtravert will automatically RESET ALL DATA TO THE FACTORY SET VALUES upon reset of this fault. Be sure motor is isolated before resetting fault and entering correct data.
Sense level	Checksum in memory.
Possible cause	Spurious fault; faulty memory.
Action	If fault recurs, replace Xtravert.
<b>Fault</b>	<b>21 GROUND FLT</b>
Detail	Ground Fault detection; Excessive current flow to ground.
Sense level	Internally set.
Possible cause	Motor or cable insulation fault.
Action	Check motor and cables (isolate from Xtravert first).
Note	The ground fault detection system is not to be used for personnel earth fault protection.
<b>Fault</b>	<b>22 EXT TRIP</b>
Detail	External Trip; External circuit (Terminal T10) has operated.
Sense level	+12Vdc
Possible cause	Operator, PLC, or external circuitry intervention.
Action	Check external circuitry.
<b>Fault</b>	<b>23 H/S TEMP</b>
Detail	Heatsink Temperature Trip; Xtravert heatsink too hot.
Sense level	90°C.
Possible cause	Poor ventilation; obstructed ventilation path, local ambient temperature exceeds 50°C.
Action	Check fan is operating; check ventilation and thermal conditions; improve cooling.
<b>Fault</b>	<b>25 COMMS TRIP</b>
Detail	Communications Trip; Host computer generated trip.
Possible cause	Trip generated by the host computer via serial communications.
Action	No action required.

---

<b>Fault</b>	<b>26 COMMS T/O</b>
Detail	Communications Timeout; Time since last valid serial communications data transfer has exceeded timeout period (Screen H2).
Sense level	Set by communications timeout value (Screen H2).
Possible cause	Serial Communications wiring fault; Xtravert RS232 or RS485 option board fault; host computer fault; incorrect settings (Screens H1, H2).
Action	Check complete serial communications system.
<b>Fault</b>	<b>29 ILT T/O</b>
Detail	Current Limit Timeout; Motor Stalled; Operation in current limit (Screen L3) has exceeded timeout period (Screen L4).
Sense level	User set current limit level and timeout period (Screens L3, L4).
Possible cause	Motor overload; incorrect settings.
Action	Check load and settings; refer to detailed descriptions of Screens L3, L4.
<b>Fault</b>	<b>31 CAL FLT</b>
Detail	Calibration Fault; Internal reference voltage levels are incorrect.
Possible cause	Xtravert fault.
Action	If persistent, replace the Xtravert.
<b>Fault</b>	<b>33 LVDC FLT</b>
Detail	Low Voltage DC Supply fault; Failure of +24V or $\pm 15V$ supplies.
Sense level	24V supply falls below 22Vdc; 15V supplies fall below 12Vdc.
Possible cause	Internal Xtravert fault.
Action	If fault is persistent, replace Xtravert.

---

**SCREEN GROUP H      HOST COMMUNICATION SCREENS**

H1

**H1                      SERIAL COMMUNICATIONS ADDRESS**

**Screen**                    **H1 COMMS ADR= 10**  
**Description**            SERIAL COMMUNICATIONS ADDRESS  
**Min/Max**                1/240

H2

**FUNCTION**            Sets the serial communications address.

Serial communications with the Xtravert is available with the installation of the Xtravert serial communications option module (PDL Part No. X485). This allows the Xtravert to be controlled by a host controller such as a PLC or computer from a remote location via RS232 or RS485 using the industry standard Modbus protocol. All the controls, parameters, and modes available on the Xtravert can be monitored or adjusted by using the serial communications option module. For example, the Modbus host controller can start and stop the motor, control its speed, monitor the estimated motor temperature, and the status of the drive. In addition, the host controller can monitor and control a process by accessing unused digital and analogue I/O on the Xtravert.

**SETTING UP**        The serial communications address has no effect if an Xtravert serial communications option module is not fitted. The serial communication option module (PDL Part No. X485) is connected to Terminals D1 to D3 replacing the display unit. Timeout protection is provided from Screen H2. The communication baudrate is fixed at 9600 Baud.

**H2                      SERIAL COMMUNICATIONS TIMEOUT SELECTION**

**Screen**                    **H2 COMMS T/O=OFF**  
**Description**            SERIAL COMMUNICATIONS TIMEOUT SELECTION  
**Options**                [OFF]/[1s]/[5s]/[25s]

**FUNCTION**            Provides the option of tripping the Xtravert (indicating 26 COMMS T/O) if the time since the last valid serial communications data transfer has exceeded the communications timeout period.

**SETTING UP**        If an Xtravert serial communications option module is not installed, leave this screen set to OFF (the timeout feature is active whether an Xtravert serial communications option module is fitted or not).  
 If an Xtravert serial communications option module is installed, select the required timeout period.

**Notes:**                Select a timeout period which exceeds the time between valid serial communication data transfers.

## SCREEN GROUP I INPUT SCREENS

I1

### I1 LOCAL START/STOP-RESET CONTROL

I2

**Screen**  
Description  
Options

**I1 LOCAL=STR/STP**  
LOCAL CONTROL  
NONE: LOCAL CONTROL DISABLED  
RESET: RESET ONLY  
STP-RST: STOP-RESET ONLY  
STR/STP: START/STOP-RESET ENABLED

I3

**FUNCTION**

Enables or disables the display unit Start/Stop-Reset.

### I2 SPEED REFERENCE SOURCE

**Screen**  
Description  
Options

**I2 REF SP=LOCAL**  
SPEED REFERENCE SOURCE  
REFER TABLE BELOW

**FUNCTION**

Defines which input source (from the following list) is used to control the output frequency of the Xtravert.

**SETTING UP**

Select the desired speed reference source to suit your requirements from the list below.

I3

### ALTERNATIVE SPEED REFERENCE SOURCE

**Screen**  
Description  
Options

**I3 AREF S=NULL**  
ALTERNATIVE SPEED REFERENCE SOURCE  
REFER TABLE BELOW

**FUNCTION**

The alternative speed reference is selected using the programmable multifunction input as setup using Screen I9.

**SETTING UP**

Select the desired alternative speed reference source to suit your requirements from the list below.

CODE	CONTROL SOURCE
NULL	NULL (ZERO)
LOCAL	SCREEN A1
AIN1	TERMINAL T14
AIN2	TERMINAL T16
AIN1&2	MAXIMUM OF AIN1 & AIN2
AIN1+2	SUM OF AIN1 + AIN2
MREF1	SCREEN M1
MREF2	SCREEN M2
INCH1	SCREEN M1
PR O/P	PROCESS CONTROL OUTPUT

4202-188 Rev D

**I4 ANALOGUE INPUT 1 FORMAT****Screen I4 AIN1 = 0-10V**

Description Selects the format of the Analogue Input 1 (AIN1)  
Options 0-10V/±10V

FUNCTION Provides the option of either 0-10V or ±10V input for Analogue Input 1

SETTING UP Select the required format for Analogue Input 1 at Terminal T14.

14

**I5-I8 ANALOGUE SCALING CONTROLS****Screen I5 A1 LO =+0.0Hz**

Description ANALOGUE INPUT 1 LOW SETPOINT  
Range -120/+120  
Units HERTZ

**Screen I6 A1 HI =+60.0Hz**

Description ANALOGUE INPUT 1 HIGH SETPOINT  
Range -120/+120  
Units HERTZ

**Screen I7 A2 LO =+0.0Hz**

Description ANALOGUE INPUT 2 LOW SETPOINT  
Range -120/+120  
Units HERTZ

**Screen I8 A2 HI =+60.0Hz**

Description ANALOGUE INPUT 2 HIGH SETPOINT  
Range -120/+120  
Units HERTZ

FUNCTION Provides controls for setting the Analogue Input spans (providing gain and offset).

**A1 LO and A2 LO**

Sets the reference when the minimum analogue level is applied to the analogue inputs.

**A1 HI and A2 HI**

Sets the reference when the maximum analogue level is applied to the analogue inputs  
The analogue inputs are linearly interpolated between the selected LO and HI settings.

SETTING UP If an analogue input is to be used for speed reference (Screens I2, I3) or process control (Screens P1, P2), it must first be selected as the source.

For Analogue Input 1, select the required format 0-10V or ±10V via Screen I4. Analogue Input 2 has a fixed format of 4-20mA. Determine the range over which analogue control is desired. Adjust the LO setting (Screens I5, I7) to the reference required at the minimum analogue input. Adjust the HI setting (Screens I6, I8) to the reference required at the maximum analogue input.

At all times, the reference speed will be constrained by the maximum and minimum speed settings (Screens L1, L2).


15

16

17

18

19



## 19 MULTIFUNCTION INPUT MODE

### Screen

19 I/P MODE =00

### Description

MULTI-FUNCTION INPUT MODE SELECT

### Options

0/12

### FUNCTION

The digital inputs of the Xtravert (Terminals T6 to T9) may be programmed to perform the many different control functions detailed on the following pages. The multi-function input mode screen defines which operating mode of the digital input controls is selected.

Detailed wiring and functional descriptions are presented in the following pages. The following are summary functional descriptions:

#### Option 0

### LOCAL CONTROL

#### Message

00 LOCAL CONTROL

#### Notes

Disables all multi-function inputs. Useful for commissioning by keyboard control without interference by external switch inputs.

#### Option 1

### 3 WIRE STANDARD WITH DIRECTION

#### Message

01 3W STANDARD

#### Notes

The normal three wire configuration. Can also be wired for two wire control.

#### Option 2

### 3 WIRE WITH ALTERNATIVE REFERENCE

#### Message

02 3W ALTERN REF

#### Notes

Provides normal three wire control plus provision to select an alternative speed reference source. The alternative speed reference source should be selected via Screen I3.

#### Option 3

### 2 WIRE WITH DIRECTION AND ALTERNATIVE REFERENCE

#### Message

03 2W ALTERN REF

#### Notes

Provides two wire start/stop control with direction reversal plus provision to select an alternative speed reference source. The alternative speed reference source should be selected via Screen I3.

---

Option 4	<b>2 WIRE START-RESET WITH DIRECTION AND ALTERNATIVE REFERENCE</b>
Message	04 2W START-RST
Notes	Provides a start-reset suitable for simple one wire control.
Option 5	<b>2 WIRE WITH DUAL ACCELERATION AND DECELERATION RATES</b>
Message	05 2W ACC/DEC
Notes	Provides the ability to externally toggle the acceleration and deceleration rate set between Screens R1, R2 and Screens R3, R4. Works also in conjunction with Screen R5.
Option 6	<b>2 WIRE WITH INCH AND ALTERNATIVE REFERENCE</b>
Message	06 2W INCH AREF
Notes	A dedicated inch input (INCH2) provides a start input while overriding the speed reference source to MREF2 (Screen M2). If the alternative reference is set to INCH1 and that input is closed then INCH3 (Screen M3 MREF3) is selected for the speed reference.
Option 7	<b>2 WIRE WITH DUAL ACCELERATION AND DECELERATION RATES, AND ALTERNATIVE REFERENCE.</b>
Message	07 2W ACC AREF
Notes	Provides the ability to externally toggle the acceleration and deceleration rate set between Screens R1, R2 and Screens R3, R4. Works also in conjunction with Screen R5. The AREF input provides provision to select an alternative speed reference source. The alternative speed reference source should be selected via Screen I3.
Option 8	<b>MULTI-REFERENCE 3 WIRE</b>
Message	08 MREF 2W
Notes	Provides seven selectable speed references (Screens M1–M7) plus zero speed according to the binary sequence of the two switch inputs XYZ (Terminals T6, T7, T9).
Option 9	<b>MULTI-REFERENCE 2 WIRE</b>
Message	09 MREF 2W AREF
Notes	Provides three selectable speed references (Screens M5–M7) plus zero speed according to the binary sequence of the three switch inputs YZ (Terminals T7, T9) plus an alternative reference input (Terminal T6). The alternative reference selection overrides the multi-reference selection.
Option 10	<b>MOTORISED POTENTIOMETER</b>
Message	10 MOTORISED POT
Notes	Provides reference control by "increase reference" and "reduce reference" push buttons. Push buttons may be connected in series/parallel to provide distributed control points. Reduce reference is defined as normally closed for fail safe operation. The motorised potentiometer switches all adjustment between the reference frequency set points MREF4 and MREF5 (Screen M4 and M5). The adjustment rate is scaled to allow full scale adjustment in 10s. The lowest absolute speed setting (or 0Hz if the range spans 0Hz) is set on power up.

---

Option 11 Message Notes	<p><b>MOTORIZED POTENTIOMETER WITH DIRECTION</b> 11 MOTOR POT DIR</p> <p>Similar to Option 10 but with start-reset and provides the ability to invert the speed reference direction.</p>
Option 12 Message Notes	<p><b>CRANE DUAL BUTTON CONTROL</b> 12 CRANE BUTTON</p> <p>A simple crane control system suited to long and cross travel. Speed and direction control by double detent (two stage action) push buttons. At closure of the first contact only of the dual action button, the Xtravert is started and the greater of the current speed or the minimum hold speed (MREF3, Screen 4 M3) is held. Closure of the second contact causes acceleration in the desired direction. Releasing the dual action button causes the Xtravert to decelerate and stop (Refer Fig.2.3). Crane brake control can be accomplished using the configurable relays operating on current and/or frequency (Refer Screens C1 to C3).</p>
SETTING UP	<p><b>WARNING:</b> Altering the multi-function input mode of the Xtravert completely reconfigures the control input terminals and the logic of their operation. Be quite sure that you understand the operating mode you require, and that any inputs already connected will not cause the Xtravert to automatically start once your mode is selected.</p>
Hints:	<p>Local Control mode is a special “safe” multi-function mode in which all inputs are disabled (the Xtravert will not start from external terminal inputs), but will still show the state and operation of the analogue and digital inputs on the Commissioning Screens (Screens Z3 to Z5). Before finally selecting your desired operating multi-function mode, use this mode to safely inspect the status and operation of all of your inputs.</p> <p>For reasons of safety, the multi-function input modes are designed so that OPENING INPUT 3 (Terminal T8) will always ensure that the Xtravert will not automatically start, regardless of what mode is selected and the status of other inputs. The Xtravert will, however, still start from keyboard and serial communications inputs when local control is selected. To prevent starting from any source, the External Trip input (Terminal T10) should be opened.</p> <p>Refer to the following table to determine which input mode your application requires. Ensuring Terminal T8 (at least) is open, so that the Xtravert will not automatically start, select your desired input mode.</p>

SCREEN	DESCRIPTION	CONTROL SWITCH INPUTS				
		MFI 1	MFI 2	MFI 3	MFI 4	XTRIP
		T6	T7	T8	T9	T10
00 LOCAL CONTROL	LOCAL	DISABLED	DISABLED	DISABLED	DISABLED	EXT. TRIP
01 3W STANDARD	3 WIRE, DIRECTION INVERT	STOP	START	ASTOP-RST	INV DIRN	EXT. TRIP
02 3W ALTERN REF	3 WIRE, ALTERNATIVE REF	STOP	START	ASTOP-RST	AREF	EXT. TRIP
03 2W ALTERN REF	2 WIRE, DIRECTION, AREF	STR/STP	INV DIRN	ASTOP-RST	AREF	EXT. TRIP
04 2W START-RST	2 WIRE, START-RST, AREF	START/RST	INV DIRN	ASTOP	AREF	EXT. TRIP
05 2W ACC/DEC	2 WIRE, START-RST, ALT ACC	ALT. ACC/DEC	INV DIRN	START-RST	AREF	EXT. TRIP
06 2W INCH AREF	2 WIRE, INCH	STR/STP	INCH2	ASTOP-RST	AREF	EXT. TRIP
07 2W ACC AREF	2 WIRE, ALT ACC/DEC	STR/STP	ALT ACC/DEC	ASTOP-RST	AREF	EXT. TRIP
08 MREF 3W	MULTI-REF 3 WIRE	X	Y	ASTOP-RST	Z	EXT. TRIP
09 MREF 2W AREF	MULTI-REF 2WIRE, AREF	AREF	Y	ASTOP-RST	Z	EXT. TRIP
10 MOTORISED POT	MOTORISED POTENTIOMETER	STR/STP	UP	ASTOP-RST	DOWN	EXT. TRIP
11 MOTOR POT DIR	MOTORISED POT. DIRECTION	INV DIRN	UP	START-RST	DOWN	EXT. TRIP
12 CRANE BUTTON	DUAL BUTTON CONTROL	-HOLD	+HOLD	ADJUST	SLOW	EXT. TRIP

4202-192 Rev C

*Figure. 2.1: Multi-function Digital Input Configurations*

<b>Input</b>	<b>Start</b>
Active State	Closed
Function	Starts Xtravert; latching.
Conditions	Stop closed, Alternative stop-reset closed; no faults.
<b>Input</b>	<b>Stop</b>
Active State	Open
Function	Stops Xtravert.
<b>Input</b>	<b>Start-Reset</b>
Active State	Closed
Function	Resets fault; starts Xtravert; non-latching.
Conditions	Fault removed. Alternative stop-reset closed; no faults.
<b>Input</b>	<b>Start/Stop</b>
Active State	Closed
Function	Closed starts Xtravert; non-latching.
Conditions	Alternative stop-reset closed; no faults.
<b>Input</b>	<b>Invert Direction</b>
Active State	Closed
Function	Causes Xtravert to reverse (inverts reference frequency).
<b>Input</b>	<b>Alternative Stop-Reset</b>
Active State	Open
Function	Decelerates according to alternative stop rate (Screen R6); Resets fault; latching.
Conditions	Fault removed.

<b>Input</b>	<b>Inch 1</b>
Active State	Closed
Function	Starts Xtravert at Inch 1 speed (MREF1, Screen M1). Not latched.
Conditions	Stop or Alternative stop-reset closed; no faults.
Notes	Inch 1 may be selected via the alternative reference (Screen I3).
<b>Input</b>	<b>Inch 2</b>
Active State	Closed
Function	Starts Xtravert at Inch 2 speed (MREF2, Screen M2). Not latched.
Conditions	Alternative stop-reset closed; no faults.
<b>Input</b>	<b>X, Y, Z</b>
Active State	Closed
Function	Starts Xtravert using the multi-reference setpoints. Refer Screens M1–M7.
Conditions	Alternative stop-reset closed; no faults.
<b>Input</b>	<b>Alternative Acceleration/Deceleration</b>
Active State	Closed
Function	Selects alternative acceleration/deceleration. Refer Screens R1–R4.
<b>Input</b>	<b>Alternative Reference</b>
Active State	Closed
Function	Selects the alternative reference (Screen I3).
<b>Input</b>	<b>Increase Speed Reference</b>
Active State	Closed
Function	Increase the motorised potentiometer setpoint.
Conditions	Decrease speed reference closed.
<b>Input</b>	<b>Decrease Speed Reference</b>
Active State	Open
Function	Decrease the motorised potentiometer setpoint.
Conditions	Increase speed reference open.
<b>Input</b>	<b>-Hold, +Hold</b>
Active State	Closed
Function	Dual Button Control: Holds current speed in indicated direction when closed.
<b>Input</b>	<b>Adjust</b>
Active State	Closed
Function	Dual Button Control: Increases speed in direction according to -Hold, +Hold.
Conditions	-Hold or +Hold closed.




Figure 2.2: Multi-Function Input Configurations





Figure 2.3: Multifunction Input Mode 12 - Dual Button Crane control wiring

---

**SCREEN GROUP L      LIMIT SCREENS**

L1

**L1, L2      MINIMUM/MAXIMUM SPEEDS**

**Screen**      L1 MIN FR= 0.0Hz  
**Description**      MINIMUM FREQUENCY  
**Min/Max**      0.0/MAX FREQUENCY  
**Units**      HERTZ

L2

**Screen**      L2 MAX FR= 60.0Hz  
**Description**      MAXIMUM FREQUENCY  
**Min/Max**      MIN FREQ/120  
**Units**      HERTZ

L3

**FUNCTION**      **Minimum Frequency:** Sets a minimum frequency below which the Xtravert cannot be set to run. If run at minimum frequency (Screen L9) is enabled (Y) then the Xtravert will operate at the minimum frequency if the absolute value of the reference is set below the minimum. If run at minimum frequency is disabled (N), then the Xtravert will stop under the above conditions. Inch controls allow operation below the minimum frequency.

L4

**Maximum Frequency:** Sets a maximum frequency above which the Xtravert cannot be instructed to run. Demand by any control input of an absolute value greater than this frequency will be clamped to this frequency.

**SETTING UP**      The particular arrangement of limits and set points on the Xtravert offers a great degree of flexibility, depending upon the values chosen. Refer also to Screens I5 to I9.

**L3, L4      CURRENT LIMIT CONTROLS**

**Screen**      L3 I LIMIT=16A  
**Description**      CURRENT LIMIT  
**Min/Max**      0.05/1.50 of I(Inverter)  
**Units**      AMPS

**Screen**      L4 ILT T/O=NONE  
**Description**      CURRENT LIMIT TIMEOUT  
**Min/Max**      0.0/25.0/NONE  
**Units**      SECONDS

**FUNCTION**      To actively reduce the Xtravert frequency or acceleration to maintain load current within controllable bounds (status = ILT). Current limit timeout provides a setable maximum time of active current limit, beyond which the Xtravert will automatically trip (Fault status = 29 ILT T/O).

If the current limit timeout period is set at, or near zero, the current limit function effectively acts as a "SHEARPIN", providing rapid over-torque protection.

**SETTING UP**      Current limit: Where not strictly part of the required set-up for the particular application leave this set at 1.2 x Xtravert rated current. If there is a particular requirement for this function (e.g., for torque

L5

limiting or to ensure the motor cannot approach the overload setting, and thus will not trip out regardless of the demanded frequency) set the current limit to the desired value.

Hints:

For normal operation, avoid choosing values much below the motor's rated current as various effects (boost, rapid acceleration or deceleration) can lead to confusing results.

L6

Current limit timeout: Where not required adjust to "NONE". Adjust as appropriate for your application. For "SHEARPIN" action, set to 0.0.

L7

Hints:

In a well set up application current limit should never be required. Current limit acts to override incorrect Xtravert set up or load problems. If current limit action is observed during normal operation of the Xtravert or process, check that the set-up is correct - particularly check acceleration, deceleration, motor parameters and boost settings.

L8

## L5 REVERSE DIRECTION INHIBIT

**Screen** L5 REV INHIBIT=N  
**Description** REVERSE LOCK OUT  
**Options** [Y]ES/[N]O

**FUNCTION** Provides, as a mechanical safety function, the ability to stop the Xtravert from operating in reverse, regardless of input command or selected negative frequency.

**SETTING UP** If reverse operation is to be a normal function of the process set reverse inhibit to NO.  
 If reverse operation is not required set reverse inhibit to YES.

## L6, L7, L8 SKIP FREQUENCIES

**Screen** L6 SKIP 1 =+0.0Hz  
**Description** SKIP FREQUENCY 1  
**Min/Max** -120/+120  
**Units** HERTZ

**Screen** L7 SKIP 2 =+0.0Hz  
**Description** SKIP FREQUENCY 2  
**Min/Max** -120/+120  
**Units** HERTZ

**Screen** L8 SK BW= 10.0Hz  
**Description** SKIP BANDWIDTH  
**Min/Max** 0.0/10.0  
**Units** HERTZ

**FUNCTION** To provide two zones of reference frequencies that cannot be set. The object is to provide "keep out" areas of operation which may be selected so that natural mechanical system resonances can be avoided.


Skip frequencies 1 and 2 define the middle of each skip zone. The skip bandwidth defines the width of the zones.

**SETTING UP** Complete other commissioning first. Determine points, and breadths of any (two) mechanical resonances in your system. Enter

skip frequencies and desired bandwidth. Do not overlap skip zones unless only one zone is required. If only one skip zone is required, define the same frequency for both zones.

To turn off skip frequencies set SK BW to 0.0.

Check operation and readjust as necessary



## L9 RUN AT MINIMUM FREQUENCY

**Screen** L9 MIN FR RUN = N  
**Description** RUN AT MINIMUM FREQUENCY MODE SELECT  
**Options** [Y]ES/[N]O

**FUNCTION** When run at minimum frequency is enabled (Y), the Xtravert will continue to run even when the reference frequency is set below the minimum frequency level (MIN FR - refer to Screen L1). However, the Xtravert will operate at the minimum frequency. If run at minimum frequency is disabled (N) then the Xtravert will stop and wait in the ready mode if the reference frequency is reduced below the minimum frequency.

The inch command will override the minimum frequency limitations.

**SETTING UP** If the Xtravert is required to run (at the minimum frequency) when the reference frequency is below the minimum frequency then select [Y]ES.

If the Xtravert is required to stop and wait in the ready mode when the reference frequency is below the minimum frequency then select [N]O.

**M1****SCREEN GROUP M MULTI-REFERENCE SCREENS****M1–M7 MULTI-SPEED REFERENCES****M2**Screen **M1 MREF1= +0.0Hz**Screen **M2 MREF2= +0.0Hz**Screen **M3 MREF3= +0.0Hz**Screen **M4 MREF4= +0.0Hz**Screen **M5 MREF5= +0.0Hz****M3**Screen **M6 MREF6= +0.0Hz**Screen **M7 MREF7= +0.0Hz**Description **MULTI-SPEED REFERENCES**Min/Max **-120/+120**Units **HERTZ****M4****FUNCTION** These are frequency set points for use with the following modes:

Inch 1 (MREF1) Refer Screen I9, Options 2-7,9,12

Inch 2 (MREF2) Refer Screen I9, Option 6,12

Inch 3 (MREF3) Refer Screen I9, Option 6,12

**M5**

Multi-reference (MREF1 to MREF7) Refer Screen I9, Options 8,9

Motorised Potentiometer

(MREF4 and MREF5) Refer Screen I9, Option 9,10.

**M6**

The frequency set points may have negative values thus permitting reverse motor direction to be selected.

**SETTING UP** Set each multi-speed setpoint to your desired value. Leave unused multi-speed frequencies set at zero in case these are inadvertently selected.**M7**

Configure the multi-function input mode (Screen I9) as necessary to use these inputs.

SCREEN	TITLE	SPECIAL FUNCTIONS	MULTI-REFERENCE INPUTS		
			MF1 (T6) X	MF2 (T7) Y	MF4 (T9) Z
	STOP		O	O	O
M1	MREF1	INCH1	O	O	X
M2	MREF2	INCH2	O	X	O
M3	MREF3	INCH3	O	X	X
M4	MREF4	MOTORPOT MIN SPEED	X	O	O
M5	MREF5	MOTORPOT MAX SPEED	X	O	X
M6	MREF6		X	X	O
M7	MREF7		X	X	X

O = Open, X = Closed

4202-193 Rev B

---

**SCREEN GROUP N      MOTOR NAMEPLATE SCREENS**

N1

**N1, N2, N3, N5, N6 MOTOR NAMEPLATE SCREENS**

**Screen            N1 MTR CUR=14.6A**  
 Description      RATED (NAMEPLATE) MOTOR CURRENT  
 Min/Max          0.20/1.50 x I(Inverter)  
 Units              AMPS

N2

**Screen            N2 MTR VOLT= 400V**  
 Description      RATED (NAMEPLATE) MOTOR VOLTAGE  
 Min/Max          10/500  
 Units              AC VOLTS

N3

**Screen            N3 MTR FR = 50Hz**  
 Description      RATED (NAMEPLATE) MOTOR FREQUENCY  
 Min/Max          10/175  
 Units              HERTZ

N5

**Screen            N5 MTR RPM = 1490**  
 Description      RATED MOTOR RPM  
 Min/Max          0/8000  
 Units              RPM

N6

**Screen            N6 MTR COOL= 40%**  
 Description      MOTOR COOLING AT ZERO SPEED  
 Min/Max          5/100  
 Units              %

**FUNCTION**      To calibrate the Xtravert for the motor being driven. Sets the correct voltage and nominal operating frequency. Current, frequency and the motor cooling at zero speed parameters are used to define the thermal model. The thermal model performs a superior function to a thermal overload relay since it uses this data to compensate for differing cooling efficiencies when the motor is operated at other than rated frequency.

The thermal model is reset when power is removed from the Xtravert, therefore it is usually preferable to maintain power to the Xtravert at all times, and use the control inputs to stop and start the motor as required.

Where using multiple motors, each must have the same rated frequency and voltage. Each motor should be provided with its own thermal protection since it is not possible for the Xtravert to protect individual motors. Enter the total current.

**SETTING UP**    Enter motor rated (nameplate) parameters - current, voltage, frequency, speed. Estimate the efficiency of cooling of your motor at zero speed and enter this figure (this is very application dependent - as a guide 40–60% is typical; where open frame, water or force cooled motors are used, a higher cooling efficiency will be achieved).

01

**SCREEN GROUP O      OUTPUT SCREENS****O1                    ANALOGUE OUTPUT 1 (AO1) SOURCE****Screen                O1 AO1 SRC =02**

Description        ANALOGUE OUTPUT 1 (AO1) SOURCE

Options              0/15

FUNCTION          Selects the analogue output function (Terminal T18) according to the following:

Option 0            **Null**

Notes                Sets analogue output 1 (AO1) to 0V or 4mA as selected by Screen O2.

Option 1            **Full Scale**

Notes                Sets analogue output 1 (AO1) to +10V or 20mA as selected by Screen O2.

Option 2            **Output Frequency ±50Hz**Option 3            **Output Frequency ±60Hz**Option 4            **Output Frequency ±100Hz**Option 5            **Output Frequency ±120Hz**Option 6            **Output Current**

Notes                0-150% of Xtravert rated current

Option 7            **Output Volts**

Notes                0-500Vac

Option 8            **Host Communications**

Notes                -10 to +10V

Option 9            **Torque Current**

Notes                0-150% of Xtravert rated current Indicates the component of current in phase with the output voltage (i.e., real current). Owing to the high efficiency of the induction motor, this output is closely related to the motor torque under fixed V/Hz operation (X1 Min Flux = 100%).

Option 10          **Motor Power**

Notes                0-150% of motor rated power. Indicates power supplied to the motor. Useful for power control systems. A power factor of 0.9 is assumed. Accuracy is approximately ±10%

Option 11          **Reference Frequency ±50Hz**Option 12          **Reference Frequency ±60Hz**Option 13          **Reference Frequency ±100Hz**Option 14          **Reference Frequency ±120Hz**Option 15          **Process Control Error ±100%**

Notes                When using unipolar formats (0-10V, 4-20mA) signed outputs will be converted to magnitude only.

SETTING UP        Select the required option and set the format (0-10V, ±10V, 4-20mA) via Screen O2. The analogue output signal level may be observed on Screen Z5.

**O2 ANALOGUE OUTPUT FORMAT**

**Screen** O2 AO1=0–10V  
**Description** ANALOGUE OUTPUT FORMAT  
**Options** 0–10V /  $\pm 10V$  / 4–20mA  
**FUNCTION** Allows the format of the Analogue Output (Terminal T18) to be configured.  
**SETTING UP** Select the desired output as required.

O2

O3

**O3, O4 DIGITAL OUPUTS**

**Screen** O3 O/P RELAY 1 = 02  
**Description** OUTPUT RELAY 1 MODE SELECT  
**Options** 0/16

**Screen** O4 O/P RELAY 2 = 05  
**Description** OUTPUT RELAY 2 MODE SELECT  
**Options** 0/16  
**FUNCTION** Provides the ability to individually configure the state of each relay according to the following list. At power-up and during the reset interval all relays are in a de-energised state.

O4

**No.** 00  
**Name** DE-ENERGISED  
**Notes** This selection de-energises the relay.

**No.** 01  
**Name** ENERGISED  
**Notes** This selection energises the relay.

**No.** 02  
**Name** NO FAULTS  
**Energised** NO FAULT  
**De-Energised** FAULT  
**Notes** Indicates that the Xtravert is in an operational state. This relay is failsafe and will be energised on a fault free power-up or fault reset. A trip condition, power loss or Xtravert failure will cause the relay to de-energise.

**No.** 03  
**Name** START  
**Energised** STARTED  
**De-Energised** NOT STARTED  
**Notes** Indicates that the Xtravert has received a START command. Relay will de-energise when the Xtravert receives a STOP command or if the Xtravert trips on a fault.

**No.** 04  
**Name** RUN  
**Energised** RUNNING  
**De-Energised** NOT RUNNING  
**Notes** Indicates that the Xtravert is running the motor.

---


<b>No.</b>	<b>05</b>
<b>Name</b>	START OR RUN
<b>Energised</b>	START OR RUN
<b>De-Energised</b>	NOT START OR RUN
<b>Notes</b>	Xtravert is started or is running
<b>No.</b>	<b>06</b>
<b>Name</b>	INVERTER O/L
<b>Energised</b>	OVERLOADED
<b>De-Energised</b>	NOT OVERLOADED
<b>Notes</b>	Indicates that the Xtravert will eventually trip (or has already tripped) on "15 XV O/L" if left running at the present current. The overload will go inactive if the output current is reduced to the Xtravert rating or less. This is a predictive overload and the relay will pulse to warn of impending trip.
<b>No.</b>	<b>07</b>
<b>Name</b>	MOTOR O/L
<b>Energised</b>	OVERLOADED
<b>De-Energised</b>	NOT OVERLOADED
<b>Notes</b>	Indicates that the motor will eventually trip (or has already tripped) on "16 Motor O/L" if left running at the present current and speed. The overload will go inactive if the cooling is improved sufficiently (higher speed) or the current is reduced sufficiently. This is a predictive overload and the relay will pulse to warn of impending trip.
<b>No.</b>	<b>08</b>
<b>Name</b>	FREQ SENSE
<b>Energised</b>	ABOVE Fr ON
<b>De-Energised</b>	BELOW Fr OFF
<b>Notes</b>	See Screens C1, C2. Becomes energised when the inverter frequency has exceeded the upper frequency sense point (FR ON - Screen C1). Becomes de-energised when the frequency goes below the lower frequency sense point (FR-OFF - Screen C2). If the lower frequency sense point is set to zero, this signal will become de-energised only when the Xtravert stops (comes out of run). If the upper frequency sense point is 0 then it will become energised as soon as the Xtravert goes into run. The upper frequency sense point will always be higher than the lower frequency sense point.
<b>No.</b>	<b>09</b>
<b>Name</b>	CURRENT SENSE
<b>Energised</b>	ABOVE SENSE CURRENT
<b>De-Energised</b>	BELOW SENSE CURRENT
<b>Notes</b>	See Screen C3. Indicates that the current has exceeded the current sense point (Screen C3). This relay output exhibits 5% hysteresis.
<b>No.</b>	<b>10</b>
<b>Name</b>	INVERTER DIRECTION
<b>Energised</b>	REVERSE
<b>De-Energised</b>	FORWARD
<b>Notes</b>	The relay reflects the sign of the output frequency.

---

<b>No.</b>	<b>11</b>
<b>Name</b>	COMMS OUTPUT
<b>Energised</b>	SET
<b>De-Energised</b>	NOT SET
<b>Notes</b>	This signal can be toggled by the serial communications line and has no relation to the state of the Xtravert. It is intended purely for user convenience.
<b>No.</b>	<b>12</b>
<b>Name</b>	AT SET FREQ
<b>Energised</b>	AT FREQUENCY
<b>De-Energised</b>	NOT AT FREQUENCY
<b>Notes</b>	$\pm 0.5\text{Hz}$ . This signal indicates that the Xtravert is not accelerating or decelerating.
<b>No.</b>	<b>13</b>
<b>Name</b>	OVERLOAD ALARM
<b>Energised</b>	OVERLOADED
<b>De-Energised</b>	NOT OVERLOADED
<b>Notes</b>	Motor overloaded or inverter overloaded.
<b>No.</b>	<b>14</b>
<b>Name</b>	POWER FLOW
<b>Energised</b>	INVERTER REGENERATING
<b>De-Energised</b>	INVERTER SUPPLYING POWER
<b>No.</b>	<b>15</b>
<b>Name</b>	FEEDBACK SENSE
<b>Energised</b>	FEEDBACK BELOW REFERENCE
<b>De-Energised</b>	FEEDBACK ABOVE REFERENCE
<b>Notes</b>	Indicates that the feedback signal has exceeded the reference signal plus half the hysteresis (Screen P7)
<b>No.</b>	<b>16</b>
<b>Name</b>	REFERENCE FREQUENCY DIRECTION
<b>Energised</b>	REVERSE
<b>De-Energised</b>	FORWARD
<b>Notes</b>	The relay reflects the sign of the reference frequency.

## SCREEN GROUP P PROCESS CONTROL SCREENS

**Introduction** The Xtravert Series process controller is a fully featured PID regulator. The setpoint and feedback sources may be selected from a wide choice of options. If selected, the process output may be routed to the speed controller to provide a speed reference source (refer Screens I2, I3). The process controller may be disabled via a digital input to give auto/manual control by selecting an alternative speed reference (Refer Screen I9).



**Tuning** The process controller may be tuned using manual Zielger-Nichols techniques or by starting with the default values:  
 Increase the Controller Gains (Screen P3) until oscillation first occurs; then set to approximately 40% this setting.  
 Decrease the Integration Time (Screen P4) until oscillation occurs; then set back to approximately 150% this setting.  
 Increase the Differential Time (Screen P5) until minimal overshoot has been achieved but oscillation has not occurred. Typically the Differential Time would not exceed 25% of the Integration Time.

### P1 PROCESS CONTROL SETPOINT SOURCE

**Screen** P1 PR SRC=NULL  
**Description** PROCESS CONTROL SETPOINT SOURCE  
**Options** REFER TABLE BELOW  
**FUNCTION** Defines which input source is used as the setpoint source for process control:

CODE	PROCESS CONTROL SETPOINT SOURCE
NULL	NO SOURCE SELECTED
LOCAL	LOCAL SETPOINT CONTROL (SCREEN A3)
AIN1	ANALOGUE INPUT 1
AIN2	ANALOGUE INPUT 2
AIN 1&2	MAXIMUM OF ANALOGUE INPUTS 1 & 2
AIN 1+2	ADDITION OF SCALED ANALOGUE INPUTS 1 + 2
MREF1	MULTI-REFERENCE 1
MREF2	MULTI-REFERENCE 2

4202-301 Rev A

P2

P3

P4

**SETTING UP** Select the desired process control setpoint source to suit your requirements.

## P2 PROCESS CONTROL FEEDBACK SOURCE

**Screen** P2 FB SRC=NONE  
**Description** FEEDBACK SOURCE

**FUNCTION** Defines which input source (from the following list) is used as feedback source for process control.

### CODE FEEDBACK SOURCE

NONE

AIN1 ANALOGUE INPUT 1 (TERMINAL T14)

AIN2 ANALOGUE INPUT 2 (TERMINAL T16)

**SETTING UP** Select the desired feedback source for your application.

For obvious reasons, do not select the reference and feedback from the same source.

Use the process error (Screen P6) and/or the feedback sense relay hysteresis (Screen P7) to monitor the feedback status.

## P3, P4, P5 PROCESS CONTROL PID SETTINGS

**Screen** P3 Kc= 0.1  
**Description** CONTROLLER GAIN (Kc)  
**Range** 0.1 TO 10.0

**FUNCTION** Defines the controller gain (Kc) of the process controller.

**SETTING UP** Select the desired controller gain to suit your requirements.

**Screen** P4 Ti= INF  
**Description** INTEGRATION TIME (Ti)  
**Range** 1s TO 1000s, INF

**FUNCTION** Defines the integration time of the process controller.

**SETTING UP** Select the desired integration time to suit your requirements.

When the process controller is disabled, anti-windup protection limits the process controller integrator.

Setting the integration time too small leads to faster error correction

**P5**

*Note:* but the possibility of overshoot or instability.  
The process controller has a sampling period (Ts) of 100ms.

**Screen** **P5 Td= 0.0s**  
Description DIFFERENTIATION TIME (Td)  
Range 0.0s TO 250s

**P6**

**FUNCTION** Defines the differentiation time of the process controller.  
**SETTING UP** Select the desired differentiation time to suit your requirements.  
Typically left at the default value of 0.0s for pump and HEVAC applications.

**P7**

**Screen** **P6 ERROR = +0.0%**  
Description PROCESS ERROR  
Units %  
**FUNCTION** Displays the difference between the process reference (screen P1) and the process feedback (screen P2).

## **P7 FEEDBACK SENSE RELAY HYSTERESIS**

**Screen** **P7 FB RLY=10.0Hz**  
Description FEEDBACK SENSE RELAY HYSTERESIS  
Min/Max 0.0/120  
Units HERTZ

**FUNCTION** To set the operating points of the feedback sensing relay. This relay is useful to show that a feedback process is operating correctly and is at its setpoint.

A feedback input signal higher than the reference setpoint plus half the hysteresis frequency set in this function will de-energise the selected relay.

When the feedback drops below the reference minus half the hysteresis frequency the relay will re-energise.

Equations for relay output:

Relay de-energised:  
Feedback > reference + ½ hysteresis

Relay energised:  
Feedback < reference – ½ hysteresis

**SETTING UP** The feedback sense relay hysteresis is not used unless the Xtravert is configured for process control (feedback) operation.

Set the relay hysteresis to the value required by your feedback process.

Configure the relay output using Screens O3, O4.

**EXAMPLE** Reference = 50 Hz  
Hysteresis = 10 Hz  
Relay open  
Feedback > 50 Hz + 5 Hz  
Relay closed  
Feedback < 50 Hz – 5 Hz

---

**SCREEN GROUP R      RATE SCREENS**

R1

**R1, R2      ACCELERATION/DECELERATION RATE (NORMAL)**

**Screen**            R1 ACC=5.0Hz/s  
**Description**    ACCELERATION RATE (NORMAL)  
**Min/Max**        0.02/500  
**Units**            HERTZ/SEC

R2

**Screen**            R2 DEC=5.0Hz/s  
**Description**    DECELERATION RATE (NORMAL)  
**Min/Max**        0.02/500  
**Units**            HERTZ/SEC

R3

**FUNCTION**      Control the rate of acceleration and deceleration of the motor.

R4

**SETTING UP**    Use the slowest settings acceptable for your application. An acceleration rate which is too fast may cause the Xtravert to overload (status ILT) and automatically override your setting with a slower one. A deceleration rate which is too fast can cause the motor to regenerate (status VLT) into the Xtravert and automatically override your setting with a slower one.

R5

Being realistic with these settings generally leads to a more successful commissioning. Where fast accelerations/decelerations are called for, it is often best to use slower settings initially, until all other operations are proven (also refer Screens L3, L4, X4).

Freewheel to stop (instead of controlled deceleration) can be achieved by setting the stop mode (Screen S2) to spin.

**R3, R4, R5      ALTERNATIVE ACCELERATION/DECELERATION RATES**

**Screen**            R3 AACC=10.0Hz/s  
**Description**    ALTERNATIVE ACCELERATION RATE  
**Min/Max**        0.02/500  
**Units**            HERTZ/SEC

**Screen**            R4 ADEC=10.0Hz/s  
**Description**    ALTERNATIVE DECELERATION RATE  
**Min/Max**        0.02/500  
**Units**            HERTZ/SEC

**Screen**            R5 BRK FR= 0.0Hz  
**Description**    BREAK FREQUENCY FOR ACCEL/DECEL  
**Min/Max**        0.0/120  
**Units**            HERTZ

**FUNCTION**      To provide the option of having two acceleration and deceleration rates which can be programmed to change over at a specified break frequency.

The normal acceleration rate (Screen R1) and deceleration rate (Screen R2) are active above the break frequency. The alternative acceleration rate and deceleration rate are active below the break frequency.

R6


## SETTING UP

The break frequency is normally set to zero, thus effectively disabling the alternative rates.

If alternative accelerations are not required, leave the break frequency at 0.0Hz.

Set the alternative acceleration and deceleration as desired. Set the breakpoint to the point above which normal acceleration/ deceleration are required to be active, and below which alternative rates are required. The alternative acceleration and deceleration rates may also be selected by using a multi-function input (refer Screen I9).

Being realistic with these settings generally leads to a more successful commissioning. Where fast accelerations/decelerations are called for, it is often best to use slower settings initially, until all other operations are proven.



## R6

## ALTERNATIVE STOP DECELERATION RATE

## Screen

R6 ASTP=10.0Hz/s

## Description

ALTERNATIVE STOP DECELERATION RATE

## Min/Max

0.02/500

## Units

HERTZ/SEC

## FUNCTION

To provide a third deceleration rate which is used when the alternative stop (ASTOP) input is activated.

## SETTING UP

Adjust ASTOP to the level of deceleration required. Be sensible about choosing this value - choosing a very high rate will be of no use if the Xtravert loses control of the load while trying to stop it. Be sure to check the operation of this control while commissioning.

---

**R7 S-CURVE TIME CONSTANT****R7**

**Screen** R7 S-CURVE=0.20s  
**Description** S-CURVE TIME CONSTANT  
**Min/Max** 0.00/0.50  
**Units** SECS

**FUNCTION** S-curve is used to provide a soft change in torque during acceleration or deceleration. Use S-curve to reduce harshness of acceleration. Typical uses include reducing the effects of slackness in chains or couplings and the soft acceleration of high inertia loads (flywheels, large fans and pumps). S-curve is also useful for improving the Xtravert's ability to operate with voltage limiting.

**SETTING UP** Unless S-curve acceleration employed, leave the time constant set to 0.0 seconds.

Set the S-curve time constant to achieve the degree of acceleration softening required. Choose a setting consistent with the acceleration/deceleration settings (the S-curve time would typically equal 5–20% of the acceleration/deceleration time).

S-curve may be used as an alternative to a lower deceleration rate to help avoid voltage limiting problems when decelerating loads with high inertia (Refer Screen X8).

---

**SCREEN GROUP S      START/STOP SCREENS**

S1

**S1                      STARTING MODE**

S2

**Screen**                **S1 STR MODE=RAMP**  
**Description**        **STARTING MODE**  
**Options**                **NORMAL [RAMP] / [SPINNING]**

**FUNCTION**            Provides the option of a special starting mode for motor loads which may be spinning when started (e.g., freewheeling fans).

Problems can occur if a spinning load is started conventionally (i.e., Xtravert turns on at zero Hertz, before accelerating to the set frequency) as the load must first be stalled to near zero frequency, before being accelerated.

When spinning start is selected, the Xtravert starts at the maximum frequency, instead of zero Hertz. If the set frequency does not match the spinning frequency of the load, an over current situation arises, causing the Xtravert to operate in current limit and reduce its output frequency until the frequency matches the speed of the load. Once the frequencies match, the current will be reduced and the load will be accelerated normally toward the set point.

**Note:**                    When spin starting from the maximum frequency, the direction is set to the same as the reference frequency. When the reference frequency is 0.0Hz the spin start will be in the positive direction.

**SETTING UP**            If the Xtravert will not normally be required to start spinning loads, set the starting mode to (normal) ramp acceleration.

If starting into spinning loads is a specific requirement of your application, set the starting mode to SPIN. During a spin start, while the Xtravert is trying to match the output frequency with the motor speed, the output current will be controlled independently of the motor current limit (Screen L3) and the current limit timeout (Screen L4). For most reliable starting, set the current limit timeout to above 0.0s (or OFF) to prevent "Shearpin" tripping once the Xtravert matches the motor speed.

**S2                      STOPPING MODE**

**Screen**                **S2 STP MODE=RAMP**  
**Description**        **STOPPING MODE**  
**Options**                **[RAMP] DECELERATION / [SPIN] - DC BRAKE**

**FUNCTION**            Sets the mode of stopping. When set to ramp deceleration, deceleration during stopping is controlled by the deceleration ramp rates (Screens R2, R4). When set to spin, the Xtravert immediately jumps to zero frequency when commanded to stop, allowing the motor to freewheel (spin) to stop.

The use of spin to stop in conjunction with DC Hold/Brake (Screens S4, S5) provides a DC injection brake stopping function which does not involve regeneration and therefore does not require a dynamic brake module. It is most effective at lower speeds.

**SETTING UP** Ramp deceleration is normally employed if a controlled stopping rate is required. If it is preferable that the motor freewheel to stop, or if DC braking to stop is required, set to SPIN.

S3

### S3 TORQUE BOOST VOLTAGE AT ZERO SPEED

**Screen** S3 BOOST = 0.0%  
**Description** TORQUE BOOST VOLTAGE AT ZERO SPEED  
**Min/Max** 0.0/15.0  
**Units** %V(MOTOR)

S4

**FUNCTION** To provide a compensating voltage to improve low speed torque.

S5

**SETTING UP** Torque boost has two modes configured in Screen X2. With autoboot set to [Y]es (the default condition) the drive automatically adjusts the boost level (up to the set level) in accordance with load variations.

When set correctly the Xtravert should be capable of delivering rated torque at rated current under stall conditions (shaft stationary).

With autoboot set to [N]o the boost voltage follows standard V/Hz control.

Some experimentation is usually required to find the optimal level. Use only as much boost as is required to reliably start your motor. If you use too much boost the motor may draw excessive current, possibly overloading the Xtravert and the motor.

When several motors are run from the same inverter with differing loads, autoboot should be set to [N]o.

Pump and fan applications usually require no torque boost.

For either boost mode, a first estimate of the boost required is equal to the percent slip of the motor:

$$\text{Percent slip of Motor} = \frac{100 \times (\text{synchronous speed} - \text{rated speed})}{\text{synchronous speed}}$$

It is possible to use much higher levels of boost in autoboot mode (up to 2x percent slip of motor) and achieve better starting torque.

### S4, S5 DC STOPPING CONTROLS

**Screen** S4 DC LEVEL =0%  
**Description** DC (0Hz) HOLD/BRAKE VOLTAGE AT STOP  
**Min/Max** 0/25  
**Units** %V(MOTOR)

**Screen** S5 DC TIME =0.0s  
**Description** PERIOD OF DC HOLD VOLTAGE AT STOP  
**Min/Max** 0.0/25.0  
**Units** SECS

**FUNCTION** DC level sets the amount of DC voltage (hence current) applied to the motor when the Xtravert frequency reaches zero when stopping. When applied, the DC current causes the motor to resist movement and is used to brake the motor.

DC Time sets the period of application of the DC level after the Xtravert has reached zero frequency, upon receiving a stop

**S6**

command.

Using DC at stop together with the spin stop mode (Screen S2) can be useful in positioning control systems.

Notes:

To achieve DC holding while the control frequency is at zero, but the Xtravert is not stopped, use the boost voltage (Screen S3).

**S7**

SETTING UP

If motor braking upon stopping is not required, leave both settings to zero (factory set values).

If braking at stop is required, set the DC time to a suitable value (e.g., 2 seconds). While repeatedly stopping the motor, adjust the DC level to provide the desired braking force (typically achieved when the motor current equals its rated current). You must be careful that you do not overheat the motor by operating for too long at zero frequency, with too much DC level, or without adequate cooling. Be careful not to set the DC level so high that it causes the Xtravert to current limit (status display - ILT).

**S6 DC HEATING VOLTAGE****Screen****S6 DC HEAT =OFF**

Description

DC HEATING VOLTAGE DURING STOP

Min/Max

OFF/0.1/10

Units

%V(MOTOR)

FUNCTION

To provide standby (anti-condensation) heating of the motor by means of a small DC current. When enabled, a DC heating current flows in the motor whenever the Xtravert is stopped. Any fault causing a trip disables DC heat.

SETTING UP

If not required, leave OFF. If required, adjust the DC heat level while the Xtravert is stopped, until approximately 10–25% of rated current flows in the motor.

WARNING:

High voltage will be present on the motor terminals while DC heating is employed.

**S7 LOW VOLTAGE TRIP ENABLE/DISABLE****Screen****S7 HV LOW TRIP=N**

Description

MAINS POWER LOSS RESPONSE

Options

[Y]ES/[N]O

FUNCTION

The high voltage (mains supply) power loss function provides an optional response to a power loss situation.

Upon power loss or brown out conditions, the Xtravert continues to operate normally until the energy supplied to the motor load discharges the Xtravert high voltage DC bus. At this stage the output power from the Xtravert is disabled to prevent further energy consumption by the load, but otherwise the Xtravert continues to operate from the remaining energy in the DC bus. Depending on the size of the Xtravert (and hence the energy in its DC bus), the Xtravert can stay active for several seconds in such an event. While in this state (before the DC bus discharges below the switch mode power supply (SMPS) operating voltage) and depending upon the setting mode of this screen, the Xtravert is able to restart and continue normal operation when the mains supply returns to normal.

If the high voltage (mains supply) power loss function is set to trip (Y), the Xtravert will register a mains low fault (fault O1 LOW VDC) after a two second power loss and require resetting. If the mains returns to normal within the two seconds, the Xtravert will restart automatically and perform a spinning start at the set frequency.

If the high voltage (mains supply) power loss function is set to not trip (N), the Xtravert will stay active as long as there is sufficient DC supply (perhaps several seconds). If the mains returns to normal while the Xtravert is still active, the Xtravert will restart automatically at the current set frequency.

**SETTING UP** The decision of whether to trip or not is usually based upon questions of the safety of automatically restarting equipment after brief power outages, of the ability of associated equipment to continue normal operation and of the reliability required of a process.

You must assess these factors to make your decision.

**X1****SCREEN GROUP X XTRAVERT TUNING SCREENS****X1 DYNAFLUX MINIMUM FLUX LEVEL****X2**

**Screen** X1 MIN FLUX=100%  
**Description** DYNAFLUX MINIMUM FLUX LEVEL  
**Min/Max** 40/100  
**Units** %V(MOTOR)

**FUNCTION** Sets the minimum flux level that the motor will be operated at under reduced load conditions.

The Xtravert incorporates the Dynaflux (dynamic flux) automatic motor flux optimising system. This system is particularly useful for reducing noise and power loss by automatically reducing motor flux levels (and so losses and noise), in reduced load situations.

**SETTING UP** If the flux reducing feature is not required, leave set at 100% (factory set value)

Dynaflux is best suited for slowly varying loads (e.g. pump and fan). This is due to the possibility of motor stall, upon a rapid load increase at a time when there is insufficient fluxing.

For fan and pump (or similar) loads, set to the lowest value, consistent with reliable operation. Usually 40% will be suitable.

Using a value which is too low can lead to instability or surging. If this occurs, increase the minimum flux level.

Selecting intermediate levels of minimum fluxing caters for more dynamic loads with reduced amounts of Dynaflux action.

Set the minimum flux level to 100% for highly dynamic loads (e.g. servos and cranes).

**X2 TORQUE BOOST MODE**

**Screen** X2 AUTOBOOST=Y  
**Description** SELECT TORQUE BOOST MODE  
**Options** [Y]ES/[N]O

**FUNCTION** In order to obtain full torque at low frequency, voltage boost must be applied. This option permits configuration for automatic boost (Y) or fixed boost (N). Refer to Screen S3 for set-up of boost levels.

**SETTING UP** For normal single motor operation, Autoboot provides best performance and should be left set to [Y]ES. For multiple motor operation, set Autoboot to [N]O.

Autoboot automatically varies the boost level according to the load condition, as a ratio of the level set by Screen S3. Screen S3 must still be set to a level appropriate to the motor being used.

**X3 SLIP FREQUENCY****X3**

**Screen** X3 SLIP FR=0.0%  
**Description** FULL LOAD SLIP COMPENSATION  
**Min/Max** 0.0/10  
**Units** %

**X4**

**FUNCTION** Provides improved speed regulation under conditions of varying load torque. Load current is sensed and used to provide a small proportional increase in frequency to compensate for the slip of the induction motor as load changes.

**SETTING UP** Leave slip compensation set to 0.0% unless you have a special requirement for improved speed regulation.

Calculate the full load slip frequency of the motor and enter this frequency

e.g., for a 1420 rpm, 50Hz, 4 pole motor:

synchronous speed = 1500rpm

full load speed = 1420rpm

slip speed = 1500-1420 = 80rpm

slip % = (slip speed x 100) / synchronous speed  
 = (80 x 100)/1500 = 5.3%

Better speed regulation may possibly be achieved by actually measuring shaft speed under varying load and experimentally setting the slip compensation

**X4 I LIMIT SLIP**

**Screen** X4 ILT SLIP=2.0%\*  
**Description** CURRENT LIMIT SLIP VALUE  
**Min/Max** 0.0/9.9/OFF  
**Units** %

**Notes** \* This value is dependent on Xtravert current rating.

**FUNCTION** Current Limit Slip(ILT) is a variable used to enhance the stability of current limit control by entering a motor slip parameter.

Do not adjust this parameter unless current limit action is unstable. Nominally this value should be set to the rated percent slip of the motor (see Screen X3 to calculate this value). To improve stability of current limit use a lower figure (the penalty against this is that predictive current limit action will occur at an earlier stage, more severely limiting acceleration rates and possibly intruding more into the normal area of operation). Predictive current limit can be turned off by setting ILT Slip to "off".

In applications requiring fast acceleration or deceleration current limit slip should be set to "off" and the current limit to maximum.

**X5****X5 VOLTAGE LIMIT SLIP**

**Screen** X5 VLT SLIP=2.0%\*  
**Description** VOLTAGE LIMIT SLIP  
**Min/Max** 0.0/9.9  
**Units** %  
**Notes** \* This value is dependent on Xtravert current rating.

**X6****FUNCTION**

If a motor is overdriven (e.g., by decelerating its attached load too fast) it will regenerate into the Xtravert. Too much regeneration will cause the Xtravert to take evasive action ("voltage limiting") by reducing the deceleration rate as regeneration occurs.

**X7**

The voltage limit slip setting is an adjustment which is used to enhance the stability of voltage limiting control by providing a motor slip parameter.

**SETTING UP**

Do not adjust this setting unless voltage limiting is unstable. Nominally this value should be set to the rated percent slip of the motor (see Screen X3 to calculate this value). To improve stability of voltage limit use a lower value. The penalty against this is that voltage limiting will occur at an earlier stage, thus affecting deceleration more.

The S-curve setting (Screen R7) may also be used to improve stability during voltage limiting.

**X6 NO LOAD DAMPING**

**Screen** X6 DAMPING=0.4%\*  
**Description** NO LOAD DAMPING  
**Min/Max** 0.0/5.0  
**Units** %  
**Notes** \* This value is dependent on Xtravert current rating.

**FUNCTION**

Some motors may become unstable and appear to surge when operated at light load and at certain speeds. The damping term may be introduced to eliminate this tendency.

**SETTING UP**

Do not adjust this value unless light load stability problems exist. Increase setting to improve stability. Increasing the setting too far may induce instability.

The setting is nominally equal to 20% of the calculated percentage motor slip (see Screen X3).

No load damping introduces very small output frequency variations (typically <0.1 Hz). If absolute fixed output frequency is a specific requirement of your application, set to 0.0%.

**X7 MODULATION TYPE**

**Screen** X7 SWITCH FR =WW  
**Description** MODULATION FREQUENCY  
**Options**

[NB]	NARROW BAND	8kHz
[WW]	WHISPERWAVE	8kHz
[NL]	NARROW BAND	5kHz
[WL]	WHISPERWAVE	5kHz

- FUNCTION** Alters modulation mode and switching frequency. Alters the type of noise produced by the motor. Narrow band produces a conventional fixed frequency noise spectrum. WhisperWave is a special mode which distributes the noise over a wider frequency range. The noise produced in WhisperWave mode is usually found to be less annoying and easier to mask.
- SETTING UP** To allow for direct comparison of the motor acoustic noise level, this mode may be switched while the Xtravert is running. Choose the option that you find most suitable.

## X8 REGENERATION MODE

- Screen** X8 REGEN = VCLAMP  
**Description** REGENERATION MODE  
**Options** [VCLAMP] Voltage Clamp  
 [DBRAKE] Dynamic Brake

- FUNCTION** If a motor is overdriven (e.g., by decelerating its attached load too fast) it will regenerate into the Xtravert. Too much regeneration will cause the Xtravert to trip out to protect itself (Fault O3 HIGH VDC). The regeneration mode setting controls the way in which the Xtravert responds to the onset of regeneration to avoid tripping out. When set to voltage clamp mode, the Xtravert takes evasive action by reducing the deceleration rate as regeneration occurs. This is the normal setting.
- If a dynamic brake is fitted, this will automatically absorb the regenerated energy. In this case the dynamic brake mode (which takes no evasive action) may be selected.
- SETTING UP** If your application does not use dynamic braking, leave set to voltage clamp. If your application uses dynamic braking, use dynamic brake mode only if acceptably fast response cannot be obtained using voltage clamping.

---

**SCREEN GROUP Y      MENU OPTION SCREENS**

Y1
----

**Y1                      LANGUAGE SELECTION**

Y2
----

**Screen**                    Y1 ENGLISH  
**Description**            LANGUAGE SELECTION  
 ENGLISH/DEUTSCH/ESPANOL

**FUNCTION**            Determines the language displayed by the Xtravert.

**SETTING UP**          Choose the appropriate language.

**Y2                      INITIALISATION**

**Screen**                    Y2 INITIALISE =N  
**Description**            INITIALISE ALL SETTINGS  
**Options**                 [Y]ES / [N]O

**FUNCTION**            Resets all internal settings to the default (factory set) condition. The default settings are those shown in this section, the summary tables and the commissioning configuration records.

Initialisation is usually used to completely reset an Xtravert for use in a new application. It can also be useful to return the Xtravert to a known and defined state if you have become lost or confused about the settings that are entered.

**SETTING UP**          Initialise as required.

**WARNING:**            Initialising the Xtravert **RESETS ALL SETTINGS** to the default settings. Use the Commissioning Configuration Form to record any set up that you wish to retain for re-entry after initialising.

Enter YES [Y] to initialise the Xtravert. The display shows "INITIALISING..." while doing so.

---

**SCREEN GROUP Z      COMMISSIONING SCREENS**

Z1

**Z      COMMISSIONING SCREENS**

**Screen**      **Z COMMISSION =Y**  
**Description**      COMMISSION MODE  
**Options**      [Y]ES/[N]O

Z2

**FUNCTION**      Provides a means of preventing accidental adjustment of the control screens.  
 The Xtravert must be set to commission mode (Y) before adjustment can be made to any screen except local frequency. Setting the commission screen to No prevents adjustment of any screen.

Z3

**SETTING UP**      Set this parameter to Yes if you wish to adjust any parameter. Reset the display to No when you have finished your adjustments to prevent inadvertent adjustment.

Z4

**Z2      SOFTWARE AND HARDWARE REVISIONS**

**Screen**      **X504 3P 230V 4A**  
**Z2 S/W1.1 H/W1.1**  
**Description**      SOFTWARE AND HARDWARE REVISION NUMBERS

**FUNCTION**      Shows the Xtravert Model, and the revision numbers of the Xtravert software and hardware.

Z5

**Z3      ANALOGUE INPUT 1 (AIN1) STATUS**

**Screen**      **Z3 AIN1=+10.0V**  
**Description**      STATUS OF ANALOGUE INPUT 1 (AIN1)  
**Range**      -10V TO +10V

**FUNCTION**      Displays the status of Analogue Input 1 (Terminal T14)  
 For 0-10V input,    0V to +10V  
 For ±10V input,    -10V to +10V

**Z4      ANALOGUE INPUT 2 (AIN2) STATUS**

**Screen**      **Z4 AIN2=+20mA**  
**Description**      STATUS OF ANALOGUE INPUT 2 (AIN2)  
**Range**      0mA to 20mA

**FUNCTION**      Displays the status of Analogue Input 2 (Terminal T16)  
 For 4-20mA input, 0mA to 20mA

**Z5      ANALOGUE OUTPUT 1 (AO1) STATUS**

**Screen**      **Z5 AO1=+10.0V**  
**Z5 AO1=+20mA**  
**Description**      STATUS OF ANALOGUE OUTPUT 1 (AO1)  
**Range**      -10V TO +10V or 4-20mA

**FUNCTION**      Displays the status of Analogue Output 1 (Terminal T18)  
 For 0-10Voutput,    0V to +10V

**Z6**

For  $\pm 10V$  output,  $-10V$  to  $+10V$   
 For 4-20mA output, 4mA to 20mA

**SETTING UP** This screen automatically displays the output in the required format as set by Screen O2.

**Z7**

## **Z6 MULTIFUNCTION INPUT STATUS**

**Screen** **Z6 MFI:0000 X**  
**Description** STATUS OF MULTI-FUNCTION INPUTS  
**Range** O (OPEN) or X (CLOSED)

**Screen** **Z6 MFI:0000 X**

**Reference** **0 1 2 3 4 5**

**Reference 0:** Screen number Z6

**Reference 1:** Status of Multi-function Input 1 (Terminal T6)  
 O - Open X - Closed

**Reference 2:** Status of Multi-function Input 2 (Terminal T7)  
 O - Open X - Closed

**Reference 3:** Status of Multi-function Input 3 (Terminal T8)  
 O - Open X - Closed

**Reference 4:** Status of Multi-function Input 4 (Terminal T9)  
 O - Open X - Closed

**Reference 5:** Status of External Trip Input (Terminal T10)  
 O - Open  
 X - Closed (required for normal operation)

**Note 1:** Multi-function inputs - O or X represent an Open (circuit not connected to +24V) or a Closed (circuit connected to +24V) respectively.

## **Z7 OUTPUT RELAY STATUS**

**Screen** **Z7 RLY:1=XO 2=O**  
**Description** STATUS OF OUTPUT RELAYS;  
**Range** O (OPEN) or X (CLOSED);

**Screen** **Z7 RLY:1=XO 2=O**

**Reference** **0 1 2 3**

**Reference 0:** Screen number Z7

**Reference 1:** Status of Output Relay 1 (Terminals T1/T2)  
 O (Open)  
 X (Closed)

**Reference 2:** Status of Output Relay 1 (Terminals T2/T3)  
 O (Open)  
 X (Closed)

**Reference 3:** Status of Output Relay 2 (Terminals T4/T5)  
 O (Open)  
 X (Closed)

**Note:** RLY1 is normally open on Terminals (T1/T2)  
 RLY1 is normally closed on Terminals (T2/T3)  
 RLY2 is normally open on Terminals (T4/T5)

## SECTION 3: COMMISSIONING CONFIGURATION RECORD

DRIVE Model: \_\_\_\_\_ Serial No.: \_\_\_\_\_  
 Location: \_\_\_\_\_  
 Application Type: \_\_\_\_\_

CABLE Manufacturer: \_\_\_\_\_  
 Size: \_\_\_\_\_mm<sup>2</sup>  
 Type: Screened / Unscreened  
 Length: \_\_\_\_\_m

MOTOR Manufacturer: \_\_\_\_\_  
 Model: \_\_\_\_\_  
 kW: \_\_\_\_\_ V: \_\_\_\_\_ A: \_\_\_\_\_  
 Poles: \_\_\_\_\_ rpm: \_\_\_\_\_ Wiring: Star / Delta

		RECORD 1	RECORD 2
	Date:	___/___/___	___/___/___
	Commissioned by:	_____	_____
ADJUSTMENTS	(= default)		
A1 LOCAL SP	(= +50.0Hz)	_____	_____
C1 FR ON	(= 12.0Hz)	_____	_____
C2 FR OFF	(= 10.0Hz)	_____	_____
C3 I SENSE	(= 16.0A)	_____	_____
H1 COMMS ADR	(= 10)	_____	_____
H2 COMMS T/O	(= OFF)	_____	_____
I1 LOCAL	(= STR/STP)	_____	_____
I2 REF SP	(= LOCAL)	_____	_____
I3 AREF SP	(= NULL)	_____	_____
I4 AIN1	(= 0-10V)	_____	_____
I5 A1 LO	(= +0.0Hz)	_____	_____
I6 A1 HI	(= +60.0Hz)	_____	_____
I7 A2 LO	(= +0.0Hz)	_____	_____
I8 A2 HI	(= +60.0Hz)	_____	_____

I9 I/P MODE	(= 00)	_____	_____
L1 MIN FR	(= 0.0Hz)	_____	_____
L2 MAX FR	(= 60.0Hz)	_____	_____
L3 I LIMIT	(= )	_____	_____
L4 ILT T/O	(= NONE)	_____	_____
L5 REV INHIBIT	(= N)	_____	_____
L6 SKIP1	(= 0.0Hz)	_____	_____
L7 SKIP2	(= 0.0Hz)	_____	_____
L8 SK BW	(= 10.0Hz)	_____	_____
L9 MIN FR RUN	(= N)	_____	_____
M1 MREF1	(= +5.0Hz)	_____	_____
M2 MREF2	(= +0.0Hz)	_____	_____
M3 MREF3	(= +0.0Hz)	_____	_____
M4 MREF4	(= +0.0Hz)	_____	_____
M5 MREF5	(= +0.0Hz)	_____	_____
M6 MREF6	(= +0.0Hz)	_____	_____
M7 MREF7	(= +0.0Hz)	_____	_____
N1 MTR CUR	(= 14.6A)	_____	_____
N2 MTR VOLT	(= 400V)	_____	_____
N3 MTR FR	(= 50Hz)	_____	_____
N5 MTR RPM	(=1450)	_____	_____
N6 MTR COOL	(= 40%)	_____	_____
O1 AO1 SRC	(= 02)	_____	_____
O2 AO1	(= 0-10V)	_____	_____
O3 O/P RELAY1	(= 02)	_____	_____
O4 O/P RELAY2	(= 05)	_____	_____
P1 PR SRC	(=NULL)	_____	_____
P2 FB SRC	(= NULL)	_____	_____
P3 Kc	(=0.1)	_____	_____
P4 Ti	(=INF)	_____	_____
P5 Td	(=0.0s)	_____	_____
P7 FB RLY	(= 10.0Hz)	_____	_____
R1 ACC	(= 5.0Hz/s)	_____	_____

---

R2 DEC	(= 5.0Hz/s)	_____	_____
R3 AACC	(= 10.0Hz/s)	_____	_____
R4 ADEC	(= 10.0Hz/s)	_____	_____
R5 BRK FR	(= 0.0Hz)	_____	_____
R6 ASTP	(= 10.0Hz/s)	_____	_____
R7 S-CURVE	(= 0.20s)	_____	_____
S1 STR MODE	(= RAMP)	_____	_____
S2 STP MODE	(= RAMP)	_____	_____
S3 BOOST	(= 0.0%)	_____	_____
S4 DC LEVEL	(= 0%)	_____	_____
S5 DC TIME	(= 0.0s)	_____	_____
S6 DC HEAT	(= OFF)	_____	_____
S7 HV LOW TRIP	(= N)	_____	_____
X1 MIN FLUX	(= 100%)	_____	_____
X2 AUTOBOOST	(= Y)	_____	_____
X3 SLIP FR	(= 0.0%)	_____	_____
X4 ILT SLIP	(= 4.0%)	_____	_____
X5 VLT SLIP	(= 4.0%)	_____	_____
X6 DAMPING	(= 0.8%)	_____	_____
X7 SWITCH FR	(= WW)	_____	_____
X8 REGEN	(=V-CLAMP)	_____	_____
Y1 LANGUAGE	(=ENGLISH)	_____	_____
Z2 S/W REVISION	(= x.x)	_____	_____
Z2 H/W REVISION	(= x.x)	_____	_____

## SECTION 4: USING THE XTRAVERT FOR PROCESS CONTROL

### 4.1: GENERAL NOTES


The Xtravert process controller is a fully featured PID regulator. The setpoint and feedback sources may be selected from a wide choice of options. If selected the Process Output may be routed to the speed reference source (refer Screens I2, I3). The process controller may be disabled via a digital input (selecting the alternative speed reference) to give auto/manual control.

### 4.2: APPLICATION EXAMPLE - CONSTANT PRESSURE PUMPING

Constant pressure pumping is a common application of AC Motor Speed Controllers. This section shows the configuration, wiring and adjustment of a typical example.

Constant pressure pumping systems maintain the pressure of the outgoing pipe by controlling the speed of the pump. If the demand increases (e.g., opening a tap) the pressure decreases and the pump has to wind up the speed. The system pressure is used as a feedback signal. The output pressure is selected with the setpoint potentiometer.

The example given is of a system of the following specification:



Setpoint Source	0-10V (Potentiometer)
Feedback Source	4-20mA pressure sensor 0-4 bar 24V supply, 2 wire
Motor	0.33kW, 1.1A, 415V 2700 rpm
Pump	Grundfos CH2-30 Centrifugal pump
Xtravert	X702
Start/Stop Control	2 wire
Direction	Forward, Reverse inhibited

### SETUP:

Using the simple setup procedure as outlined in section 2.1:

---

**Set up the motor information of Screen Group N.**

N1 MTR CUR = 1.1A

N2 MTR VOLT = 415V

N3 MTR FR = 50.0Hz

N5 MTR RPM = 2700

**Set up the limits of operation using Screen Group L.**

L1 MIN FR = 0.0Hz

L2 MAX FR = 50.0Hz

L3 I LIMITS = 1.3A

L5 REV INHIBIT = Y

**Set up the control sources via Screen Group I.**

I1 LOCAL = NONE

I2 REF SP = PR O/P

I3 AREF S = LOCAL

I9 I/P MODE = 07 2W ACC AREF

**External monitoring of speed is achieved via Screen Group O.**

O1 AO1 SRC = 02 O/P FREQ 0-50Hz

O2 AO1 = 0-10V

**The ramp rates are then set via Screen Group R.**

R1 ACC = 20Hz/s

R2 DEC = 20Hz/s

R6 ASTP = 20Hz/s

**The process controller is then set up using a combination of Screen Groups Pand I.**

P1 PR SRC = AIN1

P2 FB SRC = AIN2

I4 AIN1 = 0-10V

I5 A1 LO = +0.0Hz

I6 A1 HI = +40.0Hz (representing 0-4.0 bar)

I7 A2 LO = +0.0Hz

I8 A2 HI = +40.0Hz 1 (representing 0-4.0 bar)

**TUNING:**

The process controller may be tuned using manual Zielger-Nichols techniques or by starting with the default values:


Increase the Controller Gains (Screen P3) until oscillation first occurs; then set to approximately 40% this setting.

Decrease the Integration Time (Screen P4) until oscillation occurs; then set back to approximately 150% this setting.

Increase the Differential Time (Screen P5) until minimal overshoot has been achieved but oscillation has not occurred. Typically the Differential Time would not exceed 25% of the Integration Time.

In pump applications, the Differential Time (Screen P5) is not used and is left set to the default 0.05.

The process error may be observed using Screen P6 to ensure process tracking occurs.



#### 4.3: APPLICATION EXAMPLE - CONSTANT PRESSURE PUMPING WITH AUTOMATIC STOP/START CONTROL

Using Xtravert features the user can arrange to automatically stop a pump/motor for a period of no demand. Upper and lower pressure limits determine the turn off and the turn on point.

The start/stop input is wired up in such a way that the start/stop button and the feedback sense relay output are in series (to turn the Xtravert off when running on low demand).

##### EXAMPLE OF OPERATION OF CONSTANT PRESSURE PUMP

The corresponding process parameters of the Xtravert setup are:

- Setpoint pressure = reference frequency level
- Upper - lower pressure limit = feedback sense hysteresis (P7 FB RLY)
- Minimum speed (25 Hz) = minimum output frequency  $F_{min}$  (L1 MIN FR)

Using the example of Section 4.2, the configuration table has the following extra settings.

<b>Adjustment</b>	<b>L1 MIN FR</b>
(Default)	(= 0.0Hz)
Setting	25.0
Notes	Sets minimum output frequency.
<b>Adjustment</b>	<b>P7 FB RLY</b>
(Default)	(= 10.0Hz)
Setting	5.0
Notes	Hysteresis band around the reference frequency outside which the feedback sense relay changes state.
<b>Mode</b>	<b>O4 O/P RELAY 2</b>
(Default)	(= 05 START OR RUN)
Setting	15 FEEDBACK SENSE
Notes	Sets relay 2 to open when the feedback signal is higher than the reference plus half the hysteresis.
<b>Mode</b>	<b>L9 RUN AT MINIMUM FREQUENCY</b>
(Default)	(= N)
Setting	Y
Notes	Allows the drive to run at the minimum frequency (Screen L1) causing the pressure rise necessary to reach the upper hysteresis level.

## DESCRIPTION OF OPERATION

This system is similar to that described in Section 4.2 except that use is made of additional features to overcome the following problem common in pressure control systems.

### Problem

Under conditions of very low or no draw off, centrifugal pumps still maintain speed to maintain pressure. Due to this speed there may be high losses in the pump, even to the extent of boiling the fluid.

The normal solution to this problem is the addition of a non-return valve. This maintains pressure, however the pump may continue to run.

As a further solution to this problem the above system using feedback relays is implemented to automatically stop and start the pump. Key points are as follows:

- i) A minimum speed is set which guarantees to provide a degree of over-pressure under the conditions that the pump is supposed to stop (i.e., under zero flow conditions).
- ii) A feedback hysteresis level sets the over- pressure level (the amount above the set point) at which the hysteresis relay opens. Under zero flow conditions, the minimum speed setting must cause the pressure to exceed this level for this system to work.
- iii) The feedback hysteresis relay opens (the stop/start circuit) under the above condition, and stops the drive. The non return valve maintains the system pressure.
- iv) As flow resumes, the pressure drops. When the pressure drops below the set point minus hysteresis level, the feedback hysteresis relay closes, starting the drive again.
- v) Apart from this automatic stop/start mechanism, the system operates as a normal pressure control system.

## SECTION 5: APPLICATION EXAMPLE – SIMPLE FAN SPEED CONTROL

A typical application example is for simple fan speed control using a potentiometer to set 0-10V speed reference, and pushbuttons for start and stop-reset control. External speed monitoring is achieved using a simple 0-10V meter representing 0-100% speed. This section shows the configuration, wiring and adjustment of a typical example.

The example given is of a system of the following specification:

Control signal	0–10V (potentiometer)
Motor	5.5kW, 11.4A, 400V, 1450rpm
Xtravert model	X712
Stop/start control	3 wire
Direction control	None required

The configuration table (not including irrelevant and/or settings that have not been altered from factory set values) and wiring configurations follow:

### SIMPLE FAN SPEED CONTROL EXAMPLE CONFIGURATION TABLE

DRIVE NO:	_____	MODEL:	X712
LOCATION:	Fan Speed Control		
MOTOR:	kW: 5.5	A: 11.4	V: 400
POLES:	4	RPM:	1450

### SETUP

Using the procedure as set up in Section 2.1:

#### Set up the motor information of Screen Group N.

N1 MTR CUR=11.4A

N2 MTR VOLT=400V

N3 MTR FR =50Hz

N3 MTR RPM =1450

N6 MTR COOL=40%

#### Set the limits of operation using Screen Group L.

L1 MIN FR = 0.0Hz

L2 MAX FR = 50.0Hz

L3 I LIMIT = 13.6A

L5 REV INHIBIT=Y

#### Set up the control sources via Screen Group I.

I1 LOCAL=NONE

I2 REF SP=AIN1

I4 AIN1 = 0–10V

I5 A1 LO=+0.0Hz

I6 A1 HI=+50.0Hz

---

I9 I/P MODE=01 3W STANDARD

**External monitoring of speed is achieved via Screen Group O.**

O1 AO1 SRC =02 Output Frequency 0-50Hz

O2 AO1 = 0-10V

**The ramp rates are then set via Screen Group R.**

R1 ACC = 5.0Hz/s

R2 DEC = 5.0Hz/s

R6 ASTP=10.0Hz/s

Wiring could be completed using a similar form to Fig. 5.1.

START is activated by momentarily closing the normally open pushbutton connected at Terminal T7. This starts the Xtravert accelerating the motor to the reference speed defined by the potentiometer connected at Terminal T14.


STOP is activated by momentarily opening the normally closed pushbutton connected at Terminal T6. This stops the Xtravert decelerating the motor to zero speed.

The acceleration and deceleration rates are defined by Screen R1 and R2.

By momentarily opening the normally closed XTRIP pushbutton connected at Terminal T10 the Xtravert will trip, displaying the fault condition "22 EXT TRIP".

By opening the normally closed switch connected at Terminal T8, the Xtravert will stop, decelerating the motor using the alternative stop rate defined by Screen R6 (This overrides the deceleration rate defined by Screen R2). If any internal or external fault should occur, then the Xtravert may be reset (once the fault condition has been removed) upon the opening edge of the ASTOP-RESET switch.

## TYPICAL CONNECTIONS



SCREEN ALL CONTROL CABLES

Fig. 5.1: Example Fan Speed Control

## INDEX

### Symbols

±10V	14, 33, 47
0–10V	47
0-10V	14, 33
4–20mA	47

### A

A1 HI	33
A1 LO	33
A2 HI	33
A2 LO	33
Acceleration	24, 35, 38, 53, 61
Alternative Accel/Decel	38, 53
Alternative Ref.	32, 34, 38, 44
Alternative Stop Rate	37, 54
Ambient Temperature	5, 10
Analogue Gain	33
Analogue Input 1	
	32, 33, 50, 65
Analogue Input 2	32, 50, 65
Analogue Input Format	33
Analogue Inputs	14, 32, 33
Analogue Offset	33
Analogue Output	
	15, 46, 47, 65
Analogue Scaling	33
Anti-Condensation Heater	58
Autoboost	57, 60
Automatic Re-start	59

### B

Baudrate	31
Boost	57, 58, 60
Break Frequency	53

### C

Cables	13, 17
Closed Loop	50
Commission Mode	17, 65
Commissioning	17, 22
Commissioning Record	18, 64, 67
Comparators	27
Contactors	13
Control Cables	19
Control Terminals	13
Crane Control	36
Current Limit	
	18, 24, 28, 30, 41, 53, 56, 58, 61
Current Limit Slip	61
Current Limit Timeout	30, 41, 56
Current Sense Relay	27, 48
Current Trip	28

### D

Damping	62
DC Brake	56, 57
DC Bus Voltage	26, 28, 58
DC Heat	58
DC Hold	56, 57
DC Time	57
Deceleration	
	24, 35, 38, 53, 55, 61

Default Settings	29, 64
Diagnostics	19, 65
Digital Potentiometer	44
Display Unit	14, 16
Dynaflux	7, 60
Dynamic Brake	63

### E

Earth Leakage	13
Earthing	14, 17, 19
Efficiency	4, 60
Electromagnetic Compatibility	13, 19
Environment	4, 10
External Trip Input	14, 29, 36

### F

Factory Defaults	29, 64
Fail-safe Relay	47
Fan speed	74
Fault	16, 19, 24, 28, 47
Fault Information	28
Fault Reset	28, 32, 37
Feedback	33
Feedback Enable	35
Feedback Sense Relay	48, 50, 72
Feedback Source	50
Flux	60
Freewheel Stop	56
Frequency Reference	48
Frequency Relay	27
Frequency Sense	48
Frequency Sensing	27
Frequency Setpoint	26, 32
Fuses	4, 13

### G

Ground Fault	29
--------------	----

### H

Hardware Revision	65
Holdup	59
Host Control	24, 31, 46

### I

Inch	32, 37, 43, 44
Inching	24, 35
Initialisation	29, 64

Input Modes	34	Output Voltage	26
Input Processing	32	Overload	4, 25, 26, 29, 48, 53
Installation	10, 17, 22	Overload Alarm	48
<b>K</b>		<b>P</b>	
Keyboard	17	Parameter Modification	17
Keyboard Setpoint	26	Potentiometer Supply	14
<b>L</b>		Power Cables	13, 19
Language Selection	64	Power Terminals	13
LED Indicators	16	Powerloss Ride-Through	58
Limits	41	Process Control	43, 50, 70
Load Sense	27	Protection	4, 5
Local Control	26, 32, 34, 36	<b>R</b>	
Local Setpoint	26	Ready State	24, 43
Local Speed	26	Reference Frequency	26, 46
Low Volts	26, 28, 58	Reference Source	32
<b>M</b>		Reference Speed	26
Mains Power Loss	58	Regeneration	48
Maximum Frequency	41, 56	Relays	14, 47, 66
Maximum Speed	41	Reset	28, 32, 37
Minimum Flux	60	Reverse Lockout	42
Minimum Frequency	41	<b>S</b>	
Minimum Speed	41	S-Curve	50, 55
Modulation	62	Safety	19, 59
Motor Cables	13, 20		
Motor Cooling	9, 45, 58	Security	65
Motor Damping	62	Serial Communications	
Motor Direction			8, 24, 29, 30, 31, 46, 48
	25, 34, 37, 42, 44, 48	Serial Communications Timeout	
Motor Frequency	25, 45		31
Motor Instability	42, 62	Service	19, 28
Motor Nameplate	45	Setpoint	50
Motor Ratings	45	Shearpin	30, 41
Motor Resonance	42	Skip Bandwidth	42
Motor Rotation	25, 37, 42, 44, 48	Skip Frequencies	42, 43
Motor Slip	57, 61	Slip Compensation	61
Motor Speed	25	Software Revision	28, 65
Motor Temperature		Spares	19
	25, 26, 29, 48	Specifications	4
Motor Voltage	45	Speed Reference	32, 33, 48
Motorised Potentiometer	44	Speed Relay	27
Mounting	11	Speed Sense	27, 48
Multi-function Inputs		Speed Setpoint	32
	14, 32, 34, 36, 44, 54, 66	Spin Start	56
Multi-Reference	32, 44	Spin Stop	53, 56, 58
<b>N</b>		Stability	62
Nameplate	45	Stalled Motor	30, 42
Narrow Band	62	Start Mode	56
<b>O</b>		Start-Reset	35
Options	31	Starting	32
Output Current	25	Status Line	24
Output Frequency	25, 46	Stop	24
		Stop Mode	56

Stopping	32	N5 Motor RPM	45
Supply	28, 58	N6 Motor Cooling at Zero Speeds	45
Supply Frequency	4	O1 Analogue Output 1 Source	46
Supply Voltage	4	O2 Analogue Output Format	47
Switching Frequency	62	O3 Output Relay	47
<b>T</b>		O4 Output Relay 2	47
Thermal Model	9, 29, 45	P1 Feedback Source	51
Torque Boost	57, 60	P1 Process Control Setpoint Source	50
<b>V</b>		P2 Feedback Source	51
Voltage Limit	18, 24, 53, 55, 62	P3, P4, P5 Process Control PID Settings	51
Voltage Limit Slip	62	P6 Process Error	52
<b>W</b>		P7 Feedback Sense Relay Hysteresis	52
Warnings	18, 25, 58	R1 Acceleration Rate	53
Whisper Wave	7, 62	R2 Deceleration Rate	53
Wiring	13, 17, 19	R3 Alternative Acceleration Rate	53
<b>X</b>		R4 Alternative Deceleration Rate	53
Xtravert Temperature	29	R5 Break Frequency Accel/Decel	53
<b>SCREENS</b>		R6 Alternative Stop Decel Rate	54
A1 Local Speed Setpoint	26	R7 S–Curve Time Constant	55
A2 Motor Temp, Speed Ref.	26	S1 Starting Mode	56
A3 DC Bus & Output Voltage	26	S2 Stopping Mode	56
A4 Motor Speed	26	S3 Torque Speed Voltage	57
C1 Upper Speed Sense Relay Setpoints	27	S4 DC Stop Level	57
C2 Lower Speed Relay Setpoint	27	S5 DC StopTime	57
C3 Current Sense Relay Setpoint	27	S6 DC Heating Voltage	58
F Fault Screens	28	S7 Low Voltage Trip	58
H1 Serial Comms Address	31	X1 Dynaflux Minimum Flux Level	60
H2 Serial Comms Timeout	31	X2 Torque Boost Mode	60
I1 Local Start/Stop–Reset	32	X3 Slip Frequency	61
I2 Speed Reference Source	32	X4 I Limit Slip	61
I3 Alternative Speed Reference	32	X5 Voltage Limit Slip	62
I4 Analogue Input 1 Format	33	X6 No Load Damping	62, 63
I5 A1 LO	33	X7 Modulation Type	62
I6 A1 HI	33	X8 Regeneration Mode	63
I7 A2 LO	33	Y1 Language Selection	64
I8 A2 HI	33	Y2 Initialisation	64
I9 Multifunction Input Mode	34	Z Commissioning Screens	65
L1 Maximum Speeds	41	Z2 Software/Hardware Rev.	65
L2 Maximum Frequency	41	Z3 Analogue Input 1	65
L3 Current Limit Controls	41	Z4 Analogue Input 2	65
L4 Current Limit Timeout	41	Z5 Analogue Output 1	65
L5 Reverse Direction Inhibit	42	Z6 Multifunction Input	66
L6 Skip Frequency 1	42	Z7 Output Relay Status	66
L7 Skip Frequency 2	42		
L8 Skip Bandwidth	42		
L9 Run at Minimum Frequency	43		
M1–M7 Multi-speed Refs	44		
N1 Rated Motor Current	45		
N2 Rated Motor Voltage	45		
N3 Rated Motor Frequency	45		

**PDL ELECTRONICS LTD***Leaders in AC Motor Control***Head Office: 81 Austin Street, Napier, New Zealand.**

Tel: +64-6-843-5855 Fax: +64-6-843-5185

Sales branch offices in Auckland, Christchurch and Wellington.

**FREEPHONE: 0800-PDL-HELP (0800-735-4357 New Zealand only)****Internet: [www.pdl.co.nz](http://www.pdl.co.nz)****Australia:** Sales branch offices in Adelaide, Melbourne, Perth and Sydney.

Brisbane Head Office: Tel: +61-7-868-2311 Fax: +61-7-868-2366

Customer Service Hotline: 1800-644-677 (Australia only)

**Germany:** Nuremberg Tel: +49-9128-91990 Fax: +49-9128-919980